

## OPERATING INSTRUCTIONS:

<p>Joining step 1 : Lift up the actuator.</p>	
<p>Joining step 2 : FFC gets along with conductivity facing down. The parallel one inserts it in the connector.</p>	
<p>Joining step 3 : Press the actuator lightly and rotate down to make a reservation, until FFC is totally inserted and not moved.</p>	
<p>Joining step 4 : FPC / FFC removal 1.) Lift up the actuator carefully 2.) withdraw FFC from FPC.</p>	

## PRECAUTIONS:

<p>Warning!! The whirling angle can't be greater than 120 degrees.</p>	
<p>Warning!! The strength of exerting pressure should be average and pushing actuator at the center.</p>	
<p>Warning!! Lift the area overlayed, should be average and lifting actuator at the center.</p>	
<p>Warning!! Operation of the actuator before mounting on the PCB is not recommended.</p>	
<p>Warning!! Not insert FFC partially or diagonally on the wrong way.</p>	

Würth Elektronik eiSos GmbH & Co. KG  
EMC & Inductive Solutions

Max-Eyth-Str. 1  
74638 Waldenburg  
Germany  
Tel. +49 (0) 79 42 945 - 0

www.we-online.com  
eiSos@we-online.com



CREATED AK	CHECKED GM		
DESCRIPTION <b>Precaution FPC</b>			
REVISION 001.000	STATUS Valid	DATE (YYYY-MM-DD) 2018-05-16	BUSINESS UNIT eiCan