



AT COMMANDS MANUAL

ADRASTEIA-I

VERSION 1.2

MARCH 11, 2025

WÜRTH ELEKTRONIK MORE THAN YOU EXPECT

Revision history

Manual version	FW version	HW version	Notes	Date
1.0	ADRASTEIA_06.006	1.0	<ul style="list-style-type: none"> Initial release of the manual 	April 2022
1.1	ADRASTEIA_06.006	1.0	<ul style="list-style-type: none"> Updated AT%MF SOCKETDATA command. Updated AT%HTTP EV command. Added FILE Related AT Commands. 	April 2024
1.2	ADRASTEIA_06.006	1.0	<ul style="list-style-type: none"> Updated Adrastea-I General AT commands. Updated Adrastea-I Network Service Related AT commands. Updated Adrastea-I Proprietary AT commands. Updated Packet Domain AT commands. Added CoAP Related AT Commands. Added RF TX/RX test mode command (AT%TSTRF) Added Typical application use cases chapter 	March 2025

Abbreviations

Abbreviation	Name
3GPP	3rd Generation Partnership Project
AES	Advanced Encryption Standard
ASCI	Advanced Speech Call Items
APN	Access Point Name
BCD	Binary Coded Decimal
CQI	Channel Quality Indicator
CSG	Closed Subscriber Group
DCE	Data Control Equipment
DH	Deep Hibernation
DTE	Data Terminal Equipment
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
EJTAG	Embedded Joint Test Action Group
GLONASS	Global Navigation Satellite System
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
GPIO	General Purpose Input Output
I2C	Inter-Integrated Circuit
ICCID	Integrated Circuit Card Identifier. Identifies internationally a SIM card
IMS	IP Multimedia Subsystem
IRA	International Reference Alphabet
IoT	Internet of Things
IMEI	International Mobile station Equipment Identity
IMEISV	International Mobile station Equipment Identity and Software Version number
LTE	Long Term Evolution
MAC	Media Access Control
MCU	Micro controller Unit
MIB	Master Information Block
MSIO	Master In Slave Out
ME	Mobile Equipment
MT	Mobile Termination
MTU	Maximum Transfer Unit
PLMN	Public Land Mobile Network

PSM	Power Save Mode
RAM	Random Access Memory
RF	Radio Frequency
RLF	Radio Link Failure
RLP	Radio Link Protocol
RX	Receiver
SIB	System Information Block
SIM	Subscriber Identity Module
SVN	Software Version Number
SPI	Serial Peripheral Interface
TA	Terminal Adaptor
TDD	Time Division Duplexing
TE	Terminal Equipment
TX	Transmitter
UART	Universal Asynchronous Receiver/Transmitter
UE	User Equipment
UICC	Universal Integrated Circuit Card
URC	Unsolicited Response Code
USB	Universal Serial Bus
USIM	Universal Subscriber Identity Module

Contents

1	Introduction	11
1.1	Adrastea-I Key Features	13
1.2	AT command Syntax and Types	14
1.2.1	Test Command:	15
1.2.2	Read Command:	15
1.2.3	Set Command:	17
1.2.4	Execute Command:	17
1.2.5	Unsolicited Result Code Command:	18
1.3	Quick Lookup Table: AT Command Syntax and Types	19
2	General AT Commands	20
2.1	+CGMI: Request Manufacturer Identification	20
2.1.1	AT+CGMI: Execute Command	20
2.1.2	AT+CGMI: Read Command	21
2.1.3	AT+CGMI: Test Command	21
2.2	+CGMM: Request Model Identification	21
2.2.1	AT+CGMM: Execute Command	22
2.2.2	AT+CGMM: Read Command	22
2.2.3	AT+CGMM: Test Command	22
2.3	+CGMR: Request Revision Identification	22
2.3.1	AT+CGMR: Execute Command	23
2.3.2	AT+CGMR: Read Command	23
2.3.3	AT+CGMR: Test Command	23
2.4	+CGSN: Request Product Serial Number Identification	24
2.4.1	AT+CGSN: Execute Command	25
2.4.2	AT+CGSN: Read Command	25
2.4.3	AT+CGSN: Test Command	25
2.5	+GSN: Request Product Serial Number Identification	26
2.5.1	AT+GSN: Execute Command	26
2.5.2	AT+GSN: Read Command	26
2.5.3	AT+GSN: Test Command	26
2.6	+CIMI: Request International Mobile Subscriber Identity	27
2.6.1	AT+CIMI: Execute Command	27
2.6.2	AT+CIMI: Read Command	27
2.6.3	AT+CIMI: Test Command	27
2.7	+CSCS: Select TE Character Set	28
2.7.1	AT+CSCS: Set Command	29
2.7.2	AT+CSCS: Read Command	29
2.7.3	AT+CSCS: Test Command	29
2.8	+GCAP: Capabilities list	30
2.8.1	AT+GCAP: Execute Command	30
2.8.2	AT+GCAP: Read Command	30
2.8.3	AT+GCAP: Test Command	30
2.9	+CFUN: Set phone functionality	31
2.9.1	AT+CFUN: Set Command	32
2.9.2	AT+CFUN: Read Command	32

2.9.3	AT+CFUN: Test Command	32
2.10	+CGATT: Attach or detach the MT from, the Packet Domain service	33
2.11	ATZ: Reset Device	34
2.11.1	ATZ: Execute Command	34
2.12	ATI: Display Product Identification Information	35
2.12.1	ATI: Execute Command	35
2.13	AT&F0: Settings to Factory Default Values	36
2.13.1	AT&F0: Execute Command	36
2.14	ATV: Result Code Format Mode	37
2.14.1	ATV: Execute Command	37
2.15	ATE: Echoes characters	37
2.16	AT&K: UART Flow control	38
2.17	ATQ: Result Code Suppression	38
3	Network Service Related AT Commands	40
3.1	+COPN: Read Operator Names	40
3.1.1	+COPN: Execute Command	40
3.1.2	+COPN: Test Command	41
3.2	+COPS: PLMN Selection	41
3.2.1	+COPS: Set Command	41
3.2.2	+COPS: Read Command	42
3.2.3	+COPS: Read Command	42
3.2.4	+COPS: Test Command	42
3.3	+CSQ: Signal quality	45
3.4	+CESQ: Extended Signal Quality	46
3.5	+CPSMS: Power Saving Mode Setting	48
3.6	+CEDRXRDP: eDRX Read Dynamic Parameters	51
3.7	+CEDRXS: eDRX Setting	55
3.8	+CRCES: Reading Coverage Enhancement Status	58
3.9	+CSODCP: Sending of Originating data via the control plane	60
3.10	+CRTDCP: Reporting of terminating data via the control plane	62
3.11	+CCIOPT: CloT optimization configuration	63
4	(U)SIM Related AT Commands	65
4.1	+CIMI: Request International Mobile Subscriber Identity	65
4.1.1	AT+CIMI: Execute Command	65
4.1.2	AT+CIMI: Read Command	65
4.1.3	AT+CIMI: Test Command	65
4.2	+CLCK: Facility lock	66
4.3	+CNUM: Subscriber number	68
4.4	+CPIN: Enter Pin	70
4.4.1	AT+CPIN: Set Command	71
4.5	+CPWD: Change Password	72
4.5.1	AT+CPWD: Set Command	73
4.6	+CRSM: Restricted SIM access	74
4.7	%CCID: Request ICCID	76

5	Adrastea-I Proprietary AT Commands	77
5.1	AT%CSQ: Signal quality	77
5.1.1	AT%CSQ: Execute Command	78
5.1.2	AT%CSQ: Read Command	78
5.1.3	AT%CSQ: Test Command	78
5.2	AT%CMATT: PS Attach or Detach	79
5.2.1	AT%CMATT: Set Command	79
5.2.2	AT%CMATT: Read Command	79
5.2.3	AT%CMATT: Test Command	80
5.3	AT%CPININFO: Remaining Number of PIN and PUK attempts	80
5.3.1	AT%CPININFO: Execute Command	82
5.3.2	AT%CPININFO: Read Command	82
5.3.3	AT%CPININFO: Test Command	82
5.4	AT%STATUS: Current Status of the Specified Device subsystem	83
5.4.1	AT%STATUS: Execute Command	89
5.4.2	AT%STATUS: Read Command	89
5.4.3	AT%STATUS: Test Command	90
5.5	AT%RATACT: Switch to Selected RAT without full reboot	90
5.5.1	AT%RATACT: Set Command	92
5.5.2	AT%RATACT: Read Command	92
5.5.3	AT%RATACT: Test Command	92
5.6	AT%MEAS: Measurement for Serving Cell	93
5.6.1	AT%MEAS: Set Command	98
5.6.2	AT%MEAS: Read Command	99
5.6.3	AT%MEAS: Test Command	99
5.7	AT%NWOPER: Set/Query NW Operator Mode of the Modem.	99
5.7.1	AT%NWOPER: Set Command	100
5.7.2	AT%NWOPER: Read Command	100
5.7.3	AT%NWOPER: Test Command	100
5.8	AT%PDNSET: Set run-time PDN Parameters For Data PDNs	102
5.8.1	AT%PDNSET: Set Command	104
5.8.2	AT%PDNSET: Read Command	104
5.8.3	AT%PDNSET: Test Command	104
5.9	AT%SETBDELAY: Modifies the uBoot delay	105
5.9.1	AT%SETBDELAY: Set Command	105
5.9.2	AT%SETBDELAY: Read Command	105
5.9.3	AT%SETBDELAY: Test Command	105
5.10	AT%SCAN: Return the RSSI Scan Results	106
5.10.1	AT%SCAN: Set Command	107
5.10.2	AT%SCAN: Read Command	108
5.10.3	AT%SCAN: Test Command	108
5.11	AT%SCANCFG: Configure changes in regular scan procedure for manual scan	109
5.11.1	AT%SCANCFG: Set Command	110
5.12	AT%SCANCMD: For user-triggered scan procedures	111
5.13	AT%DNSRSLV: To Resolve a Specific Domain Name.	113
5.13.1	AT%DNSRSLV: Set Command	114
5.13.2	AT%DNSRSLV: Read Command	114
5.13.3	AT%DNSRSLV: Test Command	114

5.14	AT%NOTIFYEV: Notify The Events	115
5.14.1	AT%NOTIFYEV: Set Command	120
5.14.2	AT%NOTIFYEV: Read Command	120
5.14.3	AT%NOTIFYEV: Test Command	120
5.14.4	%NOTIFYEV: Unsolicited Responses	121
5.15	AT%PINGCMD: Execute PING services	121
5.15.1	AT%PINGCMD: Set Command	122
5.15.2	AT%PINGCMD: Read Command	122
5.15.3	AT%PINGCMD: Test Command	122
5.16	AT%CERTCMD: To Read/Write/Delete/list User Certificates to/from NV.	123
5.16.1	Upload CA certificate	126
5.16.2	Upload client private key	126
5.16.3	Read Client Certificate	126
5.16.4	Get the list of credential folder files:	126
5.16.5	Upload PSK ID:	127
5.16.6	Upload PSK Passphrase "mySharedKey" into file:	127
5.16.7	Read PSK ID file:	127
5.16.8	Read PSK file:	127
5.17	AT%CERTCFG: To Add/Delete Certificate (TLS) Profiles	128
5.17.1	Create New Config File Section:	130
5.17.2	Create New PSK Config File Section:	131
5.18	AT%CPSMS: Enable/Disable PSM Status Change Notification	132
5.19	AT%TSTRF: AT command for RF TX/RX test mode	134
5.19.1	RX test mode	137
5.19.2	TX test mode	137
5.20	AT%VER: Display firmware version information	138
6	AT Commands for Packet Domain	140
6.1	+CEREG: EPS Network Registration Status	140
6.1.1	AT+CEREG: Set Command	143
6.1.2	AT+CEREG: Read Command	143
6.1.3	AT+CEREG: Test Command	143
6.2	+CGEREP: Packet domain event reporting	145
6.2.1	AT+CGEREP: Set Command	146
6.2.2	AT+CGEREP: Read Command	146
6.2.3	AT+CGEREP: Test Command	146
6.3	+CGDCONT: Define PDP Context	147
6.3.1	AT+CGDCONT: Set Command	148
6.3.2	AT+CGDCONT: Read Command	149
6.3.3	AT+CGDCONT: Test Command	149
6.4	+CGACT: PDP Context Activate or Deactivate	150
6.4.1	AT+CGACT: Set Command	151
6.4.2	AT+CGACT: Read Command	151
6.4.3	AT+CGACT: Test Command	151
6.5	+CGAUTH: Define PDP Context Authentication Parameters	152
6.6	+CEMODE: UE modes of operation for EPS	153
6.7	+CGCMOD: Modify PDP Context	154
6.8	+CGCONTRDP: PDP Context Read Dynamic Parameters	155

6.9	+CGEQOS: Define EPS Quality Of Service	157
6.10	+CGPADDR: Show PDP Address(es)	158
7	FILE Related AT Commands	160
7.1	%FILECMD: AT command to read/write/delete a file	160
7.2	%FILEDATA: AT command to read/write data from/to the file	165
8	SMS Related AT Commands	167
8.1	+CMGF: Set Message Format	167
8.1.1	AT+CMGF: Set Command	167
8.1.2	AT+CMGF: Read Command	168
8.1.3	AT+CMGF: Test Command	168
8.2	+CMGD: Delete Message	169
8.3	+CMGL: List Messages	170
8.4	+CMGR: Read Messages	172
8.5	+CMGS: Send Message	175
8.5.1	AT+CMGS: Execute Command	177
8.6	+CMGW: Write Message to Memory	178
8.7	+CMSS: Send SMS from storage	180
8.8	+CNMI: SMS Event Reporting Configuration	181
8.8.1	AT+CNMI: Set Command	183
8.8.2	AT+CNMI: Read Command	183
8.8.3	AT+CNMI: Test Command	183
8.9	+CPMS: Preferred SMS message storage	184
8.10	+CSCA: SMS Service Center Address	186
8.11	+CSDH: Show SMS text mode parameters	187
8.12	+CSMP: Set SMS Text Mode Parameters	188
8.13	+CSMS: Select Message Services	189
8.14	%CMGSC: Send Message Large Message	190
9	Socket Related AT commands	192
9.1	%SOCKETCMD: To Create and Maintain Socket	192
9.2	%SOCKETDATA: To send/receive to/from The Socket	205
9.3	%MFSOCKETDATA: To send/receive Binary Data	208
9.4	%SOCKETEV: Notify About Socket Events	210
10	HTTP/HTTPS Related AT commands	212
10.1	%HTTPCFG: To Configure HTTP Connection Parameters	212
10.2	%HTTPCMD: To Communicate With HTTP Server	215
10.3	%HTTPSEND: Sending Data To The Server	216
10.4	%HTTPREAD: To Read The Body Of HTTP Response	218
10.5	%HTTPFOTAGET: To perform FOTA Procedure via HTTP/HTTPS.	219
10.6	%HTTPEV: To Notify About HTTP Events.	220
10.7	HTTP Example	222
11	GNSS Related AT Commands	224
11.1	AT%IGNSSACT: Activate GNSS Functionality	224
11.2	AT%IGNSSCFG: Set and Get GNSS run-time mode configuration.	226
11.3	AT%IGNSSINFO: Query GNSS Information	228

11.4	AT%IGNSSEV: Enable GNSS Unsolicited Notification Events	232
11.5	AT%IGNSSMEM: To Delete specific data from the GNSS storage.	234
11.6	AT%IGNSSCEP: CEP data file saved in memory	235
12	LWM2M Related AT Commands	237
12.1	AT%LWM2MCMD: Control the LWM2M client	237
12.2	AT%LWM2MOPEV: Unsolicited Command	244
12.3	AT%LWM2MEV: Notify Status of Firmware Upgrade process	247
12.4	AT%LWM2MOBJEV: Notify to Application	248
12.5	AT%LWM2MOBJRSP: Application response for %LWM2MCMDU	250
12.6	AT%LWM2MOBJDEF: Sets and gets resources definition of Host Objects	252
13	MQTT Related AT Commands	254
13.1	MQTT AT Commands	254
13.1.1	%MQTTCFG: Configure MQTT Connection Parameters	254
13.1.2	%MQTTCMD: Communicate With MQTT Server (Broker)	257
13.1.3	%MQTTEV: Notify About MQTT Events	260
13.2	MQTT AT Commands for AWS	263
13.2.1	%AWSIOTCFG: Configure AWS IoT Cloud	263
13.2.2	%AWSIOTCMD: Communicate with AWS IoT Message Broker	265
13.2.3	%AWSIOTEV: Notify About AWS IOT Events	267
13.3	Example: MQTT AT Commands for AWS	269
14	COAP Related AT commands	272
14.1	%COAPCFG: To configure COAP parameters	272
14.2	%COAPCMD: To communicate with COAP server	275
14.3	%COAPEV: To notify about COAP events	279
15	Typical application use cases	283
15.1	Select LTE-M or NB-IoT Mode	283
15.1.1	Manual selection of LTE-M or NB-IoT mode	283
15.1.2	Automatic Selection of LTE-M or NB-IoT Mode	284
15.2	Register to Network	286
15.3	Manual Network Scan	287
15.4	Activate GNSS	288
15.5	Adrastea-I Power Saving Modes	290
15.5.1	DH0 Mode Setting	290
15.5.2	DH1 Mode Setting	292
15.5.3	DH2 Mode Setting	293
15.6	Data connection with SOCKET commands	295
15.6.1	UDP communication	295
15.6.2	DTLS communication	297
15.6.3	TCP communication	300
15.6.4	TLS communication	302
15.7	HTTP connection	304
15.8	Secure HTTP (HTTPS) connection	306
15.9	MQTT connection	308
15.10	Secure MQTT connection	310
15.11	Steps for FOTA Update	313

16 References	315
17 Important notes	316
18 Legal notice	316
19 License terms	317

1 Introduction

This document provides information about the AT command set supported by the Adrastea-I. Adrastea-I module is a compact LTE-M/NB-IoT Cellular module with integrated GNSS, integrated ARM Cortex-M4 and 1MB Flash memory for customer developed applications.

Based on Sony Altair ALT1250 chipset, Adrastea-I module provide AT-Command based multi-band configurability enabling international multi-regional coverage in LTE Cat M1 / NB1 radio access technologies.

Adrastea-I includes a fully integrated global navigation satellite system solution that supports GPS and GLONASS positioning systems.

The ARM Cortex-M4 processor is exclusively for user application software, and it offers 1 MB of flash and 256 kB of RAM dedicated to this use.

Compact 13.4mm x 14.6mm x 1.85mm design allows the module to fit in small-size applications.

The module can be operated through one of two available cellular communication technologies:

- LTE-Cat.M or
- LTE-Cat.NB-IoT.

Adrastea-I EV-Kit and "Adrastea Commander" tool [1] allow getting started with the module and testing its functionalities. EV-Board can be connected to an USB port of a PC. The EV-Board also represents our reference design. For further information, refer to the EV-Board manual [2].

The module comes with declaration of conformity (CE), is compliant to RoHS, REACH and Deutsche Telekom certified.




Figure 1: Adrastea-I

1.1 Adrastea-I Key Features

Feature	Description
Physical Dimenstions	13.4mm x 14.6mm x 1.85mm
Supported Networks	<ul style="list-style-type: none"> - LTE-Cat.M - LTE-Cat.NB-IoT
LTE Supported Bands	LTE-Cat.M: B2/B3/B4/B5/B8/B12/B20/B25/B26/B28 LTE-Cat.NB-IoT: B3/B5/B8/B20/B28
Module Interfaces	<ul style="list-style-type: none"> - USIM - UART - I2C Master - SPI Master - GPIO - ADC - JTAG
Integrated GNSS	Adrastea-I includes a fully integrated global navigation satellite system solution that supports below positioning systems: <ul style="list-style-type: none"> - GPS - GLONASS
Integrated User MCU	User MCU is exclusively for user application software: <ul style="list-style-type: none"> - ARM Cortex-M4 - 1 MB Flash Memory - 256 kB RAM
Output Power class	Power Class 3 (23 dBm)
Maximum Data Rate	LTE-Cat.M: Downlink: 300 Kbps, Uplink: 375 Kbps LTE-Cat.NB-IoT: Downlink: 27.2 Kbps, Uplink 62.5 Kbps
3GPP Standard Compliance	3GPP Release 13 compliant, Upgradable to Rel 14
Firmware Upgrade	<ul style="list-style-type: none"> - Firmware upgrade over USB interface - Firmware upgrade over air
Supported Protocols	<ul style="list-style-type: none"> - IPv4, IPv6 - TCP/UDP SOCKET - HTTP/HTTPS - TLS/DTLS - LWM2M Client - MQTT
AT Commands	3GPP TS 27.007 and 3GPP TS 27.005 (3GPP Release-13) AT commands, as well as Wurth Elektronik enhanced AT commands
Operating Voltage	<ul style="list-style-type: none"> - VDD: From 2.3 V to 4.3 V - VDD_FEM: From 3.1 V to 4.3 V
Temperature Range	Operation temperature: -40 °C to +85 °C

Table 1: Module Key Features

1.2 AT command Syntax and Types

The AT commands are sent to the Adrastea-I module with the following generic syntax:

AT<+ or %><at_command_name> = <param1>,<param2><CR><LF>

Following syntactical definitions apply for AT command syntax.

- AT: AT is the command line prefix for AT commands.
- + or %: All standard AT commands starts with +. All wurth Elektronik enhanced AT commands begin with a percent sign %.
- <at_command_name>: It represents the name of the AT command.
- <param1>: Name enclosed in <angle brackets> is a syntactical element. Brackets themselves do not appear in the command line.
 - When AT command have more than 1 parameter then comma (,) is used as delimiter to separate each parameter.
 - A string type parameter should be enclosed between quotation marks "" i.e. "STRING".
 - For number type parameter positive and negative counting numbers, as well as zero are allowed.

<param2> : Name enclosed in [square brackets] represents optional parameter of an AT command. Brackets themselves do not appear in the command line. When a parameter is not given, the value will be set to the default value provided in the command description.

- If the optional parameter is at the end of AT command and this parameter is omitted then this parameter skipped entirely.
- In case of multiple optional parameters, if a parameter is omitted then „ (two delimiters with no whitespace) are mandatory for omitted parameter.
- AT or at both is OK but other combinations ("aT" or "At" or "Ta") are not supported.
- Additional whitespaces in AT command is not allowed. Additional whitespaces will return ERROR by the module.
- <CR><LF>: Mandatory Command line termination characters <CR><LF>. To increase the readability these characters are not displayed on serial port console.
- When writing or sending an SMS, Ctrl-Z (SUB, 0x1A) or ESC (0x1B) terminates the command.

1.2.1 Test Command:

A test command provides the list of the values allowed by each parameter of the AT command.

Test Command Format:

```
AT+ <Command> =?
```

and

```
AT%<Command> =?
```

Where:

AT is the command line prefix.

"+" or "%" is the prefix for extended commands.

<Command> is the body of a basic command.

=? represents a test command for checking possible subparameter values.

Test Command Example:

```
AT+CEREG=?  
+CEREG: (0,1,2,3,4,5)  
  
OK
```

1.2.2 Read Command:

A read command provides the current setting of the command parameters. It is used to find out the current command configuration.

Read Command Format:

```
AT+ <Command>?
```

and

```
AT%<Command>?
```

Where:

AT is the command line prefix.

"+" or "%" is the prefix for extended commands.
<Command> is the body of a basic command.
? represents a read command.

Read Command Example:

```
AT+CEREG?  
+CEREG: 2,5,"CB48","01CD6007",9  
  
OK
```

1.2.3 Set Command:

A set command configures the preferred settings for the specified AT command.

Set Command Format:

```
AT+<Command>=1
```

and

```
AT%<Command>=1
```

Where:

AT is the command line prefix.

"+" or "%" is the prefix for extended commands.

<Command> is the body of a basic command.

1 is a subparameter (multiple subparameters are separated by commas).

Set Command Example:

```
AT+CEREG=2  
OK
```

1.2.4 Execute Command:

Execute command is to print information text or execute a specific action for the command.

Execute Command Format:

```
AT+<Command>
```

and

```
AT%<Command>
```

Where:

AT is the command line prefix.

"+" or "%" is the prefix for extended commands.

<Command> is the body of a basic command.

Execute Command Example:

```
AT%CSQ
%CSQ: 13,99,30

OK
```

1.2.5 Unsolicited Result Code Command:

Unsolicited result codes indicates about status of operation.

Unsolicited result codes also indicates occurrence of an event not directly associated with issuance of an AT command.

Unsolicited Result Code Command Example:

```
%NOTIFYEV:"RRCSTATE",2

%NOTIFYEV: "SIB1"

%NOTIFYEV: "SIB1"

%NOTIFYEV:"RRCSTATE",0
```

1.3 Quick Lookup Table: AT Command Syntax and Types

Command Type	Command Format	Explanation
Test Command	AT+ <Command> =? AT% <Command> =?	<p>A test command provides the list of the values allowed by each parameter of the AT command.</p> <p>Where: AT is the command line prefix. "+ or %" is the prefix for extended commands. <Command> is the body of a basic command. =? represents a test command for checking possible subparameter values.</p> <p>Example: AT+CEREG=?</p>
Read Command	AT+<Command>? AT% <Command>?	<p>A read command provides the current setting of the command parameters. It is used to find out the current command configuration.</p> <p>Where: AT is the command line prefix. "+ or %" is the prefix for extended commands. <Command> is the body of a basic command. ? represents a read command.</p> <p>Example: AT+CEREG?</p>
Set Command	AT+<Command>=<...> AT% <Command> = <...>	<p>A set command configures the preferred settings for the specified AT command.</p> <p>Where: AT is the command line prefix. "+ or %" is the prefix for extended commands. <Command> is the body of a basic command. 1 is a subparameter (multiple subparameters are separated by commas).</p> <p>Example: AT+CEREG=2</p>
Execute Command	AT+<Command> AT% <Command>	<p>Execute command is to print information text or execute a specific action for the command.</p> <p>Example: AT+CGSN</p>
Unsolicited result code	%NOTIFYEV: "SIB1"	<p>Unsolicited result codes indicates about status of operation.</p> <p>Example: %NOTIFYEV: "SIB1"</p>

Table 2: AT Command Syntax and Types

2 General AT Commands

These commands are for the identification of the module.

2.1 +CGMI: Request Manufacturer Identification

The +CGMI command requests manufacturer identification.

Command	Command Type	Response
AT+CGMI	Execute	<manufacturer> or +CME ERROR: <err>
AT+CGMI?	Read	<manufacturer> OK
AT+CGMI=?	Test	OK

Table 3: AT+CGMI

Description:

Execution command causes the TA to return one or more lines of information text <manufacturer>, determined by the MT manufacturer, which is intended to permit the user of the TA to identify the manufacturer of the MT to which it is connected to. Typically, the text will consist of a single line containing the name of the manufacturer, but manufacturers may choose to provide more information if desired.

Defined values:

<manufacturer>: The identification of manufacturer. Total number of characters, including line terminators, in the information text shall not exceed 2048 characters. Text shall not contain the sequence 0<CR> or OK<CR>

Example:

2.1.1 AT+CGMI: Execute Command

```
AT+CGMI
```

```
Wurth Elektronik eiSos
```

```
OK
```

2.1.2 AT+CGMI: Read Command

```
AT+CGMI?
```

```
Wurth Elektronik eiSos
```

```
OK
```

2.1.3 AT+CGMI: Test Command

```
AT+CGMI=?
```

```
OK
```

2.2 +CGMM: Request Model Identification

The +CGMM command requests identification model determined by manufacturer.

Command	Command Type	Response
AT+CGMM	Execute	<model> or +CME ERROR: <err>
AT+CGMM?	Read	<model> OK
AT+CGMM=?	Test	OK

Table 4: AT+CGMM

Description:

Execution command causes the TA to return one or more lines of information text <model>, determined by the MT manufacturer, which is intended to permit the user of the TA to identify the specific model of the MT to which it is connected to. Typically, the text will consist of a single line containing the name of the product, but manufacturers may choose to provide more information if desired.

Defined values:

<model>: The identification model determined by manufacturer. Total number of characters, including line terminators, in the information text shall not exceed 2048 characters. Text shall not contain the sequence 0<CR> or OK<CR>.

Example:

2.2.1 AT+CGMM: Execute Command

```
AT+CGMM
```

```
WIRL-CLTI-ADRASTEAI
```

```
OK
```

2.2.2 AT+CGMM: Read Command

```
AT+CGMM?
```

```
WIRL-CLTI-ADRASTEAI
```

```
OK
```

2.2.3 AT+CGMM: Test Command

```
AT+CGMM=?
```

```
OK
```

2.3 +CGMR: Request Revision Identification

The +CGMM command requests the version of the product and other information determined by manufacturer.

Command	Command Type	Response
AT+CGMR	Execute	<revision> or +CME ERROR: <err>
AT+CGMR?	Read	<revision> OK
AT+CGMR=?	Test	OK

Table 5: AT+CGMR

Description:

Execution command causes the TA to return one or more lines of information text <revision>, determined by the MT manufacturer, which is intended to permit the user of the TA to identify the version, revision level or date, or other pertinent information of the MT to which it is connected to. Typically, the text will consist of a single line containing the version of the product, but manufacturers may choose to provide more information if desired.

Defined values:

<revision>:The version of the product and other information determined by manufacturer.Total number of characters, including line terminators , in the information text shall not exceed 2048 characters. Text shall not contain the sequence 0<CR> or OK<CR>.

Example:**2.3.1 AT+CGMR: Execute Command**

```
AT+CGMR
ADRASTEAI_06.006
OK
```

2.3.2 AT+CGMR: Read Command

```
AT+CGMR?
ADRASTEAI_06.006
OK
```

2.3.3 AT+CGMR: Test Command

```
AT+CGMR=?
OK
```

2.4 +CGSN: Request Product Serial Number Identification

Execution command returns product serial number identification like IMEI, IMEISV, SVN.

Command	Command Type	Response
AT+CGSN=<n>	Execute	AT+CGSN=1 +CGSN: "<IMEI>" OK AT+CGSN=2 +CGSN: "<IMEISV>" OK AT+CGSN=3 +CGSN: "<SVN>" OK or +CME ERROR: <err>
AT+CGMI?	Read	+CME ERROR
AT+CGSN=?	Test	+CGSN: (0-3) OK

Table 6: AT+CGSN

Description:

Execution command causes the TA to return IMEI (International Mobile station Equipment Identity number) and related information to identify the MT that the TE is connected to.

Defined values:

<n>:integer type. Indicating the serial number type that has been requested.

Value	Description
1	returns the IMEI (International Mobile station Equipment Identity)
2	returns the IMEISV (International Mobile station Equipment Identity and Software Version number)
3	returns the SVN (Software Version Number)

Table 7: +CGSN_Description

Example:

2.4.1 AT+CGSN: Execute Command

Below AT+CGSN=1 shall print IMEI of the module.

```
AT+CGSN=1  
  
+CGSN:"359100540001992"  
  
OK
```

Below AT+CGSN=2 shall print IMEISV of the module.

```
AT+CGSN=2  
  
+CGSN:"3591005400019906"  
  
OK
```

Below AT+CGSN=3 shall print SVN of the module.

```
AT+CGSN=3  
  
+CGSN:"06"  
  
OK
```

2.4.2 AT+CGSN: Read Command

```
AT+CGSN?  
  
ERROR
```

2.4.3 AT+CGSN: Test Command

```
AT+CGSN=?  
  
+CGSN: (0–3)  
  
OK
```

2.5 +GSN: Request Product Serial Number Identification

Command	Command Type	Response
AT+GSN	Execute	<Adrastea-I serial Number> OK
AT+GSN?	Read	<Adrastea-I serial Number> OK
AT+GSN=?	Test	OK

Table 8: AT+GSN

Description:

Execution command causes the TA to return SN(Product Serial Number) information to identify the MT that the TE is connected to..

Defined values:

<Adrastea-I serial Number>: Product Serial Number, Text shall not contain the sequence 0<CR> or OK<CR>.

Example:

2.5.1 AT+GSN: Execute Command

```
AT+GSN

132000199

OK
```

2.5.2 AT+GSN: Read Command

```
AT+GSN?

132000199

OK
```

2.5.3 AT+GSN: Test Command

```
AT+GSN=?

OK
```

2.6 +CIMI: Request International Mobile Subscriber Identity

Command	Command Type	Response
AT+CIMI	Execute	<IMSI> OK
AT+CIMI?	Read	ERROR
AT+CIMI=?	Test	OK

Table 9: AT+CIMI

Description:

Execution command causes the TA to return <IMSI>, which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or USIM) which is attached to MT.

Defined values:

<imsi>: string (without double quotes). International Mobile Subscriber Identity.

Example:

2.6.1 AT+CIMI: Execute Command

```
AT+CIMI
001010123456063
OK
```

2.6.2 AT+CIMI: Read Command

```
AT+CIMI?
ERROR
```

2.6.3 AT+CIMI: Test Command

```
AT+CIMI=?
OK
```

2.7 +CSCS: Select TE Character Set

Command	Command Type	Response
AT+CSCS=<chset>	Set	OK
AT+CSCS?	Read	+CSCS: <chset> OK
AT+CSCS=?	Test	+CSCS: ("UCS2","8859-1","IRA","PCCP437") OK

Table 10: AT+CSCS

Description:

Set command informs TA which character set is used by the TE. TA is then able to convert character strings correctly between TE and MT character sets.

Read command shows current setting and test command displays conversion schemes implemented in the TA.

Test command returns values supported as a compound value.

Defined values:

<chset>: string.

Value	Description
"UCS2"	16-bit universal multiple-octet coded character set. UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF. e.g. "004100620063" equals three 16-bit characters with decimal values 65, 98 and 99.
"8859-n"	ISO 8859 Latin n (1-6) character set.
"IRA"	International reference alphabet.
"HEX"	Character strings consist only of hexadecimal numbers from 00 to FF. e.g. "032FE6" equals three 8-bit characters with decimal values 3, 47 and 230; no conversions to the original MT character set shall be done.
"PCCP437"	PC character set Code.

Table 11: +CSCS_Description

Example:

2.7.1 AT+CSCS: Set Command

```
AT+CSCS="8859-1"  
OK
```

2.7.2 AT+CSCS: Read Command

```
AT+CSCS?  
+CSCS: "8859-1"  
  
OK
```

2.7.3 AT+CSCS: Test Command

```
AT+CSCS=?  
+CSCS: ("UCS2","8859-1","IRA","HEX","PCCP437")  
  
OK
```

2.8 +GCAP: Capabilities list

Command	Command Type	Response
AT+GCAP	Execute	+GCAP: +CLTE-M1 OK
AT+GCAP?	Read	ERROR
AT+GCAP=?	Test	ERROR

Table 12: AT+GCAP

Description:

This command gets the complete list of capabilities.

Example:

2.8.1 AT+GCAP: Execute Command

```
AT+GCAP
```

```
+GCAP: +CNB-1
```

```
OK
```

2.8.2 AT+GCAP: Read Command

```
AT+GCAP?
```

```
ERROR
```

2.8.3 AT+GCAP: Test Command

```
AT+GCAP=?
```

```
ERROR
```

2.9 +CFUN: Set phone functionality

Command	Command Type	Response
AT+CFUN=<fun>[,<rst>]	Set	OK
AT+CFUN?	Read	+CFUN: <fun>
AT+CFUN=?	Test	+CFUN: (list of supported <fun>s),(list of supported <rst>s)

Table 13: AT+CFUN

Description:

Set command selects the level of functionality <fun> in the module. Level "full functionality" has the highest power consumption. "Minimum functionality" has the lowest power consumption.

Defined values:

<fun>: integer.

Value	Description
0	minimum functionality
1	full functionality
2	Disable (turn off) MT transmit RF circuits only
3	Disable (turn off) MT receive RF circuits only
4	Disable phone both transmit and receive RF circuits

Table 14: +CFUN_FUN_Description

<rst>: integer.

Value	Description
0	do not reset the MT before setting it to <fun> power level Note: This shall be always default when <rst> is not given.
1	reset the MT before setting it to <fun> power level

Table 15: +CFUN_RST_Description

Example:

2.9.1 AT+CFUN: Set Command

```
AT+CFUN=4
```

```
OK
```

2.9.2 AT+CFUN: Read Command

```
AT+CFUN?
```

```
+CFUN: 1
```

```
OK
```

2.9.3 AT+CFUN: Test Command

```
AT+CFUN=?
```

```
+CFUN: (0-1,4),(0-1)
```

```
OK
```

2.10 +CGATT: Attach or detach the MT from, the Packet Domain service

Command	Command Type	Response
AT+CGATT=<state>	Set	+CME ERROR: <err>
AT+CGATT?	Read	+CGATT: <state>
AT+CGATT=?	Test	+CGATT: (list of supported <state>s)

Table 16: AT+CGATT

Description:

The execution command is used to attach the MT to, or detach the MT from, the Packet Domain service. After the command has completed, the MT remains in V.250 command state. If the MT is already in the requested state, the command is ignored and the OK response is returned. If the requested state cannot be achieved, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command.



If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup.

Any active PDP contexts will be automatically deactivated when the attachment state changes to detached. The read command returns the current Packet Domain service state. The test command is used for requesting information on the supported Packet Domain service states.

Defined values: <state>: integer. Indicates the state of PS attachment.

Value	Description
0	detached
1	attached

Table 17: +CGATT_State_Description

2.11 ATZ: Reset Device

Command	Command Type	Response
ATZ	Execute	OK

Table 18: ATZ

Description:

Reset device but doesn't return values to factory default.

Example:

2.11.1 ATZ: Execute Command

```
ATZ
```

```
OK
```

2.12 ATl: Display Product Identification Information

Command	Command Type	Response
ATl	Execute	Manufacturer: Model: Revision: OK

Table 19: ATl

Description:
Display Product Identification Information.

Example:

2.12.1 ATl: Execute Command

```
ATl

Manufacturer: Wurth Elektronik eiSos
Model: WIRL-CLTI-ADRASTEAI
Revision: ADRASTEAI_06.006

OK
```


2.13 AT&F0: Settings to Factory Default Values

Command	Command Type	Response
AT&F0	Execute	OK

Table 20: ATF0

Description:

TA sets all parameters to their defaults as specified by the manufacturer.

Example:

2.13.1 AT&F0: Execute Command

```
AT&F0
```

```
OK
```

2.14 ATV: Result Code Format Mode

Command	Command Type	Response
ATV[<value>]	Execute	OK

Table 21: ATV

Description:

DCE response format.

Defined values:

<value>: integer.

Value	Description
0	Displays result codes in numeric form.
1	Displays result codes in verbose form.

Table 22: ATV_Description

Example:

2.14.1 ATV: Execute Command

```
ATV0
OK
```

2.15 ATE: Echoes characters

Command	Command Type	Response
ATE[<value>]	Execute	OK

Table 23: ATVE

Description:

The setting of this parameter determines whether or not the DCE echoes characters received from the DTE during command state and online command state.

Defined values:

<value>: integer.

Value	Description
0	DCE does not echo characters during command state and online command state.
1	DCE echoes characters during command state and online command state.

Table 24: ATE_Description

2.16 AT&K: UART Flow control

Command	Command Type	Response
AT&K[<value>]	Execute	OK ERROR

Table 25: AT&K

Description:

This command is used for enable/disable UART flow control. Support only AT&K0 and AT&K3.

Defined values:

<value>: integer.

Value	Description
0	Disable flow control
3	Enable flow control

Table 26: ATK_Description

2.17 ATQ: Result Code Suppression

Command	Command Type	Response
ATQ=[<value>]	Execute	OK If value is 0 (none) If value is 1 (because result codes are suppressed). ERROR For unsupported values (if previous value was Q0). (none) For unsupported values (if previous value was Q1).

Table 27: ATQ

Description:

The setting of this parameter determines whether or not the DCE transmits result codes to the DTE. When result codes are being suppressed, no portion of any intermediate, final, or unsolicited result code header, result text, line terminator, or trailer is transmitted. Information text transmitted in response to commands is not affected by the setting of this parameter.

	V0	V1
Information Response	<text><cr><lf>	<cr><lf><text><cr><lf>
result Codes	<numeric code><cr>	<cr><lf><verbose code><cr><lf>

Table 28: ATK_Description

Defined values:

<value>: integer.

Value	Description
0	DCE transmits limited headers and trailers and numeric text.
3	DCE transmits full headers and trailers and verbose response text.

Table 29: ATQ_Value_Description

3 Network Service Related AT Commands

This chapter describes LTE network related commands.

3.1 +COPN: Read Operator Names

Command	Command Type	Response
AT+COPN	Execute	+COPN:<numeric1>,<alpha1> +COPN:<numeric2>,<alpha2> [...] or +CME ERROR: <err>
AT+COPN?	Read	ERROR
AT+COPN=?	Test	OK

Table 30: AT+COPN

Description:

Execute command returns the list of operator names from the MT. Each operator code <numericn> that has an alphanumeric equivalent <alphan> in the MT memory shall be returned.

Defined values:

<numeric_n>: string. Operator in numeric format (see +COPS).

<alpha_n>: string. Operator in string format (see +COPS).

Example:

3.1.1 +COPN: Execute Command

```
AT+COPN
```

```
.....
```

```
+COPN: "23003", "Vodafone_CZ"
```

```
+COPN: "23001", "T-Mobile_CZ"
```

```
+COPN: "23002", "O2_CZ"
```

```
+COPN: "26203", "o2_de"
```

```
+COPN: "26207", "o2_de"
```

```
+COPN: "26202", "Vodafone.de"
```

```
+COPN: "26201", "Telekom.de"
```

```
.....
```

```
OK
```

3.1.2 +COPN: Test Command

```
AT+COPN=?
```

```
OK
```

3.2 +COPS: PLMN Selection

Command	Command Type	Response
AT+COPS=[<mode>[,<format>[,<operator>[,<AcT>]]]]	Set	OK or +CME ERROR: <err>
AT+COPS?	Read	+COPS:<mode>[,<format>[,<operator>[,<AcT>]]]
AT+COPS=?	Test	+COPS: [<stat>,long alphanumeric <operator> name,short alphanumeric <operator> name,numeric <operator>[,<AcT>]]]

Table 31: AT+COPS

Description:

3.2.1 +COPS: Set Command

The +COPS command selects a PLMN automatically or manually, and reads and searches the current mobile network.

Set command forces an attempt to select and register the LTE network operator using the SIM/USIM card installed in the currently selected card slot.

<mode> is used to select whether the selection is done automatically or manually.



This command should be abortable when registration/deregistration attempt is made.

Syntax:

```
AT+COPS=[<mode>[,<format>[,<operator>[,<AcT>]]]]
```

Example:

The following command example selects the automatic network selection:

```
AT+COPS=0
```

```
OK
```

The following command manually selects network 26201:

```
AT+COPS=1,2,"26201"
```

```
OK
```

3.2.2 +COPS: Read Command

Read command returns the current mode, the currently selected operator and the current Access Technology. If no operator is selected, <format>, <oper> and <AcT> are omitted.

Syntax:

```
AT+COPS?
```

Response Syntax:

```
+COPS:<mode>[,<format>,<operator>[,<AcT>]]
```

Example:

3.2.3 +COPS: Read Command

```
AT+COPS?  
+COPS: 0,0,"Telekom.de",9
```

```
OK
```

3.2.4 +COPS: Test Command

Test command returns a set of five parameters, each representing an operator present in the network. Details of 5 parameters are as below:

1. A set consists of an integer indicating the availability of the operator <stat>.
2. long alphanumeric format of the name of the operator.
3. short alphanumeric format of the name of the operator.
4. numeric format representation of the operator.
5. Access technology.

Syntax:

AT+COPS=?

Response Syntax:

+COPS: [<stat>,long alphanumeric <operator>,short alphanumeric <operator>,numeric <operator>[,<AcT>]]

Example:

```
AT+COPS=?
+COPS: (1,"Telekom.de","TDG","26201",9),,(0-3),(0-2)

OK
```

Defined values:

<mode>: integer.

Value	Description
0	automatic (<operator> field is ignored).
1	manual (<operator> field shall be present, and <AcT> optionally).
2	deregister from network.
3	set only <format> (for read command +COPS?), do not attempt registration/deregistration (<oper> and <AcT> fields are ignored); this value is not applicable in read command response.

Table 32: +COPS_Mode_Description

<format>: integer.

Value	Description
0	long format alphanumeric <operator>.
1	short format alphanumeric <operator>.
2	numeric <oper>.

Table 33: +COPS_Format_Description

<operator>: string.

<format>:integer. Indicates if the format is alphanumeric or numeric.

Value	Description
0	long format alphanumeric <operator>
1	short format alphanumeric <operator>
2	numeric <operator>

Table 34: +COPS_Format_Description

<stat>: integer.

Value	Description
0	Unknown.
1	Available.
2	Current.
3	Forbidden.

Table 35: +COPS_Stat_Description

<Act>: integer. The parameter sets/shows the access technology selected.

Value	Description
0	GSM.
1	GSM Compact.
2	UTRAN.
3	GSM with EGPRS.
4	UTRAN with HSDPA.
5	UTRAN with HSUPA.
6	UTRAN with HSDPA and HSUPA.
7	E-UTRAN.
9	E-UTRAN (NB-S1 Mode).

Table 36: +COPS_Act_Description

3.3 +CSQ: Signal quality

Command	Command Type	Response
AT+CSQ	Execute	+CSQ: <rss>, <ber> OK
AT+CSQ?	Read	ERROR: <err>
AT+CSQ=?	Test	+CSQ: (0-31,99), (0-7,99) OK

Table 37: AT+CSQ

Description:

Execution command returns received signal strength indication <rss> and channel bit error rate <ber> from the MT.

Defined values:

<rss>: integer. Received signal strength indication.

Value	Description
0	-113 dBm or less
1	-111 dBm
2...30	-109 .. -53 dBm (Increase of 2dBm for each increasing value)
31	-51 dBm or greater
99	not known or not detectable

Table 38: +CSQ_rssi_Description

<ber>: Integer. Channel bit error rate (in percent).

Value	Description
0...7	as RXQUAL values in the table in 3GPP TS 45.008 Release-13 subclause 8.2.4
99	not known or not detectable

Table 39: +CSQ_Ber_Description

3.4 +CESQ: Extended Signal Quality

Command	Command Type	Response
AT+CESQ	Execute	+CESQ: <rxlev>,<ber>,<rscp>,<ecno>,<rsrq>,<rsrp> +CME ERROR: <err>
AT+CESQ=?	Test	+CESQ: (list of supported <rxlev>), ,(list of supported <ber>),(list of supported <rscp>),(list of supported <ecno>), (list of supported <rsrq>),(list of supported <rsrp>)

Table 40: AT+CESQ

Description:

Execution command returns received signal quality parameters. If the current serving cell is not a 2G cell, <rxlev> and <ber> are set to value 99. If the current serving cell is not a 3G FDD or 3G TDD cell, <rscp> is set to 255. If the current serving cell is not a UTRA FDD cell, <ecno> is set to 255. If the current serving cell is not an LTE cell, <rsrq> and <rsrp> are set to 255

Test command returns values supported as compound values.

Defined values:

- <rxlev>: integer. For LTE set to value 99 (not known or not detectable).
- <ber>: integer. For LTE set to value 99 (not known or not detectable).
- <rscp>: integer. For LTE set to 255 (not known or not detectable).
- <ecno>: integer. For LTE set to 255 (not known or not detectable).
- <rsrq>: integer. Reference signal received quality.

Value	Description
0	rsrq < -19.5 dB
1	-19.5 dB ≤ rsrq < -19 dB
2	-19 dB ≤ rsrq < -18.5 dB
...	...
32	-4 dB ≤ rsrq < -3.5 dB
33	-3.5 dB ≤ rsrq < 3 dB
34	-3 dB ≤ rsrq
255	not known or not detectable

Table 41: +CESQ_rsrq_Description

<rsrp>: integer. Reference signal received power.

Value	Description
0	$\text{rsrp} < -140 \text{ dBm}$
1	$-140 \text{ dBm} \leq \text{rsrp} < -139 \text{ dBm}$
2	$-139 \text{ dBm} \leq \text{rsrp} < -138 \text{ dBm}$
...	...
95	$-46 \text{ dBm} \leq \text{rsrp} < -45 \text{ dBm}$
96	$-45 \text{ dBm} \leq \text{rsrp} < -44 \text{ dBm}$
97	$-44 \text{ dBm} \leq \text{rsrp}$
255	not known or not detectable

Table 42: +CESQ_rsrp_Description

3.5 +CPSMS: Power Saving Mode Setting



For the Adrastea-I module to operate correctly in eDRX and PSM modes, these features must be enabled by the network operator. However, eDRX and PSM configurations can vary between operators, and some may not support these features. This variability can impact the power-saving capabilities of the Adrastea-I. For more details refer to Chapter "5 Functional description" in Adrastea-I manual [3]

Command	Command Type	Response
AT+CPSMS=[<mode>[, <Requested_Periodic-RAU>[, <Requested_GPRSREADYtimer>[, <Requested_Periodic-TAU>[, <Requested_Active-Time>]]]]]	Set	OK
AT+CPSMS?	Read	+CPSMS:<mode>,<Requested_Periodic-RAU>[, [<Requested_GPRS-READYtimer>], <Requested_Periodic-TAU>], [<Requested_Active-Time>]
AT+CPSMS=?	Test	+CPSMS:(list of supported <mode>s), (list of supported <Requested_Periodic-RAU>s), (list of supported <Requested_GPRS-READY-timer>s), (list of supported <Requested_Periodic-TAU>s), (list of supported <Requested_Active-Time>s)

Table 43: AT+CPSMS

Description:

The set command controls the setting of the UEs power saving mode (PSM) parameters. The command controls whether the UE wants to apply PSM or not, as well as the requested extended periodic TAU value in LTE and the requested Active Time value.

See the unsolicited result codes provided by commands +CEREG for the Active Time value and the extended periodic TAU value that are allocated to the UE by the network in E-UTRAN.

A special form of the command can be given as +CPSMS= (with all parameters omitted). In this form, the parameter <mode> will be set to 0, the use of PSM will be disabled and data for all parameters in command +CPSMS will be removed or, if available, set to the manufacturer specific default values.

The read command returns the current parameter values.

The test command returns the requested extended periodic TAU value in LTE and the requested Active Time value as compound values.

Defined values:

<mode>: integer.

Value	Description
0	Disable PSM.
1	Enable PSM.

Table 44: +CPSMS_Mode_Description

<Requested_Periodic-RAU>: string. Ignored for LTE.

<Requested_GPRS-READY-timer>: string. Ignored for LTE.

<Requested_Periodic-TAU>: string. One byte in an 8 bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in LTE. This parameter is Optional. When this parameter is omitted the default value, is manufacturer specific.

The requested extended periodic TAU value is coded as one byte coded as bit format (e.g. "01000111" equals 70 hours).

Bits 5 to 1 represent the binary coded timer value.

Bits 8 to 6 define the timer value unit as follows:

value	Description
0 0 0	value is incremented in multiples of 10 minutes.
0 0 1	value is incremented in multiples of 1 hour.
0 1 0	value is incremented in multiples of 10 hours.
0 1 1	value is incremented in multiples of 2 seconds.
1 0 0	value is incremented in multiples of 30 seconds.
1 0 1	value is incremented in multiples of 1 minute.
1 1 0	value is incremented in multiples of 320 hours.
1 1 1	value indicates that the timer is deactivated.

Table 45: CPSMS_T3412_Timer_value

<Requested_Active-Time>: string. One byte in an 8 bit format. Requested Active Time value (T3324) to be allocated to the UE. This parameter is Optional. When this parameter is omitted the default value, is manufacturer specific.

The requested Active Time value is coded as one byte coded as bit format (e.g. "00100100" equals 4 minutes).

Bits 5 to 1: Represent the binary coded timer value. Bits 6 to 8: Defines the timer value unit for the GPRS timer as follows:

value	Description
0 0 0	value is incremented in multiples of 2 seconds.
0 0 1	value is incremented in multiples of 1 minute.
0 1 0	value is incremented in multiples of decihours.
1 1 1	value indicates that the timer is deactivated.

Table 46: CPSMS_Active_Timer_value

Example:

Following command enables PSM and sets timer T3412 value to 60s and T3324 to 10s.

```
AT+CPSMS=1,,,"10100001","00000101"
```

```
OK
```

Following command disable PSM.

```
AT+CPSMS=0
```

```
OK
```

3.6 +CEDRXRDP: eDRX Read Dynamic Parameters

Command	Command Type	Response
AT+CEDRXRDP	Execute	+CEDRXRDP:<AcT-type> [,<Requested_eDRX_value> [,<NW-provided_eDRX_value> [,<Paging_time_window>]]]
AT+CEDRXRDP=?	Test	OK

Table 47: AT+CEDRXRDP

Description:

The execution command returns <AcT-type>, <Requested_eDRX_value>, <NW-provided_eDRX_value> and <Paging_time_window>.

If the cell that the MS is currently registered to is not using eDRX, AcT-type=0 is returned.

Defined values:

<AcT-type>: integer. Indicates the type of access technology. This is used to specify the relationship between the type of access technology and the requested eDRX value.

Value	Description
0	Access technology is not using eDRX
1	EC-GSM-IoT (A/Gb mode)
2	GSM (A/Gb mode)
3	UTRAN (Iu mode)
4	E-UTRAN (WB-S1 mode)
5	E-UTRAN (NB-S1 mode)

Table 48: +CEDRXRDP_Act_Type_Description

<Requested_eDRX_value>: string. Half a byte in a 4 bit format.

The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 Release-13).

<NW-provided_eDRX_value>:string. Half a byte in a 4 bit format.

The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 Release-13).

value	E-UTRAN eDRX cycle length duration
0 0 0 0	5.12 seconds (Refer to Note1)
0 0 0 1	10.24 seconds (Refer to Note1)
0 0 1 0	20.48 seconds
0 0 1 1	40.96 seconds
0 1 0 0	61.44 seconds (Refer to Note1)
0 1 0 1	81.92 seconds
0 1 1 0	102.4 seconds (Refer to Note1)
0 1 1 1	122.88 seconds (Refer to Note1)
1 0 0 0	143.36 seconds (Refer to Note1)
1 0 0 1	163.84 seconds
1 0 1 0	327.68 seconds
1 0 1 1	655,36 seconds
1 1 0 0	1310.72 seconds
1 1 0 1	2621.44 seconds
1 1 1 0	5242.88 seconds (Refer to Note2)
1 1 1 1	10485.76 seconds (Refer to Note)

Table 49: NW_Provided_eDRX_Value

Note1: The value is applicable only in WB-S1 mode. If received in NB-S1 mode it is interpreted as 0010 by this version of the protocol.

Note2: The value is applicable only in NB-S1 mode. If received in WB-S1 mode it is interpreted as 1101 by this version of the protocol.

<Paging_time_window>: string. Half a byte in a 4 bit format.

Below Table is applicable for LTE-M:

value	Paging Time Window length	Unit
0 0 0 0	1.28	seconds
0 0 0 1	2.56	seconds
0 0 1 0	3.84	seconds
0 0 1 1	5.12	seconds
0 1 0 0	6.4	seconds
0 1 0 1	7.68	seconds
0 1 1 0	8.96	seconds
0 1 1 1	10.24	seconds
1 0 0 0	11.52	seconds
1 0 0 1	12.8	seconds
1 0 1 0	14.08	seconds
1 0 1 1	15.36	seconds
1 1 0 0	16,64	seconds
1 1 0 1	17.92	seconds
1 1 1 0	19.20	seconds
1 1 1 1	20.48	seconds

Table 50: LTEM_PTW_Value

Below Table is applicable for NB-IoT:

value	Paging Time Window length	Unit
0 0 0 0	2.56	seconds
0 0 0 1	5.12	seconds
0 0 1 0	7.68	seconds
0 0 1 1	10.24	seconds
0 1 0 0	12.8	seconds
0 1 0 1	15.36	seconds
0 1 1 0	17.92	seconds
0 1 1 1	20.48	seconds
1 0 0 0	23.04	seconds
1 0 0 1	25.6	seconds
1 0 1 0	28.16	seconds
1 0 1 1	30.72	seconds
1 1 0 0	33.28	seconds
1 1 0 1	35.84	seconds
1 1 1 0	38.4	seconds
1 1 1 1	40.96	seconds

Table 51: NB-IoT_PTW_Value

3.7 +CEDRXS: eDRX Setting



For the Adrastea-I module to operate correctly in eDRX and PSM modes, these features must be enabled by the network operator. However, eDRX and PSM configurations can vary between operators, and some may not support these features. This variability can impact the power-saving capabilities of the Adrastea-I. For more details refer to Chapter "5 Functional description" in Adrastea-I manual [3].

Command	Command Type	Response
AT+CEDRXS=[<mode>[,<AcT-type>[,<Requested_eDRX_value>]]]	Set	OK
AT+CEDRXS?	Read	+CEDRXS:<AcT-type>,<Requested_eDRX_value>
AT+CEDRXS=?	Test	+CEDRXS: (list of supported <mode>), (list of supported <AcT-type>), (list of supported <Requested_eDRX_value>)

Table 52: AT+CEDRXS

Description:

The set command controls the setting of the UEs eDRX parameters. The command controls whether the UE wants to apply eDRX or not, as well as the requested eDRX value for each specified type of access technology.

The set command also controls the presentation of an unsolicited result code
+CEDRXP:<AcTtype>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]

A special form of the command can be given as +CEDRXS=3. In this form, eDRX will be disabled and data for all parameters in the command +CEDRXS will be removed or, if available, set to the manufacturer specific default values.

The read command returns the current settings for each defined value of <AcT-type>.

The test command returns the supported <mode> and the value ranges for the access technology and the requested eDRX value as compound values.

Defined values:

<mode>: integer. Indicates to disable or enable the use of eDRX in the UE.

Value	Description
0	Disable the use of eDRX
1	Enable the use of eDRX
2	Enable the use of eDRX and enable the unsolicited result code +CEDRXP:<AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]
3	Disable the use of eDRX and discard all parameters for eDRX or, if available, reset to the manufacturer specific default values.

Table 53: +CEDRXS_Act_Description

<AcT-type>: integer. Indicates the type of access technology.

Value	Description
0	Access technology is not using eDRX. This parameter value is only used in the unsolicited result code.
1	EC-GSM-IoT (A/Gb mode)
2	GSM (A/Gb mode)
3	UTRAN (Iu mode)
4	E-UTRAN (WB-S1 mode)
5	E-UTRAN (NB-S1 mode)

Table 54: +CEDRXS_Act_Type_Description

<Requested_eDRX_value>: string. Half a byte in a 4 bit format.

The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 Release-13).

value	E-UTRAN eDRX cycle length duration
0 0 0 0	5.12 seconds (Refer to Note1)
0 0 0 1	10.24 seconds (Refer to Note1)
0 0 1 0	20.48 seconds
0 0 1 1	40.96 seconds
0 1 0 0	61.44 seconds (Refer to Note1)
0 1 0 1	81.92 seconds
0 1 1 0	102.4 seconds (Refer to Note1)
0 1 1 1	122.88 seconds (Refer to Note1)
1 0 0 0	143.36 seconds (Refer to Note1)
1 0 0 1	163.84 seconds
1 0 1 0	327.68 seconds
1 0 1 1	655,36 seconds
1 1 0 0	1310.72 seconds
1 1 0 1	2621.44 seconds
1 1 1 0	5242.88 seconds (Refer to Note2)
1 1 1 1	10485.76 seconds (Refer to Note)

Table 55: Requested_eDRX_Value

Note1: The value is applicable only in WB-S1 mode. If received in NB-S1 mode it is interpreted as 0010 by this version of the protocol.

Note2: The value is applicable only in NB-S1 mode. If received in WB-S1 mode it is interpreted as 1101 by this version of the protocol.

<NW-provided_eDRX_value>: string. Half a byte in a 4 bit format.

The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 Release-13).

Refer to Table: 49

<Paging_time_window>: string type; half a byte in a 4 bit format;

For LTE-M Values refer to Table:50.

For NB-IoT Values refer to Table:51.

Example:

Following command enables eDRX and sets requested value to 20.48 seconds.

```
AT+CEDRXS=1,4,"0010"
```

```
OK
```

3.8 +CRCES: Reading Coverage Enhancement Status

Command	Command Type	Response
AT+CRCES	Execute	+CRCES: <AcT>,<CE_level>,<CC> OK
AT+CRCES?	Read	ERROR
AT+CRCES=?	Test	OK

Table 56: AT+CRCES

Description:

Read command returns the coverage enhancement status of the MT. The terminal can consider the coverage enhancement status prior to deciding to transmit data. Depending on the coverage enhancement status the terminal can refrain from transmitting data.

The coverage enhancement status is only provided by the MT if the access technology of the serving cell is EUTRAN, or E-UTRAN (NB-S1 mode). For all other access technology of the serving cell is different, <AcT>=0 is indicated.

Defined values:

<AcT>: integer. Access technology of the serving cell;

Value	Description
0	Serving cell has no coverage enhancement
1	E-UTRAN
2	EC-GSM-IoT (A/Gb mode)
3	E-UTRAN (NB-S1 mode) (see NOTE 1)

Table 57: +CRCES_Act_Description

NOTE 1:: 3GPP TS 36.331 Release-13 specifies the System Information blocks which give the information about whether the serving cell supports NB-IoT, which corresponds to E-UTRAN (NB-S1 mode).

<CE_level>:integer. Coverage Enhancement (CE) level of the MT in the serving cell. Applicable only if <AcT>=1 (E-UTRAN) or <AcT>=3 (E-UTRAN (NB-S1 mode)). Coverage Enhancement levels are defined and specified in 3GPP TS 36.331 Release-13.

Value	Description
0	No Coverage Enhancement in the serving cell
1	Coverage Enhancement level 0
2	Coverage Enhancement level 1
3	Coverage Enhancement level 2
4	Coverage Enhancement level 3

Table 58: +CRCES_CE_Level_Description

<CC>:integer. Coverage Class (CC) of the MT in the serving cell. For LTE it is set to 0.

Value	Description
0	No Coverage Class in the serving cell
1	Coverage Class 1
2	Coverage Class 2
3	Coverage Class 3
4	Coverage Class 4
5	Coverage Class 5

Table 59: +CRCES_CC_Description

3.9 +CSODCP: Sending of Originating data via the control plane

Command	Command Type	Response
AT+CSODCP=<cid>, <cpdata_length>,<cpdata> [,<RAI>[,<type_of_user_data>]]	Set	OK or ERROR
AT+CSODCP=?	Test	+CSODCP: (1),(1500),(0,1,2),(0,1) OK

Table 60: AT+CSODCP

Description:

The set command is used by the TE to transmit data over control plane to network via MT. Context identifier <cid> is used to link the data to particular context.

This command optionally indicates that the application on the MT expects that the exchange of data:

- Will be completed with this uplink data transfer.
or
- Will be completed with the next received downlink data.

This command also optionally indicates whether or not the data to be transmitted is an exception data.

This command causes transmission of an ESM DATA TRANSPORT message, as defined in 3GPP TS 24.301 Release-13.

Test command returns range of supported <cid>, the maximum number of bytes of user data indicated by <cpdata_length>, supported <RAI>s and supported <type_of_user_data>s as compound values.

Defined values:

<cid>: integer. A numeric parameter which specifies a particular EPS bearer context definition.

< cpdata_length>: integer. Indicates the number of octets of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero.

<cpdata>: string. Contains the user data container contents (refer 3GPP TS 24.301 Release-13 subclause 9.9.4.24). When there is no data to transmit, the <cpdata> shall be an empty string ("").

<RAI>: integer. Indicates the value of the release assistance indication, refer 3GPP TS 24.301 subclause 9.9.4.25 Release-13.

Value	Description
0	No information available
1	The MT expects that exchange of data will be completed with the transmission of the ESM DATA TRANSPORT message.
2	The MT expects that exchange of data will be completed with the receipt of an ESM DATA TRANSPORT message

Table 61: +CSODCP_RAI_Description

<type_of_user_data>:integer. Indicates whether the user data that is transmitted is regular or exceptional.

Value	Description
0	Regular data.
1	Exception data.

Table 62: +CSODCP_Type_of_data_Description

3.10 +CRTDCP: Reporting of terminating data via the control plane

Command	Command Type	Response
AT+CRTDCP=[<reporting>]	Set	OK or ERROR
AT+CRTDCP?	Read	+CRTDCP: <reporting>
AT+CRTDCP=?	Test	+CRTDCP: (list of supported <reporting>), (range of supported <cid>), (maximum number of octets of user data indicated by <cpdata_length>)

Table 63: AT+CRTDCP

Description:

The set command is used to enable and disable reporting of data from the network to the MT that is transmitted via the control plane in downlink direction. If reporting is enabled, the MT returns the unsolicited result code when data is received from the network.

+CRTDCP: <cid>,<cpdata_length>,<cpdata>

Read command returns the current settings.

Test command returns supported values as compound values.

Defined values:

<reporting>: integer. Controlling reporting of mobile terminated control plane data events.

Value	Description
0	Disable reporting of MT control plane data
1	Enable reporting of MT control plane data by the unsolicited result code +CRTDCP.

Table 64: +CRTDCP_Reporting_Description

<cid>:integer. A numeric parameter which specifies a particular EPS bearer context definition. The <cid> parameter is local to the TE-MT interface and identifies the PDP or EPS bearer contexts which have been setup via AT command (see the +CGDCONT and +CGDSCONT commands).

<cpdata_length>:integer. Indicates the number of octets of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero.

<cpdata>:string. Contains the user data container contents.

3.11 +CCIOTOPT: CloT optimization configuration

Command	Command Type	Response
AT+CCIOTOPT=[<n>, [<supported_UE_opt>[, <preferred_UE_opt>]]]	Execute	OK or ERROR
AT+CCIOTOPT?	Read	+CCIOTOPT:<n>,<supported_UE_opt>,<preferred_UE_opt> OK
AT+CCIOTOPT=?	Test	+CCIOTOPT: (list of supported <n>s),(list of supported <supported_UE_opt>s),(list of supported <preferred_UE_opt>s) OK

Table 65: AT+CCIOTOPT

Description:

The set command controls which CloT EPS optimizations the UE indicates as supported and preferred in the ATTACH REQUEST and TRACKING AREA UPDATE REQUEST messages. The command also allows reporting of the CloT EPS optimizations that are supported by the network. A UE supporting CloT functionality may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP Release-13 TS 24.301, subclause 9.9.3.34).

Based on the application characteristics the UE may prefer to be registered for control plane CloT EPS optimization or for user plane CloT EPS optimization (see 3GPP Release-13 TS 24.301, subclause 9.9.3.0B). Further the network may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP Release-13 TS 24.301, subclause 9.9.3.12A).

The set command is used also to control the unsolicited result code +CCIOTOPTI. An unsolicited result code +CCIOTOPTI:<supported_Network_opt> is used to indicate the supported CloT EPS optimizations by the network. The read command returns the current settings for supported and preferred CloT EPS optimizations and the current status of unsolicited result code +CCIOTOPTI. The test command returns values supported as compound values.



In CAT-M it is possible to enable or disable CP-CIoT optimization. while CP-IoT optimization is enabled, then it is possible set preferred UE optimization to none or CP-CIoT. In NB-IoT there is only possibility to enable CP-CIoT optimization and set it as preferred. No possibility to disable since it is mandatory in NB-S1-mode. UP-CIoT is not supported in both CAT-M and NB-IoT networks.

Defined values:

<n>: integer. Enables or disables reporting of unsolicited result code +CCIOTOPTI.

Value	Description
0	Disable reporting
1	Enable reporting
3	Disable reporting and reset the parameters for CloT EPS optimization to the default values.

Table 66: +CCIOTOPT_n_Description

<supported_UE_opt>: integer. Indicates the UE's support for CloT EPS optimization.

Value	Description
0,2,3	No Support
1	Support for control plane CloT EPS optimization.

Table 67: +CCIOTOPT_Supported_UE_OPT_Description

<preferred_UE_opt>: integer. Indicates the UE's preference for CloT EPS optimization.

Value	Description
0	No preference
1	Preference for control plane CloT EPS optimization.
2	Preference for user plane CloT EPS optimization. (No Support)

Table 68: +CCIOTOPT_Prefered_UE_OPT_Description

<supported_Network_opt>: integer. Indicates the Network support for CloT EPS optimization.

Value	Description
0,2,3	No Support
1	Support for control plane CloT EPS optimization.

Table 69: +CCIOTOPT_Supported_Network_OPT_Description

4 (U)SIM Related AT Commands

4.1 +CIMI: Request International Mobile Subscriber Identity

Command	Command Type	Response
AT+CIMI	Execute	<IMSI> OK
AT+CIMI?	Read	ERROR
AT+CIMI=?	Test	OK

Table 70: AT+CIMI

Description:

Execution command causes the TA to return <IMSI>, which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or USIM) which is attached to MT.

Defined values:

<imsi>: string (without double quotes). International Mobile Subscriber Identity.

Example:

4.1.1 AT+CIMI: Execute Command

```
AT+CIMI

001010123456063

OK
```

4.1.2 AT+CIMI: Read Command

```
AT+CIMI?

ERROR
```

4.1.3 AT+CIMI: Test Command

```
AT+CIMI=?

OK
```

4.2 +CLCK: Facility lock

Command	Command Type	Response
AT+CLCK=<fac>,<mode> [,<password>]	Set	+CME ERROR: <err> when <mode>=2 and command successful: +CLCK: <status>
AT+CLCK?	Read	ERROR
AT+CLCK=?	Test	+CLCK: ("SC","PN","PU","PS") OK

Table 71: AT+CLCK

Description:

Set command is used to lock, unlock or interrogate a MT or a network facility <fac>. Password is normally needed to do such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) will be returned only if service is not active for any <class>.

This command should be abortable when network facilities are set or interrogated.

Test command returns facility values supported as a compound value.

Defined values:

<fac>: string. facility.

Value	Description
"SC"	SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power up and when this lock command issued)
"PN"	Network Personalization
"PU"	Network subset Personalization
"PS"	PH SIM (lock PPhone to SIM/UICC card installed in the currently selected card slot)

Table 72: +CLCK_fac_Description

<mode>: integer.

Value	Description
0	Unlock
1	Lock
2	Query status

Table 73: +CLCK_Mode_Description

<password>: string.

<status>: integer.

Value	Description
0	Not Active
1	Active

Table 74: +CLCK_Status_Description

4.3 +CNUM: Subscriber number

Command	Command Type	Response
AT+CNUM	Execute	+CNUM:[<alpha1>],<number1>,<type1> [,<speed>,<service>[,<itc>]] [+CNUM:[<alpha2>], <number2>,<type2>[,<speed>,<service>[,<itc>]]][...]]
AT+CNUM?	Read	ERROR
AT+CNUM=?	Test	OK

Table 75: AT+CNUM

Description:

Execute command returns the MSISDNs related to the subscriber (this information can be stored in the SIM/UICC or in the MT). If subscriber has different MSISDN for different services, each MSISDN is returned on a separate line.

Defined values:

<alpha_n>:string. Optional alphanumeric string associated with <number_n>. used character set should be the one selected with command Select TE Character Set +CSCS.

<number_n>:string. Phone number of format specified by <type_n>.

<type_n>:integer. Type of address octet in integer format.

<speed>:integer. type as defined in (refer 3GPP TS 24.008 Release-13 subclause 6.7).

<service>:integer. Service related to the phone number.

Value	Description
0	asynchronous modem
1	synchronous modem
2	PAD Access (asynchronous)
3	Packet Access (synchronous)
4	Voice
5	fax

Table 76: +CNUM_Service_Description

all other values below 128 are reserved.

<itc>:integer. Indicates the type of access technology. This AT-command is used to specify the relationship between the type of access technology and the requested eDRX value.

Value	Description
0	3.1 kHz
1	UDI

Table 77: +CNUM_ITC_Description

4.4 +CPIN: Enter Pin

Command	Command Type	Response
AT+CPIN= <pin>[,<newpin>]	Set	OK or +CME ERROR: <err>
AT+CPIN?	Read	+CPIN: <code>
AT+CPIN=?	Test	OK

Table 78: AT+CPIN

Description:

The Set command sends to the MT a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH SIM PIN, etc.).

If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second pin, <newpin>, is used to replace the old pin in the SIM.

Read command returns an alphanumeric string indicating whether some password is required or not.

Defined values:

<pin>: string. PIN code.

<newpin>: string. New PIN code.

<code>: Values reserved by the present document.

Value	Description
READY	MT is not pending for any password
SIM PIN	MT is waiting SIM PIN to be given
SIM PUK	MT is waiting SIM PUK to be given
PH-SIM PIN	MT is waiting phone to SIM card password to be given
PH-FSIM PIN	MT is waiting phone-to-very first SIM card password to be given
PH-FSIM PUK	MT is waiting phone-to-very first SIM card unblocking password to be given
SIM PIN2	MT is waiting SIM PIN2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR: 17). If PIN2 is not entered right after the failure, it is recommended that MT does not block its operation)
SIM PUK2	MT is waiting SIM PUK2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR: 18). If PUK2 and new PIN2 are not entered right after the failure, it is recommended that MT does not block its operation)
PH-NET PIN	MT is waiting network personalization password to be given
PH-NET PUK	MT is waiting network personalization unblocking password to be given
PH-NETSUB PIN	MT is waiting network subset personalization password to be given
PH-NETSUB PUK	MT is waiting network subset personalization unblocking password to be given
PH-SP PIN	MT is waiting service provider personalization password to be given
PH-SP PUK	MT is waiting service provider personalization unblocking password to be given
PH-CORP PIN	MT is waiting corporate personalization password to be given
PH-CORP PUK	MT is waiting corporate personalization unblocking password to be given

Table 79: +CPIN_code_Description

Example:**4.4.1 AT+CPIN: Set Command**

Following command enters PIN 2615

```
AT+CPIN="2615"
OK
```

4.5 +CPWD: Change Password

Command	Command Type	Response
AT+CPWD=<fac>, <old password>[,<new password>]	Set	OK When inputs are wrong: ERROR or +CME ERROR:<err>
AT+CPWD?	Read	ERROR
AT+CPWD=?	Test	+CPWD:("SC",8),("P2",8),("PN",16),("PU",16), ("PS",16) OK

Table 80: AT+CPWD

Description:

Set command sets a new password for the facility lock function defined by the command Facility Lock +CLCK.

The test command returns a list of pairs which present the available facilities and the maximum length of their password.

Defined values:

<fac>: string. facility.

Value	Description
"SC"	SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power up and when this lock command issued)
"P2"	SIM PIN2
"PN"	Network Personalization.
"PU"	Network subset Personalization.
"PS"	PH SIM (lock PPhone to SIM/UICC card installed in the currently selected card slot)

Table 81: +CPWD_fac_Description

<old password>: string.

<new password>: string.

Example:

4.5.1 AT+CPWD: Set Command

Following command changes PIN from 2615 to 4321

```
AT+CPWD="SC","2615","4321"  
OK
```

4.6 +CRSM: Restricted SIM access

Command	Command Type	Response
AT+CRSM=<command>[,<fileid>[,<P1>,<P2>,<P3>[,<data>[,<pathid>]]]]	Set	+CRSM: <sw1>,<sw2>[,<response>]
AT+CRSM=?	Test	OK

Table 82: AT+CRSM

Description:

Set command transmits to the MT the SIM <command> and its required parameters. If a SIM installed in the currently selected card slot, the MT handles internally all SIM-MT interface locking and file selection routines. As response to the command, MT sends the actual SIM information parameters and response data. MT error result code +CME ERROR may be returned when the command cannot be passed to the SIM, but failure in the execution of the command in the SIM is reported in <sw1> and <sw2> parameters.

Coordination of command requests to SIM and the ones issued by GSM/UMTS application inside the MT is implementation dependent. However the TE should be aware of the precedence of the GSM/UMTS application commands to the TE commands.

Defined values:

<command>: integer.

Value	Description
176	READ BINARY
178	READ RECORD
192	GET RESPONSE
214	UPDATE BINARY
220	UPDATE RECORD
242	STATUS
203	RETRIEVE DATA
219	SET DATA

Table 83: +CRSM_command_Description

NOTE 1: The MT internally executes all commands necessary for selecting the desired file, before performing the actual command.

<fileid>:integer. This is the identifier of a elementary datafile on SIM. Mandatory for every command except STATUS.

NOTE 2: The range of valid file identifiers depends on the actual SIM and is defined in 3GPP TS 51.011. Optional files may not be present at all.

<P1>,<P2>,<P3>: integer. Parameters passed on by the MT to the SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. The values are described in 3GPP TS 51.011.

<data>: Information which shall be written to the SIM (hexadecimal character format, refer +CSCS 2.7).

<pathid>: string. Contains the path of an elementary file on the SIM/UICC in hexadecimal format (e.g. "7F205F70" in SIM and UICC case). The <pathid> shall only be used in the mode "select by path from MF".

NOTE 3: Since valid elementary file identifiers may not be unique over all valid dedicated file identifiers the <pathid>, indicates the targeted UICC/SIM directory path in case of ambiguous file identifiers.

<sw1>,<sw2>:integer. Information from the SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command.

<response>:Response of a successful completion of the command previously issued (hexadecimal character format; refer +CSCS 2.7). STATUS and GET RESPONSE return data, which gives information about the current elementary datafield. This information includes the type of file and its size. After READ BINARY, READ RECORD or RETRIEVE DATA command the requested data will be returned.

<response> is not returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command.

4.7 %CCID: Request ICCID

Command	Command Type	Response
AT%CCID	Execute	%CCID: <iccid> OK or ERROR
AT%CCID?	Read	ERROR
AT%CCID=?	Test	OK

Table 84: AT+CRSM

Description:

This execution command reads the ICCID (Card Identification Number) from the SIM's EFICCID. It is a unique identification number for the SIM. The ERROR is returned by an execution command if the SIM is not inserted.

Defined values:

<iccid>: integer string of 19 or 20 decimal digits, which reflects the SIM's ICCID value.

The ICCID format is: MMCC IINN NNNN NNNN NN C x

Value	Description
MM	Constant (ISO 7812 Major Industry Identifier)
CC	Country Code
II	Issuer Identifier
N12	Account ID (SIM number)
C	Checksum calculated from the other 19 digits using the Luhn algorithm
x	An extra 20th digit, which may be returned by SIM, but not officially part of the ICCID

Table 85: +CCID_iccid_Description

5 Adrastea-I Proprietary AT Commands

5.1 AT%CSQ: Signal quality

Command	Command Type	Response
AT%CSQ	Execute	%CSQ: <rsqi>,<ber>,<rsrq-signal quality> OK
AT%CSQ?	Read	ERROR
AT%CSQ=?	Test	%CSQ:(0-31,99),(0-7,99),(0-34,99) OK

Table 86: AT%CSQ

Description:

Execution command returns the:

- <rsqi> Received Signal Strength Indication.
- <ber> Channel bit error rate.
- <rsrq> signal quality

TB (Transport Blocks) error rate is used for the BER parameter

Read command is not supported

Test command returns the allowed values.

Defined values:

<rsqi>: integer.

Value	Description
0	-113 dBm or less
1	-111 dBm
2...30	-109... -53 dBm
31	-51 dBm or greater
99	Not known, or not detectable

Table 87: CSQ_RSSI_Description

<ber>: integer. Present in percent.

Value	Description
0...7	As RXQUAL values
99	Not known, or not detectable.

Table 88: CSQ_Ber_Description

<rsrq-signal-quality>: integer.

Value	Description
0	Less than -19.5 dB
1	-19.5 ... less than -19 dB
2	-19 ... less than -18.5 dB
34	-3 dB and greater
99	Not known, or not detectable

Table 89: CSQ_RSSQ_Description

5.1.1 AT%CSQ: Execute Command

Example:

```
AT%CSQ
%CSQ: 13,99,30

OK
```

5.1.2 AT%CSQ: Read Command

Example:

```
AT%CSQ?
ERROR
```

5.1.3 AT%CSQ: Test Command

Example:

```
AT%CSQ=?
%CSQ: (0-31,99),(0-7,99),(0-34,99)

OK
```

5.2 AT%CMATT: PS Attach or Detach

Command	Command Type	Response
AT%CMATT=<state>	Set	OK or +CME ERROR: <err>
AT%CMATT?	Read	%CMATT: <state>
AT%CMATT=?	Test	%CMATT: (0-1) OK

Table 90: AT%CMATT

Description:

This command is sent from the external Host which instructs the LTE module to detach or attach the LTE network.

Defined values:

<state>: integer.

Value	Description
0	Detach
1	Attach

Table 91: %CMATT_State_Description

5.2.1 AT%CMATT: Set Command

Example:

Following Command is used for Detach from the network.

```
AT%CMATT=0
OK
```

Following Command is used for Attach to the network.

```
AT%CMATT=1
OK
```

5.2.2 AT%CMATT: Read Command

Example:

```
AT%CMATT?
%CMATT: 1
```

```
OK
```

5.2.3 AT%CMATT: Test Command

Example:

```
AT%CMATT=?
%CMATT: (0–1)
```

```
OK
```

5.3 AT%CPININFO: Remaining Number of PIN and PUK attempts

Command	Command Type	Response
AT%CPININFO	Execute	%CPININFO: <PIN attempts left>, <PUK attempts left>, <PIN2 attempts left>, <PUK2 attempts left> OK
AT%CPININFO?	Read	ERROR
AT%CPININFO=?	Test	OK

Table 92: AT%CPININFO

Description:

This command returns the remaining number of PIN and PUK attempts.

Defined values:

<PIN attempts left>: integer. Number of failed attempts to enter PIN before it is blocked.

<PUK attempts left>: integer. Number of failed attempts to enter PUK before PUK is permanently blocked.

<PIN2 attempts left>: integer. Number of failed attempts to enter PIN2 before it is blocked.

<PUK2 attempts left>:integer. Number of failed attempts to enter PUK2 before PUK2 is permanently blocked.

Example:

5.3.1 AT%CPININFO: Execute Command

```
AT%CPININFO
%CPININFO: 3,10,3,10

OK
```

5.3.2 AT%CPININFO: Read Command

Example:

```
AT%CPININFO?
ERROR
```

5.3.3 AT%CPININFO: Test Command

Example:

```
AT%CPININFO=?
OK
```

5.4 AT%STATUS: Current Status of the Specified Device subsystem

Command	Command Type	Response
AT%STATUS= "<subsystem>"	Set	For all subsystems except of AMBR: %STATUS: <subsystem>: <status> [,<status_info>] OK
AT%STATUS?	Read	ERROR
AT%STATUS=?	Test	%STATUS: (list of supported <subsystem>)

Table 93: AT%STATUS

Description:

This execution command retrieves the current status of the specified UE subsystem. Read command is not supported.

Defined values:

<subsystem>: string.

Value
"INIT"
"USIM"
"RRC"
"SEC"
"ROAM"
"AMBR" (Not applicable for NB-IoT)
"IPS"
"CSPS"
"WDIS"
"UICC"
"TEMPM" (temperature monitor)
"DSIMA"
"PSM"
"EMM"
"ATT"
"BOOT"
"REGCMD"

Table 94: %STATUS_Sub_System_Description

For <subsystem> "INIT": This subsystem is used for RF Calibration progress, customer can

ignore it.

<status>, integer.

Value	Description
0	UE initial process ongoing (calibration in progress)
1	UE initial process has finished (calibration complete)
2	UE initial process has finished (calibration complete) but with critical errors. (SYS_CRITICAL)

Table 95: %STATUS_State_Description

For <subsystem> "USIM" :

<status>:

Status
USIM: REAL USIM, LTE
USIM: REAL USIM, non-LTE
USIM: USIM SIMULATOR
USIM: NO USIM
USIM: INACTIVE USIM - USIM is inactive (that is, deactivated), or it is still in the initialization process
USIM: PERSONALIZATION ERROR
USIM: REMOTE USIM
USIM: PERMANENT LOCK ERROR

Table 96: %STATUS_USIM_State_Description

For <subsystem> "IPS" :

<status>:

Value	Description
0	UE IP stack works correctly
1	UE IP stack failure

Table 97: %STATUS_IPS_State_Description

For <subsystem> "AMBR" :

<status>:

Status
EPS bearer id
APN-AMBR downlink
APN-AMBR uplink
No APN-AMBR is defined

Table 98: %STATUS_AMBR_State_Description

For <subsystem> "RRC" :

<status>:

Status
RRC: IDLE
RRC: CONNECTED
RRC: UNKNOWN: Used for all other states (init, standby, flight mode, etc.)

Table 99: %STATUS_RRC_State_Description

For <subsystem> "SEC" :

<status>:

Value	Description
0	No authentication request sent yet
1	Authentication success, stored context
2	Authentication success, new context
3	Authentication failure, MAC failure
4	Authentication failure, Synch failure
5	Authentication failure, non-EPS authentication unacceptable
6	Authentication failure, error unspecified
7	Authentication Reject

Table 100: %STATUS_SEC_State_Description

For <subsystem> "ROAM" :

<status>:

Value	Description
0	Not roaming (UE is not camped at all or UE is camped on HPLMN/EHPLMN)
1	UE is camped on VPLMN

Table 101: %STATUS_ROAM_State_Description

For <subsystem> "CSPS" :
<status>:

Value	Description
0	not registered or EPS_ONLY (PS) mode
1	EPS_COMBINED (CS/PS) mode

Table 102: %STATUS_CSPS_State_Description

For <subsystem> "WDIS" :
<status>:

Value	Description
0	enable signal detected
1	disable signal detected

Table 103: %STATUS_WDIS_State_Description

For <subsystem> "UICC" :
<status>:

Value	Description
0	SIM is not inserted
1	SIM inserted, init is in progress
2	SIM init passed, waiting for PIN unlock
3	Personalization failed, waiting for run-time depersonalization
4	Activation completed. Reported when "Ready" state is reported by "AT+CPIN?"
5	Activation completed. RAM cache also ready except for conditional caches of ISIM files (for IMS)

Table 104: %STATUS_UICC_State_Description

For <subsystem> "TEMPM" :
<status>:

Value	Description
0	Normal UE operation
1	Heating protection applied

Table 105: %STATUS_TEMPM_State_Description

For <subsystem> "DSIMA" :
<status>:

Value	Description
0	SIM not selected
1	SIM1 selected
2	SIM2 selected

Table 106: %STATUS_DSIMA_State_Description

For <subsystem> "PSM" :**<status>:**

Value	Description
0	PSM is not active
1	PSM is active

Table 107: %STATUS_PSM_State_Description

For <subsystem> "EMM" :**<status>:**

Value	Description
1	EMM_NULL
2	EMM_DEREGISTERED_NORMAL_SERVICE
3	EMM_DEREGISTERED_ATTEMPTING_TO_ATTACH
4	EMM_DEREGISTERED_PLMN_SEARCH
5	EMM_DEREGISTERED_NO_IMSI
6	EMM_DEREGISTERED_ATTACH_NEEDED
7	EMM_DEREGISTERED_NO_CELL_AVAILABLE
8	EMM_DEREGISTERED_ATTACH_ACCEPT_RECEIVED
9	EMM_DEREGISTERED_REGISTRATION_INITIATED
10	EMM_DEREGISTERED_LIMITED_SERVICE
11	EMM_REGISTERED_LIMITED_SERVICE
12	EMM_REGISTERED_NORMAL_SERVICE
13	EMM_REGISTERED_ATTEMPTING_TO_UPDATE
14	EMM_REGISTERED_PLMN_SEARCH
15	EMM_REGISTERED_UPDATE_NEEDED
16	EMM_REGISTERED_NO_CELL_AVAILABLE
17	EMM_REGISTERED_ATTEMPTING_TO_UPDATE_MM
18	EMM_REGISTERED_IMSI_DETACH_INITIATED
19	EMM_REGISTERED_NO_CELL_AVAILABLE_PSM_ACTIVE
20	EMM_REGISTERED_DEREGISTRATION_INITIATED
21	EMM_REGISTERED_TRACKING_AREA_UPDATING_INITIATED
22	EMM_REGISTERED_SERVICE_REQUEST_INITIATED

Table 108: %STATUS_EMM_State_Description

<status_info>, for "ATT" :

Value	Description
0	Detached
1	Normal Attach
2	Attach without PDN
3	Emergency Attach

Table 109: %STATUS_ATT_Status_Info_Description

<status_info>, for "BOOT":

Value	Description
0	Full Power on wakeup
1	sleep mode wakeup

Table 110: %STATUS_BOOT_Status_Info_Description

< status_info>, for "REGCMD" :

Value	Description
0	No Registration commanded
1	Registration commanded

Table 111: %STATUS_REGCMD_Status_Info_Description

Example:

5.4.1 AT%STATUS: Execute Command

Following Command shows the state of RRC.

```
AT%STATUS="RRC"
RRC: IDLE

OK
```

Following Command shows the state of EMM.

```
AT%STATUS="EMM"
EMM: 12

OK
```

5.4.2 AT%STATUS: Read Command

Example:

```
AT%STATUS?
ERROR
```

5.4.3 AT%STATUS: Test Command

Example:

```
AT%STATUS=?
%STATUS: ("INIT", "USIM", "IPS", "AMBR", "RRC", "PSM", "SEC", "ROAM", "CSPS", "
WDIS", "UICC", "DSIMA", "TEMPM", "EMM", "ATT", "BOOT")
OK
```

5.5 AT%RATACT: Switch to Selected RAT without full reboot

Command	Command Type	Response
AT%RATACT= <rat>[,<storage> [,<source>]]	Set	OK or ERROR
AT%RATACT?	Read	%RATACT: <rat>,<rat_mode>,<source>
AT%RATACT=?	Test	%RATACT: (list of supported <rat>s),(list of supported <storage>s)

Table 112: AT%RATACT

Description:

Execution command switches to selected RAT without full reboot. Any attempt to switch to the RAT already in use will be silently ignored and return OK.

If multiple mode is enabled in configuration file, the call of this AT with <rat>="DEFAULT" returns device to RAT automatic selection mode.



Note : The default mode for module is CAT-M1 single mode.

Defined values:

<rat>: string. RAT to be activated by execution command or currently used RAT for read command.

Value	Description
"DEFAULT"	Activate Default RAT/configured mode
"CATM"	Activate CAT-M RAT
"NB-IOT"	Activate NB-IOT RAT
"C2D"	Not support
"N2D"	Not support
"GSM"	Not support
"G2D"	Not support

Table 113: %RATACT_RAT_Description

<storage>: integer. Flag indicates if settings are persistent over a power-cycle (stored into non-volatile memory).

Value	Description
0	Not Persistent (default if parameter omitted)
1	Persistent

Table 114: %RATACT_Storage_Description

<source>: integer. Flag used for RAT switch requests arbitration.

Value	Description
0	None/Clear
1	Host (default)

Table 115: %RATACT_Source_Description

<rat_mode>: integer. RAT mode of RM state machine.

Value	Description
0	Single RAT
1	Multiple RAT

Table 116: %RATACT_RAT_Mode_Description

Example:

5.5.1 AT%RATACT: Set Command

Following AT command will change module mode to NB-IoT.

```
AT%RATACT="NB-IoT",1  
OK
```

Following AT command will change module mode to LTE-Cat.M.

```
AT%RATACT="CATM",1  
OK
```

5.5.2 AT%RATACT: Read Command

Example:

```
AT%RATACT?  
%RATACT: "NB-IoT",1,0  
OK
```

5.5.3 AT%RATACT: Test Command

Example:

```
AT%RATACT=?  
%RATACT: ("DEFAULT","CATM","NB-IoT","G2D","N2D"),(0-1),(0-2)  
OK
```

5.6 AT%MEAS: Measurement for Serving Cell

Command	Command Type	Response
AT%MEAS= "<measurement_type>"	Set	<p>For RS_SINR: %MEAS: RS_SINR=<measurement value></p> <p>For Power Headroom: %MEAS: PHR=<measurement value>, PHR Level=<measurement value></p> <p>For Srxlev: %MEAS: SRXLEV=<measurement value></p> <p>For all NBS RSRP, RSRQ and RSSI: %MEAS: EARFCN=<EARFCN>,CellID=<cell ID>,<measurement_type>=<measurementvalue> [%MEAS: EARFCN=<EARFCN>,CellID=<cell ID>,<measurement type>=<measurement value>] [...]</p> <p>For all neighboring NBS simultaneous RSRP and RSRQ reporting: %MEAS:EARFCN=<EARFCN>,CellID=<cellID>, RSRP=<measurement value>, RSRQ=<measurement value> [%MEAS:EARFCN=<EARFCN>,CellID=<cellID>,<RSRP>=<measurement value>, RSRQ=<measurement value>] [...]</p> <p>For NBS RSRP in compressed format: %MEAS:NBS RSRP:<EARFCN>,<cell ID>,<measurement value>[,<EARFCN>,<cellID>,<measurement value>[...]]</p> <p>For E-CID (AT%MEAS="95") in compressed format: %MEAS:ECID:<gcid>,<TimeDifIndex>,<ta>,<MCC>,<MNC>,<TAC>,<EARFCN>,<cellID>,<SFN>,<RSRP>,<RSRQ> [,<EARFCN>,<cell ID>,<SFN>,<RSRP>,<RSRQ> [...]]</p> <p>The Network Time corresponding to the SFN of the serving cell (AT%MEAS="93") in compressed format: %MEAS:NWTIME:<networkTTI>,<networkUtcTime></p>
AT%MEAS?	Read	ERROR
AT%MEAS=?	Test	%MEAS: <list of supported measurements>

Table 117: AT%MEAS

Description:

The averaged narrow-band measurement executed for serving eNB as defined in the spec for the RSRP and RSRQ "Reported" measurement value.



Note: The SINR is not reported over-the-air. It is "reported" value contains the combined value of all antennas measurements.

Signal Quality measurement type (8) simultaneously returns the last serving cell measurements of RSRP, RSRQ, SINR, and RSSI. This AT command is response contains only the "reported" values.

The per antenna measurement value R_{XyTXz} (y,z=0/1) is the result of last non-averaged wide-band measurement used for debugging purposes. This applies for RSRP only.

Only the single "reported" value is supported for neighbor eNB measurements.

Antenna relative phase measurement type (9) returns the relative phase between the UE RX antennas for each eNB TX antenna. This command also returns the related RSSI measurement as per the UE RX antennas.

Read command is not supported.

Defined values:

<measurement type>: string.

Value	Description
"0"	RSRP
"1"	RSRQ
"2"	SINR
"3"	RSSI
"4"	TX Power - Not applicable for NB-IoT in RRC IDLE mode
"5"	Temperature
"6"	Pathloss
"7"	CQI - Not applicable for NB-IoT
"8"	Signal Quality (RSRP & RSRQ & SINR & RSSI)
"9"	Antenna relative phase (Not applicable for NB-IoT)
"10"	RSRP reported value only
"11"	RSRQ reported value only
"12"	SINR reported value only
"13"	RS_SNR (reference signal Signal-to-Noise Ratio).
"14"	RS_SINR (reference signal Signal-to-Interference-plus-Noise Ratio)
"15"	Power Headroom - Only supported for NB-IoT
"16"	Srxlev as defined in 3GPP 36.304
"17..."	Upto "92" Reserved
"93"	Network Time alignment with SFN
"95"	Measurements for E-CID
"96"	RSRP for all detected NBSs (same as 98) in compressed format: In single line Each eNB measurement data (<EARFCN>,<cell ID>,<measurement value>) is separated by additional space
"97"	RSRP and RSRQ for all detected NBS
"98"	RSRP for all detected NBS
"99"	RSRQ for all detected NBS
"100"	RSSI for all detected NBS

Table 118: %MEAS_Measurement_Type_Description

<EARFCN>: integer. Decimal EARFC value.

<gcid>: integer. The Global cell ID hexadecimal value.

<TimeDiffIndex>: RxTxTimeDiff decimal index (as defined in 9.1.9.2 of 3GPP 36.133 Release-13) of the measured cell. The value shall be reported by the MAC based on the RxTxTimeDiff

reported by the PHY. Be aware that the RxTxTimeDiff used by the PHY is different from the value received by the MAC CE, and has a better Ts granularity and accuracy.

<ta>: integer. Currently used Timing Advance value (NTA) of the measured cell. The NTA value is represented by index values of TA = 0, 1, 2, ..., 1282, where the amount of the time alignment is given by NTA = TA 16 per [3GPP 36.213].

<mcc>: integer. A three-digit value indicating the mobile country code as defined in ITU-T

<mnc>: integer. A three-digit or two-digit value indicating the mobile network code as defined in ITU-T.

<TAC>: hexadecimal. Two byte tracking area code in hexadecimal format.

<SFN>: integer. The decimal system frame number (SFN) of the measured cell during which the measurement has been performed. Since there is averaging over multiple SFNs, it is advised to supply the latest SFN. If this value is not available at the time of the query, the command returns N/A (without quotes).

<cell ID>: integer. Decimal Physical Cell ID value<measurement value>

<measurement value>: integer. The measurement results are returned in native for each measurement unit:

- dBm: For RSRP, RSSI
- dB : For RSRQ, SINR, Pathloss
- 0.1 dBm for TX Power (for example, 2.5 dBm = 25)
- Degrees (°C) for Temperature
- Degrees (phase) & 256*dBm (RSSI) units for Antenna relative phase
- 0.1 dB for RS_SNR, RS_SINR, PHR (for example, 2.5 dB = 25)

Measurement Range:

- -140 <= RSRP <= 0
- -60 <= RSRQ <=0
- -128 <= SINR <= 40
- -26 <= TX Power <= 40
- -128 <= Temperature <= 128
- 0 <= CQI <= 15

- $-12.0 \leq \text{RS_SNR}, \text{RS_SINR} \leq 40.0$
- $-23.0 \leq \text{PHR} \leq 40.0$

If the RSRP/RSRQ measurement value for an antenna is not supported, the command returns "N/S" (Not Supported) indication for this specific antenna in the returned string.



Note: The reported range is wider than the range defined for Measurement Reporting in 3GPP spec. It is intended to report weak and abnormal measurements, especially for neighboring cells, for jamming detection.

<networkTTI>: integer. The subframe counter of the serving cell corresponds to the network UTC time. The subframe counter is a decimal running from 0 to 10239 (that is, rollover at 10240) also known as the TTI (Transmission Time Interval) counter.

<networkUtcTime>: integer. This field specifies the network UTC time which corresponds to the specified TTI counter. The UTC time is a decimal counter in 1 msec units counted since 00:00:00 on 1 January, 1900.

5.6.1 AT%MEAS: Set Command

Following AT command will show the RSRP Measurement.

```
AT%MEAS="0"  
%MEAS: RSRP: Reported = -96, Rx0Tx0 = -96, Rx0Tx1 = -116  
  
OK
```

Following AT command will show the RSRQ Measurement.

```
AT%MEAS="1"  
%MEAS: RSRQ: Reported = -9, Rx0Tx0 = -9, Rx0Tx1 = -30  
  
OK
```

Following AT command will show the Srxlev Measurement.

```
AT%MEAS="16"  
%MEAS: SRXLEV=43  
  
OK
```

5.6.2 AT%MEAS: Read Command

Example:

```
AT%MEAS?
ERROR
```

5.6.3 AT%MEAS: Test Command

Example:

```
AT%MEAS=?
%MEAS: 0-RSRP, 1-RSRQ, 2-SINR, 3-RSSI, 4-TXPOWER, 5-TEMPERATURE,
        6-Pathloss, 7-CQI, 8-Signal Quality, 9-Antenna relative phase, 10-RSRP reported
        value only, 11-RSRQ reported value only, 12-SINR reported value only, 13-
        RS_SNR, 14-RS_SINR, 15-Power Headroom, 93-Network Time alignment with
        SFN, 95-Measurements for E-CID, 96-RSRP for all detected NBS, 97-RSRP &
        RSRQ for all detected NBS, 98-RSRP for all detected NBS, 99-RSRQ for all
        detected NBS, 100-RSSI for all detected NBS

OK
```

5.7 AT%NWOPER: Set/Query NW Operator Mode of the Modem.

Command	Command Type	Response
AT%NWOPER= <oper_name>	Set	OK or ERROR
AT%NWOPER?	Read	%NWOPER: <oper_name>[,<mode>]
AT%NWOPER=?	Test	%NWOPER: (list of supported <oper_name>)

Table 119: AT%NWOPER

Description:

This command is used to set/query NW operator mode of the modem. This mode setting is used to support NW Operator specific requirements defined on top of 3GPP requirements. The <oper_name>="DEFAULT" means default 3GPP compliant behavior of the modem.

The list of operators is not limited, use test command (AT%NWOPER=?) to retrieve the list of currently supported operators. Any attempt to set unknown operator name will return ERROR.

Read command separates operator name and operator selection mode:

- <oper_name> - current NW Operator settled or selected by MCC-MNC of IMSI if "AUTO" mode was commanded
- <mode> - indicates that "AUTO" mode is currently configured

Defined values:

<oper_name>: string. The name of operator to select modem mode of operations. The name is Altair-proprietary string.

Value	Description
"DEFAULT"	Default 3GPP compliant mode
"AUTO"	NW Operator mode is selected in accordance with IMSI value of currently used SIM
"VZW"	Verizon Wireless
"ATT"	AT&T

Table 120: %NWOPER_Oper_Name_Description

Example:**5.7.1 AT%NWOPER: Set Command**

Following command will set uBoot delay to 10 seconds.

```
AT%NWOPER="T-MOBILE"
OK
```

5.7.2 AT%NWOPER: Read Command**Example:**

```
AT%NWOPER?
%NWOPER: "DEFAULT","AUTO"

OK
```

5.7.3 AT%NWOPER: Test Command**Example:**

```
AT%NWOPER=?
%NWOPER: ("AUTO","DEFAULT","VZW","CMCC","RJIL","KDDI","ATT","USCC","
          DOCOMO","SOFTBANK","LGU+","KT","T-MOBILE","SKT","CTC","VODAFONE",
          TELSTRA","TRUPHONE","CHT")
```

OK

5.8 AT%PDNSET: Set run-time PDN Parameters For Data PDNs

Command	Command Type	Response
AT%PDNSET= <ext_sessionID>, <apnname>,<ip_type>, <ppp_auth>,<user>, <passwd>,<host_name>, <IPv4AddrAlloc>, <pcscf_discovery>,<NSLPI>	Set	OK or ERROR
AT%PDNSET?	Read	%PDNSET:<ext_sessionID>,<apnname>, <ip_type>,<ppp_auth>,<user>,<passwd> ,<host_name>,<IPv4AddrAlloc>, <pcscf_discovery>,<NSLPI> %PDNSET:<ext_sessionID>,<apnname>, <ip_type>,<ppp_auth>,<user>,<passwd>, <host_name>,<IPv4AddrAlloc>, <pcscf_discovery>,<NSLPI>
AT%PDNSET=?	Test	OK

Table 121: AT%PDNSET

Description:

The command is intended to set run-time PDN parameters for data PDNs exposed to host.

In addition, the APN name and IP type provided in the command will override default PDN settings from embedded APN table stored into UE NV. The PPP security parameters are run-time only and are not stored into non-volatile memory.

The command will be effective immediately, which means that if parameters are different from those already in use, the PDN will be deactivated, updated locally and on server (via LTE messages) and then reactivated.

Missed PPP security parameters remove previous PPP security setting completely.

Command is intended to substitute previous %PPPAUTH command, which is not synced with other PDN parameters definition.



Note:

In both command and response, a parameter which is not specified will be written as ","
Last parameters of the command which are not specified may not include the "," notation.

Defined values:

<ext_sessionID>: integer. The numeric value of the session identifier which is configured and used by an external application, or by the host, and defined in the NP config file.

<apnname>: string. Indicates the APN name configured for PDN.

<ip_type>: string. Specifies the type of packet data protocol.

Value	Description
"IP"	Internet Protocol
"IPv6"	Internet Protocol, version 6
"IPv4V6"	Virtual <PDP_type> introduced to handle dual IP stack UE capability.

Table 122: %PDNSET_IP_TYPE_Description

<ppp_auth>: string. PPP authentication type.

- "NONE"
- "PAP"
- "CHAP"

<user>: string. Username used for authentication.

<passw>: string. Password used for authentication.

<host_name>: string. Optional, The name of the Authentication server.

<pcscf_discovery>: integer. Decimal value.

Value	Description
0	Disable
1	Enable

Table 123: %PDNSET_pcscf_discovery_Description

<IPv4AddrAlloc>: integer. Controls how the host requests the IPv4 address information (same as defined in AT+CGDCONT)

Value	Description
0	IPv4 address allocation through NAS signaling
1	IPv4 address allocated through DHCP

Table 124: %PDNSET_IPv4AddrAlloc_discovery_Description

<NSLPI>: integer. Indicates the NAS signaling priority requested for this PDP context as defined in AT+CGDCONT.

Value	Description
0	indicates that this PDP context is to be activated with the value for the low priority indicator configured.
1	indicates that this PDP context is is to be activated with the value for the low priority indicator set to "MS is not configured for NAS signalling low priority".

Table 125: %PDNSET_NSLPI_discovery_Description

Example:**5.8.1 AT%PDNSET: Set Command**

Following command will set for <ext_sessionID=1>, <apnname> to "apnexample" and <ip_type> to "IPV4V6".

```
AT%PDNSET=1,"apnexample","IPV4V6"
OK
```

Following command will remove APN setting for <ext_sessionID=1>.

```
AT%PDNSET=1,"null","IPV4V6"
OK
```

5.8.2 AT%PDNSET: Read Command**Example:**

```
AT%PDNSET?
%PDNSET: 1,apn.MNC.MCC.GPRS,IPV4V6,,,,,0,0,0
OK
```

5.8.3 AT%PDNSET: Test Command**Example:**

```
AT%PDNSET=?
%PDNSET: <ext_session_id>,<apnname>,<ip_type>,<ppp_auth>,<user>,<passw>,<
auth_host>,<IPv4AddrAlloc>,<pcscf_discovery>,<NSLPI>
OK
```

5.9 AT%SETBDELAY: Modifies the uBoot delay

Command	Command Type	Response
AT%SETBDELAY= <tout>	Set	OK or ERROR
AT%SETBDELAY?	Read	%SETBDELAY: <tout>
AT%SETBDELAY=?	Test	OK

Table 126: AT%SETBDELAY

Description:

The command is intended for debug purposes. It modifies the uBoot delay applied in next cold boot. Once modified, new timeout value will be used as new default timeout in all following cold boots. Read command is not supported

Defined values:

<tout>: integer. Delay timeout value in sec 0-99 sec.

Example:

5.9.1 AT%SETBDELAY: Set Command

Following command will set uBoot delay to 10 seconds.

```
AT%SETBDELAY=10
OK
```

5.9.2 AT%SETBDELAY: Read Command

```
AT%SETBDELAY?
%SETBDELAY: 0
OK
```

5.9.3 AT%SETBDELAY: Test Command

```
AT%SETBDELAY=?
OK
```

5.10 AT%SCAN: Return the RSSI Scan Results

Command	Command Type	Response
AT%SCAN= [<cmd>[,<mode>]]	Set	For <cmd>="QUERY" For <mode>=0 (short) or omitted %SCAN:<res>[,<EARFCN>,<PCI>,<RSRP>,<RSRQ>[,<EARFCN>,<PCI>,<RSRP>,<RSRQ>]...] For <mode>=1 (long) %SCAN:<res>[,<band>,<earfcn>,<pci>,<eci>,<mcc>,<mnc>,<RSRP>,<RSRQ>[,<eci>,<mcc>,<mnc>,<bw>,<tac>,<cstat>,<emg>,<oper1> [,<oper2>[...]]] [%SCAN:<band>,<earfcn>,<pci>,<eci>,<mcc>,<mnc>,<RSRP>,<RSRQ>[,<eci>,<mcc>,<mnc>,<bw>,<tac>,<cstat>,<emg>,<oper1> [,<oper2>[...]]]...] OK
AT%SCAN?	Read	%SCAN: for each cell: (<bw>, <eci>, <EARFCN>, <Physical_cell_ID>, <PLMN_ID>, <RSRP>)
AT%SCAN=?	Test	OK

Table 127: AT%SCAN

Description:

This command returns the RSSI scan results. These results are displayed only for successfully acquired SIB1 cells.

Execute and Test commands are not supported.

Defined values:

<cmd>: string. Command.

Value	Description
"QUERY"	Ask for last scan results

Table 128: %SCAN_Cmd_Description

<mode>: integer. Result representation mode.

Value	Description
0	Short format
1	Long format

Table 129: %SCAN_Mode_Description

<bw>: integer. Bandwidth configuration.

Value	Description
0	1.4 MHz (Not support in NB-IOT)
1	3 MHz (Not support in NB-IOT)
2	5 MHz (Not support in NB-IOT)
3	10 MHz (Not support in NB-IOT)
4	15 MHz (Not support in NB-IOT)
5	20 MHz (Not support in NB-IOT)

Table 130: %SCAN_BW_Description

<eci>: integer. As per 3GPP encoding for cell ID.

<EARFCN>:integer. As per 3GPP encoding for EARFCN.

<Physical cel l ID> or <PCI>: integer. PHY acquired cell ID.

<PLMN ID>. integer. As per 3GPP encoding for PLMN ID.

<RSRP>: RSRP measurements in dBm.

<res>: integer. scan result.

Value	Description
0	Scan succeeded. Cell measurements will also be provided
1	Scan failed: Low power, no cell found
2	Scan failed: Cell(s) found, but failed to acquire MIB/SIB1. Cell measurements will also be provided.

Table 131: %SCAN_Res_Description

Next params are as per 3GPP definition:

<band>,<earfcn>,<pci>,<eci>,<mcc>,<mnc>,<RSRP>,<RSRQ>,<bw>,<tac>

<operN>: string. Similar to <operator> parameter of +COPS in decimal numeric format.

Example:

5.10.1 AT%SCAN: Set Command

Following command will show RSSI scan results in Short format mode.

```
AT%SCAN="QUERY",0
%SCAN: 0,3740,350,-93,-7
```

```
OK
```


5.10.2 AT%SCAN: Read Command

```
AT%SCAN?  
Cell #1  
DL BandWidth = 6  
Global Cell ID = 01CD6007  
DL EARFCN = 3740  
Physical Cell ID = 350  
PLMN ID = 26201  
RSRP = -77
```

```
OK
```

5.10.3 AT%SCAN: Test Command

```
AT%SCAN=?  
OK
```

5.11 AT%SCANCFG: Configure changes in regular scan procedure for manual scan

Command	Command Type	Response
AT%SCANCFG=<rs_cfg>[,<sl_cfg>[,<estart>,<estop>,<estep>[,<estart>,<estop>,<estep>]]...]	Set	OK ERROR
AT%SCANCFG?	Read	ERROR (not supported)
AT%SCANCFG=?	Test	OK

Table 132: AT%SCANCFG

Description:

The command is intended to configure changes in regular scan procedure for following user-triggered scan.

The Rich Scan is a scan, which provides not only strongest cell on each mandated frequency, but also all intra cells, which can be acquired on same EARFCN.

The Run-time Scan List (RTSL) is intended to create Scan List or substitute MDOP Scan List.

If user is aware about deployment, the scanning time may be essentially reduced by band boundaries reduction or even by individual band definition.

The RTSL defines a list of EARFCN ranges, where each EARFCN range boundaries are defined within the same band.

The RTSL can contain a number of entries (up to 64 on ALT125x). To define individual EARFCN it is enough to set <estart>=<estop>.

The EARFCN ranges of RTSL should be a subset of bands defined in BSP (MDOP) file and used for device calibration at wakeup time.

Next configurations may be configured for user-triggered scan procedure:

- Regular scan over regular MDOP scan settings (default)
- Regular scan over run-time scan list (RTSL)
- Rich scan over regular MDOP scan settings
- Rich scan over run-time scan list (RTSL)

Read command is not supported.

Defined values:

<rs_cfg>: integer, Rich scan configuration.

Value	Description
0	Disable Rich scan (default)
1	Enable Rich scan for AT%SCANCMD
2	Enable Rich scan for any regular scan procedure

Table 133: %SCANCFG_RS_CONFIG_Description

<sl_cfg>: integer, run-time scan list(RTSL) configuration.

Value	Description
0	Disable RTSL (default)
1	Enable RTSL for AT%SCANCMD
2	Enable RTSL for any regular scan procedure

Table 134: %SCANCFG_SL_CONFIG_Description

<estart>: integer. Start EARFCN.

<estop>: integer. Stop EARFCN of the same band as start EARFCN.

<estep>: integer. EARFCN step.

Example:

5.11.1 AT%SCANCFG: Set Command

If only Rich scan over default bands/scan list is required, configure rich scan once at wakeup:

```
AT%SCANCFG=1
```

```
OK
```

If list of scanned frequencies is changed dynamically, configure rich scan and RTSL before each single rich scan:

```
AT%SCANCFG=1,1,2620,2625,1
```

```
OK
```

5.12 AT%SCANCMD: For user-triggered scan procedures

Command	Command Type	Response
AT%SCANCMD= <cmd>[,<mode>]	Set	OK ERROR
AT%SCANCMD?	Read	[%SCANCMD:<earfcn>,<pci>,<eci>,<plmnl>,<RSRP>,<RSRQ>,<bw>,<tac>,<cstat>[<CR><LF>%SCANCMD:<earfcn>,<pci>,<eci>,<plmnl>,<RSRP>,<RSRQ>,<bw>,<tac>,<cstat>...]]
AT%SCANCMD=?	Test	OK
(unsolicited report)	unsolicited	%SCANEND: <stat>

Table 135: AT%SCANCMD

Description:

This command is used to handle user-triggered scan procedures. It is accepted only in detached (unregistered) mode. The after-scan behavior may be different based on a previous configuration defined by AT%SCANCFG.

If the run-time scan list is not defined (<sl_cfg>=0), no additional scan is applied. The modem is already camped on a legal cell after the user-triggered scan procedure. If run-time scan list is defined, and overrides default settings (<sl_cfg>=1), the scan of original band table/scan list is automatically triggered at the end of a user scanning to camp on the legal cell. The read command is used to query the last user-triggered scan results. It will be different from the AT%SCAN results, which return the last regular scanning results. Any attempt to read user-triggered scan results before scanning will only return OK.

Defined values:

<cmd>: integer.

Value	Description
0	Set unsolicited result response presentation in accordance with <mode>
1	Start scan as predefined in AT%SCANCFG

Table 136: %SCANCMD_cmd_Description

<mode>: integer. Status of unsolicited result response presentation of %SCANEND.

Value	Description
0	Disable(default)
1	Enable

Table 137: %SCANCMD_mode_Description

<stat>: integer.

Value	Description
0	No cells to report
1	Scan succeeded to acquire one or more cells

Table 138: %SCANCMD_stat_Description

Next params are as per 3GPP definition: <earfcn>,<pci>,<eci>,<RSRP>,<RSRQ>,<bw - Omitted in NB-IoT>,<tac>

<plmnld>: integer. Similar to <oper> parameter of +COPS in decimal numeric format (see 3GPP Release 13 27.007 specification), but reported without quotes.

<cstat>: integer. Cell status from SIB1.

Value	Description
0	Regular cell
1	Cell barred
2	Cell reserved for operator use

Table 139: %SCANCMD_cstat_Description

5.13 AT%DNSRSLV: To Resolve a Specific Domain Name.

Command	Command Type	Response
AT%DNSRSLV= <SessionID>, <domain_name>[,<addr_ip_type>]	Set	%DNSRSLV:<ip_type>,<ip_addr> [%DNSRSLV: <ip_type>,<ip_addr>[...]] OK
AT%DNSRSLV?	Read	ERROR
AT%DNSRSLV=?	Test	OK

Table 140: AT%DNSRSLV

Description:

This command provides a request from the device to resolve a specific domain name. The IP address formatting for this command is as described in the AT%SOCKETCMD command.

Defined values:

< **SessionID** >, integer, A numerical numeric value defined in the NP configuration file which points to the PDN on which the IP address should be resolved. "Session ID" is defined in AT%CGINFO.

<**Domain_name**>: string. Domain name to resolve. Maximum string size is 256 Bytes

<**addr_ip_type**>: integer. optional parameter defining the IP address type to resolve.

Value	Description
0	IPv4
1	IPv6
2	IPv4v6 (default)

Table 141: %DNSRSLV_ADDR_IP_TYPE_Description

<**ip_type**>, integer ; optional parameter defining the IP address type to resolve.

Value	Description
0	IPv4
1	IPv6

Table 142: %DNSRSLV_IP_TYPE_Description

<**ip_addr**>: string. IPv4 or IPv6 resolved address.

Example:

5.13.1 AT%DNSRSLV: Set Command

Following command will show RSSI scan results in Short format mode.

```
AT%DNSRSLV=1,"www.google.com"  
%DNSRSLV:0,"142.250.185.164"  
%DNSRSLV:1,"2A00:1450:4001:811::2004"
```

OK

5.13.2 AT%DNSRSLV: Read Command

```
AT%DNSRSLV?  
ERROR
```

5.13.3 AT%DNSRSLV: Test Command

```
AT%DNSRSLV=?  
%DNSRSLV:<session_id>,<hostname>[,<addr_ip_type>]
```

OK

5.14 AT%NOTIFYEV: Notify The Events

Command	Command Type	Response
AT%NOTIFYEV=<ev_type>,<mode> [,<ev_type>,<mode>[,<ev_type>,<mode>...]]	Set	OK OR ERROR
AT%NOTIFYEV?	Read	ERROR
AT%NOTIFYEV=?	Test	%NOTIFYEV: (list of supported <ev_type>), (list of supported <mode>)
Unsolicited	unsolicited	%NOTIFYEV:<ev_type>[,<param1> [,<param2>]...]

Table 143: AT%NOTIFYEV

Description:

This command is used to notify the host about important events that have occurred in the LTE device. The reporting may be enabled/disabled per event type. Multiple events may be enabled/disabled by the same command call. This is a compound command which means that the <paramN> parameters are <ev_type> specific. Reporting for all event types is disabled by default at wakeup time

Note: The "LTIME" indication for time change in the "FW" is based on "time-priority" as follows:



- CCLK (highest priority: User set)
- SIB16 (Since it is more accurate than EMM)
- EMM information (Lowest priority)

Defined values:

<ev_type>: string.

Value	Description
"LTIME"	Time change in FW. Could be a result of an SIB16 change, updated EMM-information (NITZ), or a user change with the +CCLK command or %CCLK command.
"SIMREFRESH"	SIM refresh occurred. The event is sent, in addition to the AT%SIMREFRESH response. It is used to notify Altair or OEM internal NP applications or/and external host (such as Android) about SIM refresh event.
"WDIS"	W_DISABLE signal state chang
"SIMD"	SIM inserted/removed state chang
"ROAM"	current PLMN camping/connection state was changed between HPLMN/EHPLMN and VPLMN
"CSPS"	Enables notification on switches between PS and CS/PS modes in the modem
"SIMSTATE"	Reports that the UICC entered a new state during start-up or that the UICC ended startup and entered active state.
"MANSTUCK"	Reports repetitive attach attempt rejections for user selected PLMN in Manual mode.
"RRCSTATE"	Reports any RRC layer state change.
"EMMSTATE"	Reports about any NAS EMM layer state change.
"SIB1"	Reports any SIB1 arrival and processing in MAC
"SIB2"	Reports any SIB2 arrival and processing in MAC
"ALL"	Enables/disables all event types. This event type cannot be sent in unsolicited reporting.

Table 144: %NOTIFYEV_EV_TYPE_Description

<mode>: integer. Status of unsolicited result response presentation ;

Value	Description
0	Disable(default)
1	Enable

Table 145: %NOTIFYEV_Mode_Description

<param1>:

For "LTIME": <time> as encoded in the +CCLK response as (yy/mm/dd,hh:mm:ss).

For **"SIMREFRESH"**: <isRestart> as encoded in the %SIMREFRESH command.

For **"WDIS"**: W_DISABLE line changed status.

Value	Description
0	False (enable signal detected)
1	True (disable signal detected)

Table 146: %NOTIFYEV_Param_Description

For **"SIMD"**: changed status.

Value	Description
0	Removal signal detected
1	Insertion signal detect

Table 147: %NOTIFYEV_SIMD_Description

For **"ROAM"**: changed status.

Value	Description
0	Moved to Home PLMN (HPLMN/EHPLMN)
1	Moved to roaming PLMN (VPLMN)

Table 148: %NOTIFYEV_ROAM_Description

For **"CSPS"**:

Value	Description
0	Moved to PS mode
1	Moved to CS/PS mode

Table 149: %NOTIFYEV_CSPS_Description

For **"SIMSTATE"**:

Value	Description
0	SIM deactivated
1	SIM init passed, wait for PIN unlock
2	Personalization failed, wait for run-time depersonalization
3	Activation completed. Event is sent once "Ready" state reported by "AT+CPIN?" is achieved. Event is always sent at any SIM activation completion

Table 150: %NOTIFYEV_SIMSTATE_Description

For "RRCSTATE":

Value	Description
0	RRC Idle
1	RRC Connected
2	RRC Unknown. Applicable for all LTE-disabled device states (init, standby, flight mode, etc.)

Table 151: %NOTIFYEV_RRC_STATE_Description

For "EMMSTATE":

Value	Description
1	EMM_NULL
2	EMM_DEREGISTERED_NORMAL_SERVICE
3	EMM_DEREGISTERED_ATTEMPTING_TO_ATTACH
4	EMM_DEREGISTERED_PLMN_SEARCH
5	EMM_DEREGISTERED_NO_IMSI
6	EMM_DEREGISTERED_ATTACH_NEEDED
7	EMM_DEREGISTERED_NO_CELL_AVAILABLE
8	EMM_DEREGISTERED_ATTACH_ACCEPT_RECEIVED
9	EMM_DEREGISTERED_REGISTRATION_INITIATED
10	EMM_DEREGISTERED_LIMITED_SERVICE
11	EMM_REGISTERED_LIMITED_SERVICE
12	EMM_REGISTERED_NORMAL_SERVICE
13	EMM_REGISTERED_ATTEMPTING_TO_UPDATE
14	EMM_REGISTERED_PLMN_SEARCH
15	EMM_REGISTERED_UPDATE_NEEDED
16	EMM_REGISTERED_NO_CELL_AVAILABLE
17	EMM_REGISTERED_ATTEMPTING_TO_UPDATE_MM
18	EMM_REGISTERED_IMSI_DETACH_INITIATED
19	EMM_REGISTERED_NO_CELL_AVAILABLE_PSM_ACTIVE
20	EMM_REGISTERED_DEREGISTRATION_INITIATED
21	EMM_REGISTERED_TRACKING_AREA_UPDATING_INITIATED
22	EMM_REGISTERED_SERVICE_REQUEST_INITIATED

Table 152: %NOTIFYEV_EMM_State_Description

<param2>: for "SIMREFRESH": <RefreshType> as encoded

Value	Description
0	NAA Initialization and Full File Change Notification
1	File Change Notification
2	NAA Initialization and File Change Notification
3	NAA Initialization
4	UICC Reset
5	NAA Application Reset
6	NAA Session Reset
7	Steering of Roaming

Table 153: %NOTIFYEV_SIMREFRESH_Description

For "LTIME": <dst> as encoded in the %CCLK command response defined in the current document.

Example:

5.14.1 AT%NOTIFYEV: Set Command

Following command will Enable ALL events.

```
AT%NOTIFYEV="ALL",1
OK
```

5.14.2 AT%NOTIFYEV: Read Command

```
AT%NOTIFYEV?
ERROR
```

5.14.3 AT%NOTIFYEV: Test Command

```
AT%NOTIFYEV=?
%NOTIFYEV: (LTIME, SIMREFRESH, WDIS, SIMD, ROAM, CSPS, SIMSTATE,
MANSTUCK, RRCSTATE, SIB1, SIB2, ALL),(0,1)

OK
```

5.14.4 %NOTIFYEV: Unsolicited Responses

```
%NOTIFYEV:"RRCSTATE",2
```

```
%NOTIFYEV: "SIB1"
```

```
%NOTIFYEV: "SIB1"
```

```
%NOTIFYEV:"RRCSTATE",0
```

5.15 AT%PINGCMD: Execute PING services

Command	Command Type	Response
AT%PINGCMD=<ip_type>,<dst_ip>[,<count>[,<packetsize>,<timeout>]]	Set	OK OR ERROR
AT%PINGCMD?	Read	ERROR
AT%PINGCMD=?	Test	OK

Table 154: AT%PINGCMD

Description:

This command is used for executing PING services. The IP address formatting for using this command is as described in the AT%SOCKETCMD command.

Defined values:

<id>: integer. The identifier of each individual reply of the ping request (this can be 1 to <count>).

<IP type>: integer.

Value	Description
0	IPv4
1	IPv6

Table 155: %PINGCMD_IP_TYPE_Description

<dst_ip>: string. Destination (remote machine) IPv4 or IPv6 address.

<packetsize>: decimal. specifies the number of data bytes to be sent. The default is 56, which translates into 64 ICMP data bytes when combined with the 8 bytes of ICMP header data. Maximum size in IPv4 is 9936 Bytes. Maximum size in IPv6 is 9908 Bytes.

<count>: decimal. The number of ping request retries (default is 1).

<timeout>: decimal. Time to wait for a response, in seconds.

<tll>: decimal. The time to leave within the PING reply. TTL specifies how long to hold or use the packet, or any of its included data before expiring and discarding it.

<rtt>: decimal. The round trip PING time.

Example:

5.15.1 AT%PINGCMD: Set Command

```
AT%PINGCMD=0,"8.8.8.8"  
%PINGCMD:1,"8.8.8.8",441,110  
  
OK
```

5.15.2 AT%PINGCMD: Read Command

```
AT%PINGCMD?  
ERROR
```

5.15.3 AT%PINGCMD: Test Command

Example:

```
AT%PINGCMD=?  
%PINGCMD:<ip_type>,<dst_ip>[,<count>[,<pktsize>[,<timeout>]]]  
  
OK
```

5.16 AT%CERTCMD: To Read/Write/Delete/list User Certificates to/from NV.

Command	Command Type	Response
AT%CERTCMD=<cmd>[,<filename>[,<type>,<CR><LF><data>]]	Set	OK OR ERROR
AT%CERTCMD?	Read	ERROR
AT%CERTCMD=?	Test	%CERTCMD: (list of supported <cmd>), (list of supported <type>)

Table 156: AT%CERTCMD

Description:

Set command is used to read/write/delete/list user certificates to/from NV.



The PEM pseudo-text format specifics is that this format contains newlines (<LF>) in the <data> body. This causes some AT command processing troubles even if the <data> string context is enclosed in quotes. To overcome these troubles, the AT%CERTCMD="WRITE" command shall contain <CR><LF> additional newline separator just before PEM data enclosed in quotes.

Certificate and key formate example:

```
-----BEGIN CERTIFICATE-----
MIIFAzCCA1OgAwIBAgIRAIQz7DSQONZRGFPgu2OCiAwADQYJKoZIhvcNAQELBQAw
TzELMAkGA1UEBhMCVVMxKTAnBgNVBaoTIEludGVybmV0IFNlY3VyaXR5IFJlc2Vh
cmNoIEEdyb3VwMRUwEwYDVQDEwJULJHIFJvb3QgWDEwHhcNMTUwNjA0MTEwNDM4
WhcNMzUwNjA0MTEwNDM4WjBPMQswCQYDVQQGEwJVUzEpMCcGA1UEChMgSW50ZXJu
ZXQgU2VjdXJpdHkgUmVzZWZyY2ggR3JvdXAxFATBgNVBAMTDElUkcgUm9vdCBY
MTCCAIwDQYJKoZIhvcNAQEBBQADggIPADCCAgoCggIBAK3oJHP0FDfzm54rVygc
h77ct984kIxuPOZXoHj3dcKi/vVqbvYATyjb3miGbESTtrFj/RQSa78f0uoxmyF+
0TM8ukj13Xnfs7j/EvEhmkvBioZxaUpmZmyPfjxwv60pIgbz5MDmgK7iS4+3mX6U
A5/TR5d8mUgJ+g4rk8Kb4Mu0U1XjIB0ttov0DiNewNwIRT18jA8+o+u3dpjq+sW
T8KOEut+zwvo/7V3LvSye0rgTBILdHCNAymg4VMk7BPZ7hm/ELNKjD+Jo2FR3qyH
B5T0Y3HsLuJvW5iB4YlcnHlsdu87kGJ55tukmi8mxdAQ4Q7e2RCOFvu396j3x+UC
B5iPNgiV5+I3lg02d277DnKxHZu8A/lJBdiB3QW0KtZB6awBdpUKD9jflb0SHzUv
KBds0pjBqAlkd25HN7rOrFleaJl/ctaJxQZBKT5ZPt0m9STJEadao0xAH0ahmbWn
OlFuhjuefXKnEgV4We0+UXgVCWOPjdAvBBI+e0ocs3MFEVzG6uBQE3xK3SzynTn
jh8BCNAw1FtxNrQHusEwMFxIt4I7mKZ9YIqioymCzLg9gwQbooMDQaHwBfEbwrBw
qHyGOaoSCqI3Haadr8faqu9GY/rOPNk3sgrdQoo//fb4hVC1CLQJ13hef4Y53CI
rU7m2Ys6xt0nUW7/vGTlM0NPAGMBAAGjQjBAMA4GA1UdDwEB/wQEAwIBBjAPBgNV
HRMBAf8EBTADAQH/MB0GA1UdDgQWBBR5tFnme7bl5AFzgAiIyBpY9umbbjANBgkq
hkiG9w0BAQsFAAOCAgEAVR9YqbyyqFDQDLHYGmkGjYkIrGf1Xlpu+ILlaS/V91ZL
ubhzEFnTIZd+50xx+7LSYK05gAvqFyFWhfFQDlnrzuBZ6brJFe+GnY+EGPbk6ZGQ
3BebYhtF8GaV0nxvwu077x/Py9auJ/GpsMiu/Xl+mvoiBOv/2X/qkSsisRcOj/KK
NfY2PwByVS5uCbMioziUwthDyC3+6WVwW6LLv3xLfHTjuCvjHIIInNzktHCgKQ5
ORAZI4JMPJ+GslWYHb4phowim57iaztXOoJwTdwJx4nLCgdNbOhdjsnvzqvHu7U
TkXWstAmzOVyyghqpZXjFaH3p03JLF+1+/+sKAiuvtd7u+Nxe5AW0wderlN8NwdC
jNPElpzVmbUq4JUagEiutDkHzzxHpFKVK7q4+63SM1N95RlNbdWhscdCb+ZAJZVc
oyi3B43njtOQ5yOf+1CceWxG1bQV55ZufpsMlj4Uio/1lvh+wjChP4kqKOJ2qxg
4RgqsahDYVvTH9w7jXbyLeiNdd8XM2w9U/t7y0Ff/9yi0GE44Za4rF2LN9d11TPA
mRGunUHBcnWEvgJBQl9nJE1U0Zsnvgc/ubhPgXRR4Xq37Z0j4r7g1SgEEZwxAS7d
emyPxgcYxn/eR44/KJ4EBs+lVDR3veyJm+kXQ99b21/+jh5Xos1AnX5iItreGCC=
-----END CERTIFICATE-----
```

Figure 2: certificate-formate

Defined values:**<cmd>**: string.

Value	Description
"READ"	Read the certificates pointed by <filename>. [Private key cannot be read, command returns ERROR.]
"WRITE"	Write the credentials with its <filename> to the NV storage
"DELETE"	Delete the credential pointed by the <filename> from the NV storage
"DIR"	Get the list of credential file names pointed by <filename>.

Table 157: %CERTCMD_CMD_Description

<filename>: string.

The name of the file to be transferred, deleted or listed. Use " " for this parameter to retrieve trusted root certificates folder content. If omitted, the list of files from user root certificate folder (written by AT%CERTCMD="WRITE") is shown. Next size limitation are applicable to the size of this parameter.



The name of the file itself is limited to 29 bytes
The name of the relative path (including file name) is limited to 64 bytes



Note: if <type>=3 (PSK), the filename shall have .psk extension. Any attempt to store PSK into file with different extension will be rejected with ERROR. All other TLS/DTLS objects (<type>=0/1/2) shall not use this extension

<type>: integer.

Value	Description
0	Certificate
1	Private key
2	PSK ID
3	PSK Key

Table 158: %CERTCMD_Type_Description

<data>: string.

certificate/private key in PEM format. Usage of quotes is mandatory. The data content in PEM format is transferred in pseudo-text format with <LF> (0x10) service symbols inside and will be shown with newlines.



Hexadecimal type for PSK ID/PSK. Usage of quotes is mandatory. The data size is limited by: Up to 128 bytes for PSK ID 8-64 bytes for PSK

Example:

5.16.1 Upload CA certificate

Upload CA certificate named "AmazonRootCA3ECC256.pem"

```
AT%CERTCMD="WRITE","AmazonRootCA3ECC256.pem",0,"-----BEGIN_
CERTIFICATE-----
....
-----END_CERTIFICATE-----"
OK
```

5.16.2 Upload client private key

Upload client private key named "97fbc28291-private.pem.key" while encrypting the key

```
AT%CERTCMD="WRITE","97fbc28291-private.pem.key",1,"-----BEGIN_RSA_
PRIVATE_KEY-----
.....
-----END_RSA_PRIVATE_KEY-----"
OK
```

5.16.3 Read Client Certificate

Read Client Certificate named b7c1bd8c7c-certificate.pem.crt

```
AT%CERTCMD="READ","b7c1bd8c7c-certificate.pem.crt"
%CERTCMD: "-----BEGIN_CERTIFICATE-----
.....
-----END_CERTIFICATE-----"
OK
```

5.16.4 Get the list of credential folder files:

Get the list of credential folder files:

```
AT%CERTCMD="DIR"
%CERTCMD: "AmazonRootCA3ECC256.pem","b7c1bd8c7c-private.pem.key", "
b7c1bd8c7c-certificate.pem.crt"

OK
```

5.16.5 Upload PSK ID:

Upload PSK ID value "123456789" into file:

```
AT%CERTCMD="WRITE","testPskID.bin",2, "313233343536373839"  
OK
```

5.16.6 Upload PSK Passphrase "mySharedKey" into file:

Upload PSK Passphrase "mySharedKey" into file:

```
AT%CERTCMD="WRITE","testPSK.psk",3, "6d7953686172655644b6579"  
OK
```

5.16.7 Read PSK ID file:

Read PSK ID file named testPskId.bin:

```
AT%CERTCMD="READ","testPskId.bin"  
%CERTCFG: "313233343536373839"  
OK
```

5.16.8 Read PSK file:

Read PSK file named testPsk.psk:

```
AT%CERTCMD="READ","testPsk.psk"
```

5.17 AT%CERTCFG: To Add/Delete Certificate (TLS) Profiles

Command	Command Type	Response
AT%CERTCFG=<op>,<profile_id>[,<ca_file>][,<ca_path>][,<dev_cert>,<dev_key>][,<psk_id>,<psk_key>]]]	Set	OK OR ERROR
AT%CERTCFG?	Read	[%CERTCFG: <profile_id>[,<profile_id>...]] OK
AT%CERTCFG=?	Test	%CERTCFG: (list of supported <op>s)

Table 159: AT%CERTCFG

Description: Set command is used to to add/delete certificate (TLS) profiles into TLS certificate profiles config file.

Device contains 2 certificate storage locations:

- Root Trusted folder, which contains only root CAs
- User Trusted folder, which contains root CAs and device credentials (certificate and private key) installed by user or provisioned over the air.

The parameters encoded in AT commands and composed then into single TLS profile stored into configuration file. This config file content will be composed from per-profile sections like:

```
" profile __id": {
  'cafile': "ca_file",
  'capath': "ca_path",
  'cert': "dev_cert",
  'key': "dev_key",
  "pskid": "psk_id",
  "pskkey": "psk_key"
}
```

Where <profile_id>, <ca_file>, <ca_path>, <dev_cert> and <dev_key> are taken from the input parameter list.

Any <ca_file>, <ca_path>, <dev_cert> and <dev_key> are optional and may be omitted. The <dev_cert> and <dev_key> shall be always added together or omitted together too.

If some parameters are omitted, they will be also omitted in config file.

When per-profile section is created by this AT command, TLS security layer using this profile will apply next rules.

If root CA file name is known and <ca_file> parameter is set, then try to find <ca_file> in both storage locations in next order.

- Root Trusted folder
- User Trusted folder

If <ca_file> is defined, but not found or if root CA file name is unknown and <ca_file> parameter is omitted, apply <ca_path> parameter, if present.

- If <ca_path> = " ", then use Root Trusted folder to verify server certificate
- If <ca_path> = ".", then use User Trusted folder to verify server certificate

Always use User Trusted folder to find device <dev_cert> and <dev_key> pair.



This is the AT Command responsibility, which is going to use TLS profile (i.e. AT%SOCKETCMD, AT%ATSIOTCMD, etc.) to verify if the profile is properly defined and contain all needed credential for mutual, server or device authentication.



The Default profile ID=0 cannot be defined by this AT and does not present in TLS config file.
It may be used by TLS-consumer ATs (such as AT%SOCKETCMD, AT%ATSIOTCMD, etc.). This default profile implies only server authentication using root CA stored into Root Trusted folder.

Defined values:

<op>: string. Operation to be applied to TLS profile in config file.



Add operation applied to existed profile will return ERROR.

Value	Description
"ADD"	Add new profile
"DELETE"	Delete profile

Table 160: %CERTCFG_Op_Description

<profile_id>: integer. Numeric value to identify set of credentials used together for some TLS connection(s). (Range: 1-255)



The profile_id=0 is prohibited and reserved for root trusted certs already stored into default root trusted folder.

<ca_file>: string. The name of the root certificate file, if it is known.

<ca_path>: string. The path of the user-added or trusted root certificates.



Use " " (home directory) to create <ca_path> config file parameter for default root trusted folder.



Use "." to create <ca_path> config file parameter for user root certificate folder (which content is populated by AT%CERTCMD="WRITE").

<dev_cert>: string. The name of the user-added device cert file.

<dev_key>: string. The name of the user-added device private key file.

<psk_id>: string. The name of the user-added PSK ID.

<psk_key>: string. The name of the user-added PSK.



PSK filename shall have .psk extension.
Any attempt to create profile with PSK filename with different extension will be rejected with ERROR.

Example:

5.17.1 Create New Config File Section:

```
AT%CERTCFG="ADD",1,"AmazonRootCA3ECC256.pem",,"b7c1bd8c7c—certificate.pem.crt"  
,"b7c1bd8c7c—private.pem.key"  
OK
```

Created section:

```
"1": {  
  'cafile': "AmazonRootCA3ECC256.pem",  
  'cert': "b7c1bd8c7c—certificate.pem.crt",  
  'key': "b7c1bd8c7c—private.pem.key",  
}
```

5.17.2 Create New PSK Config File Section:

```
AT%CERTCFG="ADD",2,,,,,"testPskId.bin","testPsk.psk"  
OK
```

Created section:

```
"2": {  
  "pskid": "testPskId.bin",  
  "pskkey": "testPsk.psk"  
}
```


5.18 AT%CPSMS: Enable/Disable PSM Status Change Notification

Command	Command Type	Response
AT%CPSMS=<cmd>[,<param1>[...]]	Set	OK OR ERROR
AT%CPSMS?	Read	%CPSMS: <state>,<act> OK
AT%CPSMS=?	Test	%CPSMS: (list of supported <cmd>s) OK
Unsolicited	unsolicited	%CPSMSU: <event>

Table 161: AT%CPSMS

Description:

AT command controls non-standard PSM operations and provides enabling/disabling for PSM status change notification.

The execution AT%CPSMS=2 (start camping) triggers cell reconnection procedure, which will be normally stopped by camping on suitable cell.

Modem is considered as get stuck in PSM mode during whole camping attempt and when the camping has been finished.

Read command returns PSM activity status <act>=1.

The AT%CPSMS=2 is accepted only in PSM mode. Otherwise the ERROR will be returned.

The AT%CPSMS=3 (interrupt camping) is accepted only if camping attempt was previously triggered by AT%CPSMS=2. Otherwise the ERROR will be returned.

Read command returns together: PSM feature enabled state (may be also retrieved by AT+CPSMS?)
Current PSM activated status (may be also retrieved by AT%STATUS="PSM").

Defined values:

<cmd>: integer. Mode of unsolicited result response presentation.

Value	Description
0	Disable %CPSMSU URC (default)
1	Enable %CPSMSU URC
2	Trigger attempt to camp on cell while in PSM.
3	Interrupt "camping on cell" attempt

Table 162: %CPSMS_Cmd_Description

For <cmd>=2 (start "camping on cell" attempt)

<param1>: integer.

Value	Description
1 - 1200	Optional camping attempt timeout in sec. Default:120 sec

Table 163: %CPSMS_param1_Description

<state>: integer. State of PSM feature.

Value	Description
0	disable
1	Enable

Table 164: %CPSMS_state_Description

<act>: integer. PSM activity status.

Value	Description
0	Inactive
1	Active

Table 165: %CPSMS_Act_Description

<event>: integer.

Value	Description
0	Exit PSM
1	Enter PSM
2	Successfully camped on cell while in PSM
4	Camping attempt interrupted by timeout

Table 166: %CPSMS_Event_Description

5.19 AT%TSTRF: AT command for RF TX/RX test mode

Command	Command Type	Response
AT%TSTRF=<cmd>[,<earfcn>,<time>[,<param1>[,<param2>,<param3>[,<param4>,<param5>,<param6>[,<param7>]]]]]	Set	For <cmd>=4 (RX read) only: %TSTRF: min=<min>, avg=<avg>, max=<max>
AT%TSTRF?	Read	%TSTRF: <status>
AT%TSTRF=?	Test	OK

Table 167: AT%TSTRF

Description:

Test AT command is intended for RF TX/RX test mode. This command is not accepted in operational mode (AT+CFUN=1) and flight mode (AT+CFUN=4). The modem shall be previously switched in non-operational mode by AT+CFUN=0.

The RX and TX test commands only triggers test operation and are not blocking for the time defined in <time> parameter. To interrupt TX and RX test mode the abort sub-command (AT%TSTRF=1) is required. To return to normal operational mode after any type of the RF tests reboot is required.



To return to the normal operational mode after any type of the RF tests Adrastea-I reboot is required.

For SC-FDMA(Single Carrier FDMA): The transmission will not be on the full system BW but over BW=1.4MHz(CATM) /180KHz(NB-IOT).

The maximum Frequency/EARFCN available for testing would be according to the 3GPP Release 13 specifications for supported bands of the device.

For CW Rx Tests it is recommended to provide the following offset:

- For NB-IoT use 500kHz

- For CAT-M use 1MHz

Defined values:

<cmd>: integer. command.

Value	Description
1	Abort RX/TX test
2	Start RX test
3	Start TX test
4	RX test results read

Table 168: %TSTRF_cmd_Description

<earfcn>: integer. EARFCN decimal value as per the LTE specifications.

<time>: test execution time in ms.

Value	Description
0	For RX: one-shot measurement For TX: continuous TX forever
1-600000	ms

Table 169: %TSTRF_time_Description

For <cmd>=2 ("RX test"):

<param1>: Not Applicable.

For <cmd>=3 ("TX test"):

<param1>: integer. type of transmitted signal.

Value	Description
0	SC-FDMA (Not applicable for NB-IoT)
1	CW (continuous waveform)
2	SC-FDMA of NB-IoT

Table 170: %TSTRF_Param1_Description

For <param1>=0 (SC-FDMA):

<param2>: integer. TX power, absolute output power [dBm*100]

<param3>: integer. Bandwidth.

Value	Description
0	1.4 MHz
1	3 MHz
2	5 MHz
3	10 MHz
4	14 MHz
5	20 MHz

Table 171: %TSTRF_Param3_Description

<param4>: integer. MCS.

- 0-15

<param5>: integer. Number of RB allocation. Not applicable for NB-IoT.

- 1-6

<param6>: integer. Position of RB allocation. Where: <rb_num>+<rb_pos> <= 6 (maximum 6 RB slots). Not applicable for NB-IoT.

- 0-5

<param7>: integer. NB index as defined in 3GPP Release-13 TS36.211, sec. 5.2.4. Not applicable for NB-IoT.

- 0 - max (per BW)

For <param1>=1 (CW):

<param2>: integer. TX power, absolute output power [dBm*100]

<param3>: integer. offset to central frequency in Hz.

For <param1>=2 (SC-FDMA of NB-IoT):

<param2>: integer. TX power, absolute output power [dBm*100]

<param3>: integer. MCS

- 0-12

<param4>: integer. Subcarrier spacing.

Value	Description
0	15 KHz
1	3.75 KHz

Table 172: %TSTRF_Param4_Description

<param5>: integer. Subcarrier index, as defined in 3GPP Release 13 TS36.211, table 16.5.1.1-1:

Value	Description
0 - 18	For <param4>=0 (15KHz)
1 - 47	For <param4>=1 (3.75KHz)

Table 173: %TSTRF_Param5_Description

For <cmd>=4 (RX test results read):

<min>, <avg>, <max> values measured energy value in dBm. **<status>**: integer. Status of test.

Value	Description
0	Busy
1	Ready

Table 174: %TSTRF_status_Description

<error>: integer. As per 3GPP Release 13 TS27.007

Example:

Test commands are not accepted in operational mode (AT+CFUN=1) nor in flight mode (CFUN=4). The modem shall have been previously switched into non-operational mode by CFUN=0. To return to normal operational mode after any type of the RF tests reboot is required.

```
AT+CFUN=0
OK
```

```
AT%TSTRF=1
OK
```

5.19.1 RX test mode

The following is an example for RX test mode where EARFCN=2175 (FDD-DL), time=5000 (5 sec test duration), :

```
at%TSTRF=2,2175,5000,0
OK
```

AT%TSTRF=4 should be apply afterward to read the result:

5.19.2 TX test mode

The following command is an example for continuous TX Command: Band 20 (i.e. Centre Freq = 847MHz), TX Power=23 dBm, Bandwidth = 1.4MHz

```
AT%TSTRF=3,20630,0,1,2300,0
OK
```

The following command is an example for CATM continuous TX: EARFCN=20175, continuous TX forever, SC-FDMA, TX Power=23 dBm, Bandwidth =1.4MHz, MCS=5, number of RB allocation=6, position of RB allocation =0,

```
AT%TSTRF=3,20175,0,0,2300,0,5,6,0,0
OK
```

5.20 AT%VER: Display firmware version information

Command	Command Type	Response
AT%VER	Execute	<ver_info>
AT%VER?	Read	ERROR (OPERATION_NOT_ALLOWED)
AT%VER=?	Test	OK

Table 175: AT%VER

Description:

Display SW/FW version information.

Defined values: <ver_info>: version information.

Example:

```
AT%VER
AT%VER

NP Package: ADRASTEAI_06.006
Apps:
  RKAPP_03_00_00_00_11951_001__bb851e11f4dd3ec6c2ef1db6d32e82fbffd46827
Using APP processor – no SB or 3B versions
MAC Revision: REL_1250_03_00_00_REV_269663
MAC Package Version: ALT1250_03_00_00_00_11952_FW
MAC Build Time: May_13_2021_13_04_32
PHY Revision: 12.50.269659
PHY Build Time: May_13_2021_12_56_49
PHY Build Info: releas_0
PMP Revision: 269624
PMP Version: 11951_PMP
PMP build time: Feb_24_2020_17_02_18
DSP Revision: 65262
```

```
BB Product: 1250
BB HW Revision: 20
RFIC_6200 Revision: 00
NP Build Time: Jun 9 2021 16:26:55
C&V Ver: 9.56
Calibration date: 08.09.21
Calibrated NP package: RK_03_00_00_00_01
```

```
OK
```


6 AT Commands for Packet Domain

6.1 +CEREG: EPS Network Registration Status

The +CEREG command subscribes unsolicited network status notifications.

Command	Command Type	Response
AT+CEREG=<n>	Set	OK
AT+CEREG?	Read	<p>When <n>=0, 1, 2 or 3 and command successful:</p> <p>+CEREG: <n>,<stat>[,<tac>],[<ci>],[<AcT>[, <cause_type>,<reject_cause>]]]</p> <p>When <n>=4 or 5 and command successful:</p> <p>+CEREG:<n>,<stat>[,<lac>],[<ci>],[<AcT>],[<rac>[,<cause_type>],[<reject_cause>],[<Active-Time>],[<Periodic-TAU>]]]</p>
AT+CEREG=?	Test	+CEREG: (list of supported <n>))

Table 176: AT+CEREG

Description:

The set command controls the presentation of an unsolicited result code +CEREG: <stat> when <n>=1 and there is a change in the MT's network registration status in LTE, or unsolicited result code +CEREG:.

<stat>[,<tac>],[<ci>],[<AcT>]] when <n>=2 and there is a change of the network cell in LTE. The parameters <AcT>, <tac> and <ci> are sent only if available. The value <n>=3 further extends the unsolicited result code with [,<cause_type>,<reject_cause>], when available, when the value of <stat> changes.

The read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the MT. Location information elements <tac>, <ci> and <AcT>, if available, are returned only when <n>=2 and MT is registered in the network. The parameters[,<cause_type>,<reject_cause>], if available, are returned when <n>=3.

Test command returns values supported as a compound value.

Defined values:

<n>: integer.

Value	Description
0	disable network registration unsolicited result code
1	enable network registration unsolicited result code +CEREG: <stat>
2	enable network registration and location information unsolicited result code +CEREG:<stat>[,<tac>],[<ci>],[<AcT>]]
3	enable network registration, location information and EMM cause value information unsolicited result code +CEREG:<stat>[,<tac>],[<ci>],[<AcT>][,<cause_type>,<reject_cause>]]
4	For a UE that wants to apply PSM, enable network registration and location information unsolicited result code +CEREG: <stat>[,<tac>],[<ci>],[<AcT>][,<Active-Time>],[<Periodic-TAU>]]]
5	For a UE that wants to apply PSM, enable network registration, location information and EMM cause value information unsolicited result code +CEREG:<stat>[,<tac>],[<ci>],[<AcT>][,<cause_type>],[<reject_cause>][,<Active-Time>],[<Periodic-TAU>]]]

Table 177: +CEREG_N_Description

<stat>: integer.

Value	Description
0	not registered, MT is not currently searching an operator to register
1	registered, home network
2	not registered, but MT is currently trying to attach or searching to register
3	registration denied
4	unknown (e.g. out of E-UTRAN coverage)
5	registered, roaming
6	registered for "SMS only", home network (not applicable)
7	registered for "SMS only", roaming (not applicable)
8	attached for emergency bearer services only (see NOTE 1)
9	registered for "CSFB not preferred", home network (not applicable)
10	registered for "CSFB not preferred", roaming (not applicable)

Table 178: +CEREG_Stat_Description

NOTE 1: 3GPP TS 24.008 and 3GPP TS 24.301 Release-13 specify the condition when the MS is considered as attached for emergency bearer services.

<tac>: string. Two byte tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal).

<ci>: string. Four byte E-UTRAN cell ID in hexadecimal format.

<Act>: integer. The parameter sets/shows the access technology of the serving cell.

Value	Description
0	GSM (not applicable)
1	GSM Compact (not applicable)
2	UTRAN (not applicable)
3	GSM w/EGPRS (not applicable)
4	UTRAN w/HSDPA (not applicable)
5	UTRAN w/HSUPA (not applicable)
6	UTRAN w/HSDPA and HSUPA (not applicable)
7	E-UTRAN

Table 179: +CEREG_ActDescription

<cause_type>: integer. Indicates the type of<reject_cause>.

Value	Description
0	Indicates that <reject_cause> contains an EMM cause value.
1	Indicates that <reject_cause> contains a manufacturer-specific cause.

Table 180: +CEREG_Cause_Type_Description

<reject_cause>: integer. Contains the cause of the failed registration. The value is of type as defined by <cause_type>.

<Active-Time>: string. One byte in an 8 bit format. Indicates the Active Time value (T3324) allocated to the UE in LTE.

The Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes).

Bits 5 to 1: Represent the binary coded timer value. Bits 6 to 8: Defines the timer value unit for the GPRS timer as follows:

value	Description
0 0 0	value is incremented in multiples of 2 seconds.
0 0 1	value is incremented in multiples of 1 minute.
0 1 0	value is incremented in multiples of decihours.
1 1 1	value indicates that the timer is deactivated.

Table 181: +CEREG_Active_Timer_value

<Periodic-TAU>:string. One byte in an 8 bit format. Indicates the extended periodic TAU value (T3412) allocated to the UE in E-UTRAN.

The extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours).

Bits 5 to 1 represent the binary coded timer value.

Bits 8 to 6 define the timer value unit as follows:

value	Description
0 0 0	value is incremented in multiples of 10 minutes.
0 0 1	value is incremented in multiples of 1 hour.
0 1 0	value is incremented in multiples of 10 hours.
0 1 1	value is incremented in multiples of 2 seconds.
1 0 0	value is incremented in multiples of 30 seconds.
1 0 1	value is incremented in multiples of 1 minute.
1 1 0	value is incremented in multiples of 320 hours.
1 1 1	value indicates that the timer is deactivated.

Table 182: CEREg_T3412_Timer_value

Example:

6.1.1 AT+CEREg: Set Command

The following command set notifications with level 2:

```
AT+CEREg=2
OK
```

6.1.2 AT+CEREg: Read Command

Example:

```
AT+CEREg?
+CEREg: 2,5,"CB48","01CD6007",9
OK
```

6.1.3 AT+CEREg: Test Command

Example:

```
AT+CEREG=?  
+CEREG: (0,1,2,3,4,5)
```

```
OK
```

6.2 +CGEREP: Packet domain event reporting

Command	Command Type	Response
AT+CGEREP=[<mode>[,<bfr>]]	Set	OK
AT+CGEREP?	Read	+CGEREP: <mode>,<bfr> OK
AT+CGEREP=?	Test	+CGEREP: (list of supported <mode>),(list of supported<bfr>) OK

Table 183: AT+CGEREP

Description: Command enables or disables sending of unsolicited result codes, +CGEV: XXX from MT to TE in the case of certain events occurring in the Packet Domain MT or the network. <mode> controls the processing of unsolicited result codes specified within this command. <bfr> controls the effect on buffered codes when <mode> 1 or 2 is entered. If a setting is not supported by the MT, Read command returns the current mode and buffer settings. Test command returns the modes and buffer settings supported by the MT as compound values.

Defined values:

<mode>: integer.

Value	Description
0	Buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE.
1	discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE
2	buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE.

Table 184: +CGEREP_Mode_Description

<bfr>: integer.

Value	Description
0	MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is entered.
1	MT buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is entered (OK response shall be given before flushing the codes)

Table 185: +CGEREP_bfr_Description

Example:

6.2.1 AT+CGEREP: Set Command

The following command subscribes CGEV notifications:

```
AT+CGEREP=1  
OK
```

6.2.2 AT+CGEREP: Read Command

Example:

```
AT+CGEREP?  
+CGEREP: 1,0  
  
OK
```

6.2.3 AT+CGEREP: Test Command

Example:

```
AT+CGEREP=?  
+CGEREP: (0-2),(0-1)  
  
OK
```

6.3 +CGDCONT: Define PDP Context

This command defines Packet Data Protocol (PDP) Context.

Command	Command Type	Response
AT+CGDCONT= [<cid> [,<PDP_type>[,<APN> [,<PDP_addr>[,<d_comp> [,<h_comp>[,<IPv4AddrAlloc> [,<request_type> [,<PCSCF_discovery> [,<IM_CN_Signalling_Flag_Ind> [,<NSLPI>[,<securePCO> [,<IPv4_MTU_discovery>][, <Local_Addr_Ind>]]]]]]]]]]]	Set	OK or ERROR
AT+CGDCONT?	Read	[+CGDCONT:<cid>,<PDP_type>,<APN>, <PDP_addr>,<d_comp>,<h_comp> [,<IPv4AddrAlloc>[,<request_type> [,<PCSCF_discovery> [,<IM_CN_Signalling_Flag_Ind>[,<NSLPI> [,<securePCO>[,<IPv4_MTU_discovery> [,<Local_Addr_Ind>]]]]]]]]][+CGDCONT:<cid>,<PDP_type>,<APN>, <PDP_addr>,<d_comp>,<h_comp> [,<IPv4AddrAlloc>,<request_type> [,<PCSCF_discovery> [,<IM_CN_Signalling_Flag_Ind>[,<NSLPI> [,<securePCO>[,<IPv4_MTU_discovery> [,<Local_Addr_Ind>]]]]]]]]]
AT+CGDCONT=?	Test	+CGDCONT: (range of supportet<cid>)),<PDP_type>,, (list of supported <d_comp>), (list of supported <h_comp>),(list of supported <IPv4AddrAlloc>)...

Table 186: AT+CGDCONT

Description:

The set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter.



Modem may automatically set the PDN context. Command shall be used with caution.

Defined values:

<cid>: integer. Specifies a particular PDP context definition.

<PDP_type>: string. Specifies the type of packet data protocol.

- IP
- IPV6
- IPV4V6

<APN>: string. A logical name that is used to select the gateway or the external packet data network.

<PDP_addr>: Parameter omitted.

<d_comp>: Data compression is not supported. Parameters omitted.

<h_comp>: Header compression is not supported. Parameters omitted.

<IPv4AddrAlloc>: integer.

- 0: IPv4 address allocation through NAS signalling
- 1: IPv4 address allocated through DHCP

<request type>: Parameters omitted

<P-CSCF_discovery>: Parameters omitted

<IM_CN_Signalling_Flag_Ind>: Parameters omitted

<NSLPI>: integer. Indicates the NAS signalling priority requested for this PDP context.

- 0: indicates that this PDP context is to be activated with the value for the low priority indicator configured in the MT.
- 1: indicates that this PDP context is is to be activated with the value for the low priority indicator set to "MS is not configured for NAS signalling low priority".

<securePCO>: integer. Specifies if security protected transmission of PCO is requested or not.

- 0: Security protected transmission of PCO is not requested.
- 1: Security protected transmission of PCO is requested.

<IPv4_MTU_discovery>: Parameters omitted.

<Local_Addr_Ind>: Parameters omitted.

Example:**6.3.1 AT+CGDCONT: Set Command**

The following command set notifications with level 2:

```
AT+CGDCONT=2,"IP","iot.1nce.net"
OK
```

6.3.2 AT+CGDCONT: Read Command

Example:

```
AT+CGDCONT?  
+CGDCONT: 1,"IPV4V6",,,0,0,0,0,0,0,,  
  
+CGDCONT: 2,"IP","iot.1nce.net" ,,0,0,0,,,,,  
  
OK
```

6.3.3 AT+CGDCONT: Test Command

Example:

```
AT+CGDCONT=?  
+CGDCONT: (1-15),"IP",,,(0),(0),(0-1),(0-1),(0-2),(0),(0-1),(0),(0),(0),(0),(0)  
+CGDCONT: (1-15),"IPV6",,,(0),(0),(0-1),(0-1),(0-2),(0),(0-1),(0),(0),(0),(0),(0)  
+CGDCONT: (1-15),"IPV4V6",,,(0),(0),(0-1),(0-1),(0-2),(0),(0-1),(0),(0),(0),(0),(0)  
+CGDCONT: (1-15),"Non-IP",,,(0),(0),(0-1),(0-1),(0-2),(0),(0-1),(0),(0),(0),(0),(0)  
  
OK
```

6.4 +CGACT: PDP Context Activate or Deactivate

Command	Command Type	Response
AT+CGACT=[<state>[,<cid>]	Set	OK or +CME ERROR: <err>
AT+CGACT?	Read	+CGACT: [<cid>,<state>] [+CGACT:<cid>,<state> [...]]
AT+CGACT=?	Test	+CGACT: (list of supported <state>s)

Table 187: AT+CGACT

Description:

The execution command is used to activate or deactivate the specified PDP context. If any PDP context is already in the requested state, the state for that context remains unchanged. If the requested state for any specified context cannot be achieved, an ERROR or +CME ERROR response is returned. If the MT is not PS attached when the activation form of the command is executed, the MT first performs a PS attach and then attempts to activate the specified contexts. If the attach fails then the MT responds with ERROR or, if extended error responses are enabled, with the appropriate failure-to-attach error message.

For EPS, if an attempt is made to disconnect the last PDN connection, then the MT responds with ERROR or, if extended error responses are enabled, a +CME ERROR.

Note: If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup.

For EPS, the activation request for an EPS bearer resource will be answered by the network by either an EPS dedicated bearer activation or EPS bearermodification request. The request must be accepted by the MT before the PDP context can be set in to established state.

If no <cid>s are specified the activation form of the command activates all defined contexts.

If no <cid>s are specified the deactivation form of the command deactivates all active contexts.

The read command returns the current activation states for all the defined PDP contexts.

The test command is used for requesting information on the supported PDP context activation states.

Defined values:

<state>: integer.

Value	Description
0	Deactivated
1	Activated

Table 188: +CGACT_State_Description

<cid>: integer. Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands).

6.4.1 AT+CGACT: Set Command

The Following command activates or deactivates a PDN connection

6.4.2 AT+CGACT: Read Command

Example:

```
AT+CGACT?
+CGACT: 1,1
+CGACT: 2,0
+CGACT: 3,0
+CGACT: 4,0
+CGACT: 5,0
+CGACT: 6,0
+CGACT: 7,0
+CGACT: 8,0
+CGACT: 9,0
+CGACT: 10,0
+CGACT: 11,0
+CGACT: 12,0
+CGACT: 13,0
+CGACT: 14,0
+CGACT: 15,0
```

```
OK
```

6.4.3 AT+CGACT: Test Command

Example:

```
AT+CGACT=?
+CGACT: (0-1)
```

```
OK
```

6.5 +CGAUTH: Define PDP Context Authentication Parameters

Command	Command Type	Response
AT+CGAUTH=<cid>[,<auth_prot>[,<userid>[,<password>]]]	Set	OK or +CME ERROR: <err>
AT+CGAUTH?	Read	[+CGAUTH:<cid>,<auth_prot>,<userid>,<password>][<CR><LF>+CGAUTH:<cid>,<auth_prot>,<userid>,<password> [...]]
AT+CGAUTH=?	Test	+CGAUTH: (range of supported <cid>s),(list of supported <auth_prot>s),(range of supported <userid>s),(range of supported <password>s)

Table 189: AT+CGAUTH

Description:

Set command allows the TE to specify authentication parameters for a PDP context identified by the (local) context identification parameter <cid> used during the PDP context activation and the PDP context modification procedures. Since the <cid> is the same parameter that is used in the +CGDCONT and +CGDSCONT commands, +CGAUTH is effectively as an extension to these commands.

The read command returns the current settings for each defined context.

The test command returns values supported as a compound value.

Defined values:

<cid>: integer. Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands).

<auth_prot>: integer. Authentication protocol used for this PDP context.

Value	Description
0	NONE. Used to indicate that no authentication protocol is used for this PDP context. Username and password are removed if previously specified.
1	PAP
2	CHAP

Table 190: +CGAUTH_auth_prot_Description

<userid>: string. User name for access to the IP network.

<password>: string. Password for access to the IP network.

6.6 +CEMODE: UE modes of operation for EPS

Command	Command Type	Response
AT+CEMODE=[<mode>]	Set	OK or +CME ERROR: <err>
AT+CEMODE?	Read	+CEMODE: <mode> OK
AT+CEMODE=?	Test	+CEMODE: (list of supported s)

Table 191: AT+CEMODE

Description:

The set command is used to set the MT to operate according to the specified mode of operation for EPS, see 3GPP release-13 TS24.301. If the requested mode of operation is not supported, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command.

The read command returns the mode of operation set by the TE, independent of the current serving cell capability and independent of the current serving cell Access Technology. The test command is used for requesting information on the supported MT modes of operation as a compound value.

Defined values:

<mode>: integer.

Value	Description
0	PS mode 2 of operation
1	CS/PS mode 1 of operation
2	CS/PS mode 2 of operation
3	PS mode 1 of operation

Table 192: +CEMODE_Mode_Description



The definition for UE modes of operation can be found in 3GPP Release-13 TS 24.301

6.7 +CGCMOD: Modify PDP Context

Command	Command Type	Response
AT+CGCMOD[=<cid>[,<cid>[,...]]]	Execute	OK or +CME ERROR: <err>
AT+CEMODE=?	Test	+CGCMOD: (list of <cid>s associated with active contexts)

Table 193: AT+CGCMOD

Description:

The execution command is used to modify the specified PDP context (s) with respect to QoS profiles and TFTs. After the command has completed, the MT returns to V.250 online data state. If the requested modification for any specified context cannot be achieved, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command.

For EPS, the modification request for an EPS bearer resource will be answered by the network by an EPS bearer modification request. The request must be accepted by the MT before the PDP context is effectively changed.

If no <cid>s are specified the activation form of the command modifies all active contexts.

The test command returns a list of <cid>s associated with active contexts.

Defined values:

<cid>: integer. Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands).

6.8 +CGCONTRDP: PDP Context Read Dynamic Parameters

Command	Command Type	Response
AT+CGCONTRDP[=<cid>]	Execute	[+CGCONTRDP: <cid>,<bearer_id>,<apn>[,<local_addr and subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr> [,<P_CSCF_sec_addr>[,<IM_CN_Signalling_Flag> [,<LIPA_indication>]]]]]]]]][<CR><LF> +CGCONTRDP:<cid>,<bearer_id>,<apn> [,<local_addr and subnet_mask> [,<gw_addr>[,<DNS_prim_addr>[,<DNS_sec_addr> [,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr> [,<IM_CN_Signalling_Flag>[, <LIPA_indication>]]]]]]]]][...]]
AT+CEMODE?	Read	+CEMODE: <mode> OK
AT+CEMODE=?	Test	+CEMODE: (list of supported s)

Table 194: AT+CEMODE

Description:

The execution command returns the relevant information <bearer_id>, <apn>, <local_addr and subnet_mask>, <gw_addr>, <DNS_prim_addr>, <DNS_sec_addr>, <P-CSCF_prim_addr>, <P-CSCF_sec_addr>, <IM_CN_Signalling_Flag> and <LIPA_indication> for an active non secondary PDP context with the context identifier <cid>.

If the MT indicates more than two IP addresses of P-CSCF servers or more than two IP addresses of DNS servers, multiple lines of information per <cid> will be returned.

Note: If the MT doesn't have all the IP addresses to be included in a line, e.g. in case the UE received four IP addresses of DNS servers and two IP addresses of P-CSCF servers, the parameter value representing an IP address that can not be populated is set to an empty string or an absent string.

If the parameter <cid> is omitted, the relevant information for all active non secondary PDP contexts is returned.

The test command returns a list of <cid>s associated with active non secondary contexts.

Defined values:

<cid>:integer. Specifies a particular non secondary PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands

(see the +CGDCONT and +CGDSCONT commands).

<bearer_id>:integer. Identifies the bearer, i.e. the EPS bearer in EPS and the NSAPI in UMTS/GPRS.

<apn>: string. A logical name that was used to select the GGSN or the external packet data network.

<local_addr, subnet_mask>: string. shows the IP address and subnet mask of the MT. The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9" for IPv6.

When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<gw_addr>: string. Shows the Gateway Address of the MT. The string is given as dot-separated numeric (0-255) parameters. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<DNS_prim_addr>:string. Shows the IP address of the primary DNS server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<DNS_sec_addr>: string. Shows the IP address of the secondary DNS server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<P_CSCF_prim_addr>: string. Shows the IP address of the primary P-CSCF server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<P_CSCF_sec_addr>: string. Shows the IP address of the secondary P-CSCF server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<IM_CN_Signalling_Flag>: integer. Shows whether the PDP context is for IM CN subsystem-related signalling only or not.

Value	Description
0	PDP context is not for IM CN subsystem-related signalling only
1	PDP context is for IM CN subsystem-related signalling only

Table 195: +IM_CN_Signalling_Flag_Description

<LIPA_indicationg>: integer. indicates that the PDP context provides connectivity using a LIPA PDN connection. This parameter cannot be set by the TE.

Value	Description
0	indication not received that the PDP context provides connectivity using a LIPA PDN connection
1	indication received that the PDP context provides connectivity using a LIPA PDN connection

Table 196: +IM_CN_Signalling_Flag_Description

6.9 +CGEQOS: Define EPS Quality Of Service

Command	Command Type	Response
AT+CGEQOS=[<cid>[, <QCI>[,<DL_GBR>, <UL_GBR>[,<DL_MBR>, <UL_MBR>]]]]	Set	+CEMODE: <err> OK
AT+CGEQOS?	Read	[+CGEQOS:<cid>,<QCI>[,<DL_GBR>,<UL_GBR>], [<DL_MBR>,<UL_MBR>]] [<CR><LF> +CGEQOS: <cid>,<QCI>[,<DL_GBR>,<UL_GBR>], [<DL_MBR>,<UL_MBR>] [...]]
AT+CGEQOS=?	Test	+CGEQOS: (range of supported <cid>s),(list of supported <QCI>s),(list of supported <DL_GBR>s),(list of supported <UL_GBR>s),(list of supported <DL_MBR>s),(list of supported <UL_MBR>s)

Table 197: AT+CGEQOS

Description:

The set command allows the TE to specify the EPS Quality of Service parameters <cid>, <QCI>, [<DL_GBR> and <UL_GBR>] and [<DL_MBR> and <UL_MBR>] for a PDP context or Traffic Flows (see Release-13 3GPP TS 24.301 and 3GPP TS 23.203).

When in UMTS/GPRS the MT applies a mapping function to UMTS/GPRS Quality of Service.

A special form of the set command, +CGEQOS= <cid> causes the values for context number <cid> to become undefined.

The read command returns the current settings for each defined QoS. The test command returns the ranges of the supported parameters.

Defined values:

<cid>:integer. Specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see the +CGDCONT and +CGDSCONT commands).

<cid>:integer. Specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see the +CGDCONT and +CGDSCONT commands).

<QCI>:integer. Specifies a class of EPS QoS (see 3GPP TS 24.301)

Value	Description
0	QCI is selected by network
1 to 4	value range for guaranteed bit rate Traffic Flows
5 to 9	value range for non-guaranteed bit rate Traffic Flows
128 to 254	value range for Operator-specific QCIs

Table 198: +CGEQOS_QCI_Description

<DL_GBR>:integer. indicates DL GBR in case of GBR QCI. The value is in kbit/s.

<UL_GBR>:integer. indicates UL GBR in case of GBR QCI. The value is in kbit/s.

<DL_MBR>:integer. indicates DL MBR in case of GBR QCI. The value is in kbit/s.

<UL_MBR>:integer. indicates UL MBR in case of GBR QCI. The value is in kbit/s.

6.10 +CGPADDR: Show PDP Address(es)

Command	Command Type	Response
AT+CGPADDR[=<cid> [,<cid>[,...]]]	Execute	[+CGPADDR:<cid>[,<PDP_addr_1>[,<PDP_addr_2>]]] [<CR><LF>+CGPADDR:<cid>[,<PDP_addr_1> [,<PDP_addr_2>]] [...]]
AT+CGEQOS=?	Test	+CGPADDR: (list of defined <cid>s)

Table 199: AT+CGPADDR

Description:

The execution command returns a list of PDP addresses for the specified context identifiers. If no <cid> is specified, the addresses for all defined contexts are returned. The test command returns a list of defined <cid>s.

Defined values:

<cid>:integer. Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands).

<PDP_addr_1, PDP_addr_2>: string. Each is a string type that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT and +CGDSCONT commands when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. Both <PDP_addr_1>

and <PDP_addr_2> are omitted if none is available.

Both <PDP_addr_1> and <PDP_addr_2> are included when both IPv4 and IPv6 addresses are assigned, with <PDP_addr_1> containing the IPv4 address and <PDP_addr_2> containing the IPv6 address.

The string is given as dot-separated numeric (0-255) parameter of the form:a1.a2.a3.a4 for IPv4 and a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16 for IPv6.

When +CGPIAF is supported, its settings can influence the format of the IPv6 address in parameter <PDP_addr_1> or <PDP_addr_2> returned with the execute form of +CGPADDR.

7 FILE Related AT Commands

7.1 %FILECMD: AT command to read/write/delete a file

Command	Command Type	Response
AT%FILECMD=<cmd>[, <param1>[,<param2>], <param3>[,<param4>]]]	Set	<p>For "GET" command: %FILECMD: <length>,<crc32></p> <p>For "DIR" command: [%FILECMD:<entry_type>,<entry_name>[, <size>]]<CR><LF> %FILECMD:<entry_type>,<entry_name>[, <size>][...]]</p> <p>For "DINFO" command: %FILECMD: <drive>,<mem_total>,<mem_free>, <mem_used>,<mem_bad>,<ent_total>, <ent_free>,<ent_folder_used>, <ent_file_used>]<CR><LF> %FILECMD:<drive>,...[...]]</p> <p>OK</p> <p>or</p> <p>ERROR</p>
AT%FILECMD?	Read	ERROR (not supported)
AT%FILECMD=?	Test	%FILECMD: (list of supported <cmd>s)
(unsolicited)	(unsolicited)	%FILECMDU:<event>

Table 200: AT%FILECMD

Description:

AT command to read/write/delete a file to/from the module storage. The file will be stored on preconfigured path. Upon execution, the command return OK/ERROR immediately. Command provide opportunity for "out-of-band" binary file transfer, which invokes file transfer protocol (implementation specific) and deliver file between host and the module. Once "out-of-band" file delivery is started, the AT command path is not accessible by the host. Furthermore, the delivery process can not be aborted. The AT command path become available only after completion of file delivery (with success or failure) which is notified by FILECMDU: <event>. The "inband" (using AT%FILEDATA) file transfer is executed chunk-by-chunk. File transfer validity check is in user responsibility. This type of data transfer does not imply URC notification by %FILECMDU. The out-of-band mechanism is not supported for Adrastea-I.

There are additional file validation logic added to AT%FILECMD="PUT" followed by AT%FILEDATA="WRITE":

- If optional <param3> is used in AT%FILECMD="PUT":
Apply check of enough flash space for file download. Return ERROR if no enough memory.
- If both optional <param3> and <param4> are used:
Apply check of enough flash space for file download. AT%FILECMD returns ERROR if no enough memory.
Apply CRC checking at the end of file download by AT%FILEDATA="WRITE". Report success or failure in AT%FILEDATA response.
- If both <param3> and <param4> are omitted:
No memory and CRC check is applied.

Defined values:

<cmd>: string type

Value	Description
"PUT"	Initiate file transfer protocol between host and device and write a file to the device
"GET"	Initiate file transfer protocol between host and device and read a file from the device
"DEL"	Delete a file from the device
"NOTIFY"	Command to enable/disable notification about "out-of-band" file transfer protocol completion.
"COPY"	Copy file between two locations on Altair file system.
"PREERASE"	Apply FLASH erase operations to unused blocks of FFS. Command call is recommended just before file download, file copy or audio file recording to avoid any run-time flash erase operations. Command is blocking.
"RENAME"	Rename file on file system.
"DIR"	Expose drive or folder content.
"DINFO"	Expose drive memory and folder/file content information.

Table 201: %FILEDATA_Cmd_Description

For "PUT":

<param1>: string type. The name of the file (with or without path) to be transferred. The name of the file itself is limited by 29 bytes.

<param2>: integer type. Type of file transfer.

Value	Description
0	"out-of-band" default value.
1	"inband", usage of AT%FILEDATA is expected. Default value, if omitted.

Table 202: %FILEDATA_put_param2_Description

<param3>: integer type. The length of the file to be transferred.

<param4>: string type. Calculated CRC32 value in decimal encoding of the file to be transferred.

For "GET":

<param1>: string type. The name of the file (with or without path) to be retrieved. The name of the file itself is limited by 29 bytes.

<param2>: integer type. Type of file transfer.

Value	Description
0	"out-of-band" default value.
1	"inband", usage of AT%FILEDATA is expected. Default value, if omitted.

Table 203: %FILEDATA_get_param2_Description

For "DEL":

<param1>: string type. The name of the file (with or without path) to be deleted. The name of the file itself is limited by 29 bytes.

For "NOTIFY":

<param1>: integer type.

Value	Description
0	notification disabled (default)
1	notification enabled

Table 204: %FILEDATA_notify_param1_Description

For "COPY":

<param1>: string type. The name of the file (with or without path) to be copied. The name of the file itself is limited by 29 bytes.

<param2>: string type. The name of the file (with or without path) where the file will be copied. The name of the file itself is limited by 29 bytes. If file with specified name already exist, it will be overridden.

<length>:integer type. File length in bytes.

For "PREERASE":

<param1>: string type. Drive name

Value	Description
"b"	
"d"	conditional access

Table 205: %FILEDATA_preerase_param1_Description

For "RENAME":

<param1>: String type. The name of the file (with or without path) to be renamed. The name of the file itself is limited by 29 bytes.

<param2>: String type. the new name of the file (without path) to be assigned. The name of the file itself is limited by 29 bytes. If file with specified name already exist, it will be overridden.

For "DIR":

<param1>: String type. The name of the drive or folder (with path), which content will be reported. Access to drive c: and d: is conditional and depends on operation mode.

Value	Description
"c"	conditional access
"b"	
"d"	conditional access

Table 206: %FILEDATA_dir_param1_Description

For "DINFO":

<param1>: String type. Optional parameter. The name of the drive, which content information will be reported. Drive total entries is a number of folders and files. The total numbers of drive memory and entries depends on the drive and its purpose. If <param1> is omitted information about all drives is reported. Name values: "c"/ "b"/ "d"

<length>: integer type. File length in bytes.

<crc32>: string type. CRC32 value in decimal encoding.

<event>: integer type.

Value	Description
0	File transferred successfully
1	File transfer failure

Table 207: %FILEDATA_dinfo_param1_Description

<entry_type>: integer type. Type of entry contained in specified drive/folder.

Value	Description
0	Folder
1	File

Table 208: %FILEDATA_dinfo_entrytype_Description

<entry_name>: string type. Name of entry contained in specified drive/folder.

<size>: integer type. Optional parameter. Size of file in bytes. Parameter is inapplicable to folders.

<drive>: string type. Drive name:

Value	Description
"c"	
"b"	
"d"	

Table 209: %FILEDATA_dinfo_drive_Description

<mem_total>: integer type. Drive total memory.

<mem_free>: integer type. Drive free memory.

<mem_used>: integer type. Drive used memory.

<mem_bad>: integer type. Drive bad memory.

<ent_total>: integer type. Drive total entries.

<ent_free>: integer type. Drive free entries.

<ent_folder_used>: integer type. Drive entries used for folders.

<ent_folder_used>: integer type. Drive entries used for folders.

<ent_file_used>: integer type. drive entries used for files.

7.2 %FILEDATA: AT command to read/write data from/to the file

Command	Command Type	Response
AT%FILEDATA=<cmd>[,<param1>[,<param2>[,<param3>...]]]	Set	For "READ" command: [%FILEDATA:<more2read>[,<rlength>[,<rdata>]]] For "WRITE" command: [%FILEDATA:<wlength>[,<res>]] OK or ERROR
AT%FILEDATA?	Read	ERROR (not supported)
AT%FILEDATA=?	Test	%FILEDATA: (list of supported <cmd>s)

Table 210: AT%FILEDATA

Description: This command is used for a simple file chunk-by-chunk read/write operation via local interface. Continuous (chunk-by-chunk) read operation, which is interrupted before EOF, requires new mandatory AT%FILECMD="GET" call (even with the same filename) to restart the read process from the beginning of the file.

Defined values:

<cmd>: string type

Value	Description
"WRITE"	Write data to NV
"READ"	Read data from NV

Table 211: %FILEDATA_cmd_Description

For "WRITE":

<param1>: integer type.

Value	Description
0	This is the last "WRITE" transaction
1	More pending "WRITE" transactions

Table 212: %FILEDATA_write_param1_Description

<param2>: integer. Length of transmitted data in ASCII string length units, which is twice longer than transmitted data length in bytes: 2 to 3000

<param3>: hexadecimal. The file chunk data, in HEX format (in quotes)

For "READ":

<param1>: integer. The maximal length of data in bytes which requested to be read in this transaction; the length of data in ASCII string length units, which is twice longer than received data length in bytes: 2 to 3000

<param2>:integer. The offset from the start of reading file. This is actual byte offset. If this parameter is not included in AT request, it implies that the offset may be one of:

- Initial file pointer for the first file read after AT%FILECMD="GET" file selection.
- Next position for continuous read.

<more2read>:integer.

Value	Description
0	No more data to read
1	More data to read

Table 213: %FILEDATA_more2read_Description

<rlength>:integer. The actual received data length in ASCII string length units, which is twice longer than received data length in bytes: 2 to 3000.

<rdata>:hexadecimal. The read data, in HEX format (in quotes).

<wlength>:integer; the actual transmitted data length in ASCII string length units, which is twice longer than transmitted data length in bytes:

- 2 to 3000

<res>:integer type. File writing CRC verification result. Optional parameter, it is omitted if CRC check is not applied:

Value	Description
0	passed the CRC32 checking
1	failed the CRC32 checking

Table 214: %FILEDATA_res_Description

8 SMS Related AT Commands

8.1 +CMGF: Set Message Format

Command	Command Type	Response
AT+CMGF=[<mode>]	Set	OK or +CME ERROR:<err>
AT+CMGF?	Read	+CMGF:<mode>
AT+CMGF=?	Test	+CMGF:(list of supported <index>s)[,(list of supported <mode>s)]

Table 215: AT+CMGF

Description:

Set command tells the TA, which input and output format of messages to use.

<mode> indicates the format of messages used with send, list, read and write commands and unsolicited result codes resulting from received messages.

Defined values:

<mode>: integer. Mode can be either PDU mode or text mode.

Value	Description
0	PDU mode
1	text mode

Table 216: +CMGF_mode_Description

Example:

8.1.1 AT+CMGF: Set Command

The following command set "text mode":

```
AT+CMGF=1
OK
```

The following command set "PDU mode":

```
AT+CMGF=0
OK
```

8.1.2 AT+CMGF: Read Command

Example:

```
AT+CMGF?  
+CMGF: 1  
  
OK
```

8.1.3 AT+CMGF: Test Command

Example:

```
AT+CMGF=?  
+CMGF: (0,1)  
  
OK
```

8.2 +CMGD: Delete Message

Command	Command Type	Response
AT+CMGD=<index>[,<delflag>]	Set	OK or +CME ERROR:<err>
AT+CMGF=?	Test	+CMGD:(list of supported <index>)[,(list of supported <delflag>)]

Table 217: AT+CMGD

Description:

Set command deletes message from preferred message storage <mem1> location <index>. If <delflag> is present and not set to 0 then the ME shall ignore <index> and follow the rules for <delflag> shown below. If deleting fails, final result code +CMS ERROR: <err> is returned.

Test command shows the valid memory locations and optionally the supported values of <delflag>.

Defined values:

<index>: integer.

<delflag>: integer. Indicates multiple message deletion request as follows.



Note: Only the <delflag> 0 and 4 are currently implemented.

Value	Description
0(or omitted)	Default value if not specified. Delete the message specified in <index>.
1	Delete all read messages from preferred message storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched
2	Delete all read messages from preferred message storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched
3	Delete all read messages from preferred message storage, sent and unsent mobile originated messages leaving unread messages untouched.
4	Delete all messages from preferred message storage including unread messages.

Table 218: +CMGD_DelFlag_Description

8.3 +CMGL: List Messages

Command	Command Type	Response
AT+CMGL=<stat>	Set	<p>if text mode (+CMGF=1), command successful and SMS-SUBMITs and/or SMS-DELIVERs: +CMGL:<index>,<stat>,<oa/da>,[<alpha>],[<scts>] [,<tooa/toda>,<length>]<data>[+CMGL:<index>,<stat>,<da/oa>,[<alpha>],[<scts>] [,<tooa/toda>,<length>]<data>[...]]</p> <p>if text mode (+CMGF=1), command successful and SMS-STATUS-REPORTs: +CMGL:<index>,<stat>,<fo>,<mr>,[<ra>],[<tora>], <scts>,<dt>,<st> [+CMGL:<index>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>, <dt>,<st>[...]]</p> <p>if text mode (+CMGF=1), command successful and SMS-COMMANDs: +CMGL:<index>,<stat>,<fo>,<ct>[+CMGL:<index>,<stat>,<fo>,<ct>[...]]</p> <p>if text mode (+CMGF=1), command successful and CBM storage: +CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages> <data>[+CMGL:<index>,<stat>,<sn>,<mid>,<page>,<pages> <data>[...]]</p> <p>otherwise: +CMS ERROR:<err></p>
AT+CMGL=?	Test	+CMGL:(list of supported <stat>)

Table 219: AT+CMGL

Description:

Execution command returns messages with status value <stat> from message storage <mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'. If listing fails, final result code +CMS ERROR: <err> is returned.

Defined values:

<stat>: integer.

Value	Description
0	"REC UNREAD": received unread message (i.e. new message)
1	"REC READ": received read message
2	"STO UNSENT": stored unsent message (only applicable to SMS)
3	"STO SENT": stored sent message (only applicable to SMS)
4	"ALL": all messages (only applicable to +CMGL command)

Table 220: +CMGL_stat_Description

<index>: integer. Value in the range of location numbers supported by the associated memory.

<oa>: string. TP-Originating-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<da>: string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<alpha>: string. Alphanumeric representation of or corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specific, used character set should be the one selected with command Select TE Character Set +CSCS (refer command +CSCS 2.7).

<scts>: string. TP-Service-Centre-Time-Stamp in time-string format.

<toa>: integer. TP-Originating-Address Type-of-Address octet (when first character of is + (IRA 43) default is 145, otherwise default is 129).

<tda>: integer. TP-Destination-Address Type-of-Address octet.

<length>: integer. Value indicating in the text mode (+CMGF=1) the length of the message body in characters, or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).

<data>: TP-User-Data in text mode format.

- if indicates that GSM 7 bit default alphabet is used and indicates that TP-User-Data-Header-Indication is not set:
 - if TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set.
 - if TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number.
- if indicates that 8-bit or UCS2 data coding scheme is used, or indicates that TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.

<pdu>: hexadecimal integer. In the case of SMS: SC address followed by TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

8.4 +CMGR: Read Messages

Command	Command Type	Response
AT+CMGR=<index>	Set	<p>if text mode (+CMGF=1), command successful and SMS-DELIVER: +CMGR:<stat>,<oa>,[<alpha>],<scts>[,<toa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>]<data></p> <p>if text mode (+CMGF=1), command successful and SMS-SUBMIT: +CMGR:<stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dc>,<vp>],<sca>,<tosca>,<length>]<data></p> <p>if text mode (+CMGF=1), command successful and SMS-STATUS-REPORT: +CMGR:<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st></p> <p>if text mode (+CMGF=1), command successful and SMS-COMMAND: +CMGR:<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length>]<cdata>]</p> <p>if text mode (+CMGF=1), command successful and CBM storage: +CMGR:<stat>,<sn>,<mid>,<dc>,<page>,<pages> <data></p> <p>otherwise: +CMS ERROR:<err></p>

Table 221: AT+CMGR

Description:

Set command returns message with location value <index> from message storage <mem1> to the TE. About text mode parameters in italics. If status of the message is 'received unread', status in the storage changes to 'received read'. If reading fails, final result code +CMS ERROR: <err> is returned.

Defined values:

<stat>: integer.

Value	Description
0	"REC UNREAD": received unread message (i.e. new message)
1	"REC READ": received read message
2	"STO UNSENT": stored unsent message (only applicable to SMS)
3	"STO SENT": stored sent message (only applicable to SMS)
4	"ALL": all messages (only applicable to +CMGL command)

Table 222: +CMGR_stat_Description

<index>: integer. Value in the range of location numbers supported by the associated memory.

<oa>: string. TP-Originating-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<da>: string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<alpha>: string. Alphanumeric representation of or corresponding to the entry found in MT phonebook. Used character set should be the one selected with command Select TE Character Set +CSCS (see definition of this command in 2.7).

<scts>: string. TP-Service-Centre-Time-Stamp in time-string format.

<tda>: integer. TP-Destination-Address Type-of-Address octet (when first character of is + <da>(IRA 43) default is 145, otherwise default is 129).

<toa>: integer. TP-Originating-Address Type-of-Address octet.

<length>: integer. Value indicating in the text mode (+CMGF=1) the length of the message body in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).

<data>: TP-User-Data in text mode format.

- if indicates that GSM 7 bit default alphabet is used and indicates that TP-User-Data-Header-Indication is not set:
 - if TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set.
 - if TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number.
- if indicates that 8-bit or UCS2 data coding scheme is used, or indicates that TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.

<pdu>: hexadecimal integer. In the case of SMS: SC address followed by TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

<fo>: integer. Depending on the command or result code. First octet of SMS-DELIVER, SMS-SUBMIT (default 17), SMSSTATUS-REPORT, or SMS-COMMAND (default 2) in integer format.

<pid>: integer. TP-Protocol-Identifier (default 0).

<dc>: integer. Depending on the command or result code. SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme.

<sca>: string. RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by **<tosca>**.

<tosca>: integer. RP SC address Type-of-Address octet.

<vp>: integer or string. Depending on SMS-SUBMIT setting. TP-Validity-Period either in integer format (default 167) or in time-string format.

8.5 +CMGS: Send Message

Command	Command Type	Response
Text mode(+CMGF=1): AT+CMGS=<da>[,<toda>] <CR> <text message is entered> <Ctrl-Z/ESC>	Execute	+CMGS: <mr>[,<scts>] OK If sending fails: +CMS ERROR:<err>
PDU mode(+CMGF=0): AT+CMGS=+CMGS=<length><CR> <PDU is given> <Ctrl-Z/ESC>	Execute	+CMGS: <mr>[,<ackpdu>] OK sending fails: +CMS ERROR:<err>

Table 223: AT+CMGS

Description:

For text mode

Set/Execute command sends message from a TE to the network (SMS-SUBMIT). Message reference value <mr> is returned to the TE on successful message delivery. Optionally (when +CSMS <service> value is 1 and network supports) <scts> is returned. Values can be used to identify message upon unsolicited delivery status report result code. If sending fails in a network or an ME error, final result code +CMS ERROR: <err> is returned. This command should be abortable.

- entered text (TP-Data-Unit) is sent to address <da> and all current settings (refer Set Text Mode Parameters +CSMP 8.12 and Service Centre Address +CSCA 8.10) are used to construct the actual PDU in ME/TA.
- the TA shall send a four character sequence <CR><LF><greater_than><space> (IRA 13, 10, 62, 32) after command line is terminated with <CR>. After that text can be entered from TE to ME/TA.
- the DCD signal shall be in ON state while text is entered.
- the entered text should be formatted as follows:
 - if <dc> (set with +CSMP 8.12) indicates that GSM 7 bit default alphabet is used and <fo> indicates that TP-User-Data-Header-Indication is not set.
 - if TE character set other than "HEX" (refer command Select TE Character Set +CSCS 2.7): ME/TA converts the entered text into the GSM 7 bit default alphabet. back-space can be used to delete last character and carriage returns can be used (previously mentioned four character sequence shall be sent to the TE after every carriage return entered by the user).
 - If TE character set is "HEX", the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into the GSM 7 bit default alphabet

characters. (e.g. 17 (IRA 49 and 55) will be converted to character (GSM 7 bit default alphabet 23)).

- If <dcs> indicates that 8-bit or UCS2 data coding scheme is used or <fo> indicates that TP-User-Data-Header-Indication is set. The entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. two characters 2A (IRA 50 and 65) will be converted to an octet with integer value 42).
- Sending can be cancelled by giving <ESC> character (IRA 27).
- <ctrl-Z> (IRA 26) must be used to indicate the ending of the message body.

For PDU mode

Execution/Set command sends message from a TE to the network (SMS-SUBMIT). Message reference value is returned to the TE on successful message delivery. Optionally (when +CSMS value is 1 and network supports) is returned. Values can be used to identify message upon unsolicited delivery status report result code. If sending fails in a network or an ME error, final result code +CMS ERROR: is returned. This command should be abortable.

- **<length>**:integer. Indicate the number of octets coded in the TP layer data unit to be given (i.e. SMSC address octets are excluded).
- the TA shall send a four character sequence<CR><LF><greater_than><space> (IRA 13, 10, 62, 32) after command line is terminated with <CR>. After that PDU can be given from TE to ME/TA.
- The DCD signal shall be in ON state while PDU is given.
- The PDU shall be hexadecimal format (similarly as specified for <pdu>) and given in one line. ME/TA converts this coding into the actual octets of PDU.
- When the length octet of the SMSC address (given in the PDU) equals zero, the SMSC address set with command Service Centre Address +CSCA is used. In this case the SMSC Type-of-Address octet shall not be present in the PDU, i.e. TPDU starts right after SMSC length octet.
- Sending can be cancelled by giving <ESC> character (IRA 27).
- <ctrl-Z> (IRA 26) must be used to indicate the ending of PDU.

Defined values:

<da>: string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<scts>: string. TP-Service-Centre-Time-Stamp in time-string format.

<toda>: integer. TP-Destination-Address Type-of-Address octet (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129).

<length>: integer. Value indicating in the text mode (+CMGF=1) the length of the message body <data>in characters, or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).

<mr>: integer. TP-Message-Reference.

<ackpdu>: string. RP-User-Data element of RP-ACK PDU, format is same as for in case of SMS, but without SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.

Example:

8.5.1 AT+CMGS: Execute Command

```
AT+CMGS="+882285000016868"  
> Hello world  
OK
```

8.6 +CMGW: Write Message to Memory

Command	Command Type	Response
Text mode(+CMGF=1): AT+CMGW=<oa/da>[,<tooa/toda>[,<stat>]]<CR> <text message is entered> <Ctrl-Z/ESC>	Execute	+CMGW:<index> OK +CMS ERROR:<err>
PDU mode(+CMGF=0): AT+CMGW=<length>[,<stat>]<CR> <PDU is given> <Ctrl-Z/ESC>	Execute	+CMGW:<index> OK +CMS ERROR:<err>

Table 224: AT+CMGW

Description:

Execution command stores message (either SMS-DELIVER or SMS-SUBMIT) to memory storage <mem2>. Memory location <index> of the stored message is returned. By default message status will be set to 'stored unsent', but parameter <stat> allows also other status values to be given. The entering of text is done similarly as specified in command Send Message: +CMGS. If writing fails, final result code +CMS ERROR: <err> is returned.



Note: SMS-COMMANDs and SMS-STATUS-REPORTs can not be stored in text mode.

Defined values:

<stat>: integer.

Value	Description
0	"REC UNREAD": received unread message (i.e. new message)
1	"REC READ": received read message
2	"STO UNSENT": stored unsent message (only applicable to SMs)
3	"STO SENT": stored sent message (only applicable to SMs)
4	"ALL": all messages (only applicable to +CMGL command)

Table 225: +CMGW_stat_Description

<index>: integer. Value in the range of location numbers supported by the associated memory.

<oa>: string. TP-Originating-Address Address-Value field. BCD numbers(or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<da>:string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <toa>.

<toa>: integer. TP-Originating-Address Type-of-Address octet.<toa> (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129).

<length>: integer. Value indicating in the text mode (+CMGF=1) the length of the message body <data> in characters, or in PDU mode (+CMGF=0), the length of the actual TPvdata unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).

8.7 +CMSS: Send SMS from storage

Command	Command Type	Response
+CMSS=<index>[,<da>[,<toda>]]	Execute	Text mode +CMGF=1: +CMSS: <mr>[,<scts>] OK PDU mode +CMGF=0: +CMSS: <mr>[,<ackpdu>] OK +CMS ERROR:<err>

Table 226: AT+CMSS

Description:

Execution command sends message with location value <index> from preferred message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND). If new recipient address <da> is given given for SMS-SUBMIT, it shall be used instead of the one stored with the message. Reference value <mr> is returned to the TE on successful message delivery.

For text mode, optionally (when +CSMS <service> value is 1 and network supports) <scts> is returned.

For PDU mode, optionally (when +CSMS <service> value is 1 and network supports) <ackpdu> is returned. Values can be used to identify message upon unsolicited delivery status report result code. If sending fails in a network or an ME error, final result code +CMS ERROR: <err> is returned. This command should be abortable.

Defined values:

<index>: integer. Value in the range of location numbers supported by the associated memory.

<da>: string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS in 2.7). Type of address given by <toda>.

<scts>: string. TP-Service-Centre-Time-Stamp in time-string format.

<toda>: integer. TP-Destination-Address Type-of-Address octet (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129).

<mr>: integer. TP-Message-Reference.

<ackpdu>: string. RP-User-Data element of RP-ACK PDU. Format is same as for <pdu> in case of SMS, but without SC address field and parameter shall be bounded by double quote characters like a normal string type Parameter.

8.8 +CNMI: SMS Event Reporting Configuration

Command	Command Type	Response
AT+CNMI=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]	Set	OK +CME ERROR:<err>
AT+CNMI?	Read	+CNMI: <mode>,<mt>,<bm>,<ds>,<bfr> OK
AT+CNMI=?	Test	+CNMI: (list of supported <mode>), (list of supported <mt>), (list of supported <bm>), (list of supported <ds>), (list of supported <bfr>)

Table 227: AT+CNMI

Description:

The command registers or unregisters an SMS client.



Only one AT client can be registered as an SMS client. An existing registration must be released before registering a new client.

Defined values:

<mode>: integer. It controls the processing of unsolicited result codes specified within this command.

Value	Description
1	Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE.
2	Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.

Table 228: +CNMI_mode_Description



It is possible that ME/TA result code buffer is in volatile memory. In this case messages may get lost if the power of ME/TA is switched off before codes are sent to TE. Thus, it is not recommended to use direct message routing (<mt>=2 or 3, <bm>=2 or 3, or <ds>=1) with <mode> value 0 or 2.

<mt>: integer. Sets the result code indication routing for SMS-DELIVERs.

Value	Description
0	No SMS-DELIVER indications are routed to the TE.
1	If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI: <mem>,<index>
2	<p>SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group (store message)) are routed directly to the TE using unsolicited result code:</p> <p>+CMT: [<alpha>],<length><CR><LF><pdu> (PDU mode enabled); or+CMT: <oa>, [<alpha>],<scts>[,<toa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<data> (text mode enabled)</p> <p>If ME has its own display device then class 0 messages and messages in the message waiting indication group (discard message) may be copied to both ME display and to TE. In this case, ME shall send the acknowledgement to the network.</p> <p>Class 2 messages and messages in the message waiting indication group (store message) result in indication as defined in <mt>=1.</p>

Table 229: +CNMI_mt_Description

<bm>: integer. Ignored.

<ds>: integer.

Value	Description
0	No SMS-STATUS-REPORTs are routed to the TE.
1	<p>SMS-STATUS-REPORTs are routed to the TE using unsolicited result code:</p> <p>+CDS: <length><pdu> (PDU mode enabled) or</p> <p>+CDS: <fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> (text mode enabled)</p>
2	<p>If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code:</p> <p>+CDSI: <mem>,<index></p>

Table 230: +CNMI_ds_Description

<bfr>: integer.

Value	Description
0	TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1...3 is entered (OK response shall be given before flushing the codes).
1	TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered.

Table 231: +CNMI_bfr_Description

Example:**8.8.1 AT+CNMI: Set Command**

The following command registers as a client for MT SMS and status reports:

```
AT+CNMI=3,2,0,1
```

```
OK
```

8.8.2 AT+CNMI: Read Command**Example:**

```
AT+CNMI?  
+CNMI: 3,2,0,1,1
```

```
OK
```

8.8.3 AT+CNMI: Test Command**Example:**

```
AT+CNMI=?
```

8.9 +CPMS: Preferred SMS message storage

Command	Command Type	Response
AT+CPMS=<mem1>[,<mem2>[,<mem3>]]	Set	+CPMS:<used1>,<total1>,<used2>,<total2>,<used3>,<total3> +CMS ERROR:<err>
AT+CPMS?	Read	+CPMS:<mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> +CMS ERROR:<err>
AT+CPMS=?	Test	+CPMS:(list of supported <mem1>),(list of supported <mem2>),(list of supported <mem3>)

Table 232: AT+CPMS

Description:

Set command selects memory storages <mem1>, <mem2> and <mem3> to be used for reading, writing.



If chosen storage is not appropriate for the ME (but is supported by the TA), final result code +CMS ERROR: <err> shall be returned.

Test command returns lists of memory storages supported by the TA.

Defined values:

<mem1>: string. Memory from which messages are read and deleted (commands List Messages +CMGL, Read Message +CMGR and Delete Message +CMGD).

Value	Description
"BM"	Broadcast message storage
"ME"	ME message storage
"MT"	Any of the storages associated with ME
"SM"	(U)SIM message storage
"TA"	TA message storage
"SR"	Status report storage

Table 233: +CPMS_mem1_Description

<mem2>: string. Memory to which writing and sending operations are made (commands Send Message from Storage +CMSS and Write Message to Memory +CMGW).

Value	Description
"BM"	Broadcast message storage
"ME"	ME message storage
"MT"	Any of the storages associated with ME
"SM"	(U)SIM message storage
"TA"	TA message storage
"SR"	Status report storage

Table 234: +CPMS_mem2_Description

<mem3>: string. Memory to which received SMS are preferred to be stored (unless forwarded directly to TE. refer command New Message Indications +CNMI). Received CBMs are always stored in "BM" (or some manufacturer specific storage) unless directly forwarded to TE. Received status reports are always stored in "SR" (or some manufacturer specific storage) unless directly forwarded to TE.

Value	Description
"BM"	Broadcast message storage
"ME"	ME message storage
"MT"	Any of the storages associated with ME
"SM"	(U)SIM message storage
"TA"	TA message storage
"SR"	Status report storage

Table 235: +CPMS_mem3_Description

<total1>: integer. Total number of message locations in <mem1>.

<total2>: integer. Total number of message locations in <mem2>.

<total3>: integer. Total number of message locations in <mem3>.

<used1>: integer. Number of messages currently in <mem1>.

<used2>: integer. Number of messages currently in <mem2>.

<used2>: integer. Number of messages currently in <mem3>.

8.10 +CSCA: SMS Service Center Address

Command	Command Type	Response
AT+CSCA=<sca>[,<tosca>]	Set	OK or +CMS ERROR:<err>
AT+CSCA?	Read	+CSCA: <sca>,<tosca> OK
AT+CSCA=?	Test	OK +CMS ERROR:<err>

Table 236: AT+CSCA

Description:

Set command updates the SMSC address, through which mobile originated SMS are transmitted. In text mode, setting is used by send and write commands. In PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into <pdu> parameter equals zero.

Defined values:

<sca>: string. RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7), Type of address given by <tosca>.

<tosca>: integer. RP SC address Type-of-Address octet.

8.11 +CSDH: Show SMS text mode parameters

Command	Command Type	Response
AT+CSDH=[<show>]	Set	OK +CMS ERROR:<err>
AT+CSDH?	Read	+CSDH: <show> OK
AT+CSDH=?	Test	+CSDH: (list of supported <show>) OK +CMS ERROR:<err>

Table 237: AT+CSDH

Description:

Set command controls whether detailed header information is shown in text mode result codes ex: <today> or <fo>. Test command returns supported values as a compound value.

Defined values:

<show>: integer.

Value	Description
0	Do not show header values defined in commands +CSCA and +CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dc>) nor <length>, <today> or <tooa> in +CMT, +CMGL, +CMGR result codes for SMSDELIVERs and SMS-SUBMITs in text mode; for SMS-COMMANDs in +CMGR result code, do not show <pid>, <mn>, <da>, <today>, <length> or <cdata>
1	Show the values in result codes

Table 238: +CSDH_show_Description

8.12 +CSMP: Set SMS Text Mode Parameters

Command	Command Type	Response
AT+CSMP=[<fo>[,<vp>[,<pid>[,<dc>]]]]	Set	OK +CMS ERROR:<err>
AT+CSMP?	Read	+CSMP: <fo>,<vp>,<pid>,<dc> OK
AT+CSMP=?	Test	+CSMP: (list of supported <fo>),(list of supported <vp>),(list of supported <pid>),(list of supported <dc>) OK CMS ERROR:<err>

Table 239: AT+CSMP

Description:

Set command is used to select values for additional parameters needed when SMS is sent to the network or placed in a storage when text format message mode is selected. It is possible to set the validity period starting from when the SMS is received by the SMSC (<vp> is in range 0... 255) or define the absolute time of the validity period termination (<vp> is a string). The format of <vp> is given by <fo>. If TA supports the EVPF, it shall be given as a hexadecimal coded string (refer e.g. <pdu>) with double quotes.



NOTE: When storing a SMS-DELIVER from the TE to the preferred memory storage in text mode (refer command Write Message to Memory +CMGW), <vp> field can be used for <scts>.

Defined values: <fo>:integer. Depending on the command or result code: first octet of SMS-DELIVER, SMS-SUBMIT (default 17), SMSSTATUS-REPORT, or SMS-COMMAND (default 2) in integer format.

<pid>: integer. TP-Protocol-Identifier (default 0).

<dc>: integer. Depending on the command or result code: SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme.

<vp>: integer or string. Depending on SMS-SUBMIT <fo> setting. TP-Validity-Period either in integer format (default 167) or in time-string format.

8.13 +CSMS: Select Message Services

Command	Command Type	Response
AT+CSMS=<service>	Set	+CSMS: <mt>,<mo>,<bm> OK +CMS ERROR:<err>
AT+CSMP?	Read	+CSMS: <service>,<mt>,<mo>,<bm> OK
AT+CSMP=?	Test	+CSMS: (list of supported <service>) OK CMS ERROR:<err>

Table 240: AT+CSMS

Description:

Set command selects messaging service <service>. It returns the types of messages supported by the ME. <mt> for mobile terminated messages, <mo> for mobile originated messages and <bm> for broadcast type messages. If chosen service is not supported by the ME (but is supported by the TA), final result code +CMS ERROR: <err> shall be returned. Also read command returns supported message types along the current service setting.

Defined values:

<service>: integer.

Value	Description
0	3GPP Release-13 TS 23.040 (Technical realization of Short Message Service (SMS)) and 3GPP TS 23.041 (Technical realization of Cell Broadcast Service (CBS))
1	3GPP Release 13 TS 23.040 and 3GPP TS 23.041 the requirement of setting 1 is mentioned under corresponding command descriptions.)

Table 241: +CSMS_Service_Description

<mt>, <mo>, <bm>: integer.

Value	Description
0	Type not supported
1	Type supported

Table 242: +CSMS_mt_mo_Description

8.14 %CMGSC: Send Message Large Message

Command	Command Type	Response
if text mode (+CMGF=1): %CMGSC=<da>[,<tda>]<CR> <text is entered> <ctrl-Z/ESC>	Set	if text mode (+CMGF=1) and sending successful: %CMGSC: <mr>[,<mr>...] if sending fails: +CMS ERROR: <err>
AT+CSMP?	Read	+CSMS: <service>,<mt>,<mo>,<bm> OK
AT+CSMP=?	Test	+CSMS: (list of supported <service>) OK CMS ERROR:<err>

Table 243: AT+CSMS

Description: The standard AT+CMGS command returns single message reference index and assumes that concatenation is handled by the host, therefore only small SMS segments are used by the standard AT+CMGS command.

The AT%CMGSC command is the same as AT+CMGS but extended to allow the host:

- To send large SMS to network. In this case concatenation is required and it is fully handled by the modem which fragments the incoming long SMS, sends few sequential SMS fragments and returns the list of message-references, each is a reference of a single SMS fragment.
- To send large message in a small fragments using concatenation User Data Header (UDH) with each fragment. The fragment parameters shall be manually specified in <id>, <index> and <total> optional parameters to be coded by modem into the UDH of the SMS. In this case (params are present in AT call) the SMS cannot be larger then defined in the standard. In this use-case incoming data is not be divided into pieces and only single SMS will be sent and single message-reference will be returned.

If delivery report has been requested by the sender, then it should be received for each SMS fragment if concatenation is handled by modem. Each delivery report confirms reception of single <mr>. The host shall assume reception of SMS by the peer only if it received delivery report for all the <mr> of the SMS. and +CMT in this document.

Defined values:

<da>: string. TP-Destination-Address Address-Value field. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer command +CSCS 2.7). Type of address given by <tda>.

<tda>: integer. TP-Destination-Address Type-of-Address octet (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129).

<mr>: integer. TP-Message-Reference in integer format.

<id>: integer. User Data Header (UDH) concatenated message ID.

<index>: integer. UDH concatenated message index.

<total>: integer. UDH total number of concatenated messages.

9 Socket Related AT commands

9.1 %SOCKETCMD: To Create and Maintain Socket

This command is used to create and maintain a socket by the device.

Command	Command Type	Response
AT%SOCKETCMD=<cmd>[,<param1>[,<param2>[,<param3> ...]]]	Set	For "INFO" command: [%SOCKETCMD:<socket_stat>,<socket_type>,<src_ip>,<dst_ip>,<src_port>,<dst_port>[,<socket_dir>,<socket_to>]] For "SSLINFO" command: [%SOCKETCMD:<SSL_mode>,<ClientCerId>] For "LASTERROR" command: [%SOCKETCMD:<socket_err>] For "ALLOCATE" command: %SOCKETCMD:<socket_id> For "FASTSEND and CONFSEND" command: [%SOCKETCMD:<wlength>] For "SSLKEEP" command: [%SOCKETCMD:<ssl_session_id>] For other commands: OK ERROR
AT%SOCKETCMD?	Read	Returns the list of created sockets and their status: [%SOCKETCMD:<socket_id>,<socket_stat>[%SOCKETCMD:<socket_id>,<socket_stat> [...]]] OK
AT%SOCKETCMD=?	Test	%SOCKETCMD: (list of supported <cmd>)

Table 244: AT%SOCKETCMD

Description:

This command is used to create and maintain a socket by the device.

Number of supported sockets is operators/OEM specific configured. It can be ranged from 1 socket to several ones.

- IPv4 format shall use the format (xxx.xxx.xxx.xxx). Where xxx is a decimal number from 0 to 255. When the leading digits in each segment are 0, the number of digits is adjusted accordingly, and then output. Example: 192.0.2.1, 127.0.0.1, etc.
- IPv6 format (xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx) where x is in hexadecimal notation. Example: 2001:0db8:bd05:01d2:288a:1fc0:0001:10ee
- The unsolicited %SOCKETEV command is automatically enabled when the socket is opened. The command is sent with <event> in two cases:
 - Rx buffer has more Bytes to read.
 - Socket terminated by peer.
- The AT%SOCKETCMD command is blocking. This may cause blocking of the AT channel for a long time in case of an "OPEN" and "LISTEN" command.
- The "CLOSE" command is also blocking and can take time (the socket implementation may take about 8 sec to close the connection due to an internal TCP FIN timer).



The "CLOSE" command may be ordered while data is still inside the module. In such cases, the module activates the "close" process only after it has sent the internally-retained data to its destination. However, the module may still drop the internally-retained data in case of connection loss, and in case of PDN closure.



The local IP address cannot be configured by the AT%SOCKETCMD command (it is assigned by the network).

The local IP port can be configured by the AT%SOCKETCMD command, or it can be set automatically by the socket.

Important Information Related to SSL.

- The network allocated SSL session ID is kept and maintained internally by the device per connection allocated "socket ID" until socket deletion. The SSL session ID is kept even when the socket connection is closed (by "DEACTIVATE" subcommand) to allow reuse of the SSL session on new opened socket connection.
- Upon "ACTIVATE" command, if SSL session ID is allocated by the network, then device will try first to recover the existing SSL session ID. If failed to recover SSL connection, then will open new one. "SSLALLOC" command will delete previously allocated SSL session ID.
- Using "SSLKEEP" subcommand, the SSL session may be kept even when the socket connection is deleted to allow reuse of the SSL session on newly created socket connection. For this purpose the SSL session identifier (<ssl_session_id>) returned by "SSLKEEP" subcommand shall be stored for future use.

- To reuse kept SSL session the "ACTIVATE" sub-command for newly created socket shall use this stored SSL session identifier.



User shall delete kept SSL session by "SSLDEL" subcommand when it is not needed any more to prevent limited resource leakage.



Number of supported SSL sessions is the same as a number of configured sockets.

Defined values:

<cmd>: string.

Value	Description	Param
"ALLOCATE"	Allocates socket session with the following parameters	Param1 - 9
"ACTIVATE"	Activates the predefined socket	Param1 - 2
"INFO"	Returns the details of the specific socket ID	Param1
"DEACTIVATE"	Request to deactivate the specific socket ID and release its resources	Param1 - 2
"FASTSEND"	This command activates the predefined socket, writes to the socket, and then deactivates it	Param1 - 3
"DELETE"	Request to delete specific socket ID allocation	Param1 - 2
"LASTERROR"	Request to get the last Socket error code	Param1
"CONFSEND"	Similar to "FASTSEND" this command activates the predefined socket, writes to the socket and then deactivates it. In addition, this command guarantees that data has been transmitted within pre-defined timeout (command is blocking). If not, command returns ERROR. Starting PRODUCTS-15699.	Param1
"SSLALLOC"	Add SSL for specific socket session id with the following SSL parameters	Param1 - 5
"SSLINFO"	Return the SSL details of specific socket ID	Param1
"SETOPT"	Set Socket options for specific socket ID	Param1 - 4
"SSLKEEP"	Keep SSL session of specific socket ID	Param1
"SSLDEL"	Delete kept SSL session	Param1

Table 245: %SOCKETCMD_cmd_Description

For <cmd> "ALLOCATE": Allocates socket session with the following parameters.
 <param1>: integer.

Value	Description
"Session ID"	a numerical numeric value defined in NP configuration file which point to the PDN on which the socket should be opened. "Session ID" is defined in AT%CGINFO

Table 246: %SOCKETCMD_Param1_Description

<param2>: string.

Value	Description
"TCP"	For creation of TCP socket (TLS mode when security is enabled)
"UDP"	For creation of UDP socket (DTLS mode when security is enabled)

Table 247: %SOCKETCMD_Param2_Description

<param3>: string.

Value	Description
"OPEN"	The socket opens the TCP/UDP connection with the peer.
"LISTEN"	The socket create TCP/UDP listener
"LISTENP"	The socket create TCP/UDP parent listener socket. Once activated, multiple connected sockets could be spawned from it.

Table 248: %SOCKETCMD_Param3_Description

<param4>: string.

Value	Description
"xxx.xxx.xxx.xxx"	Destination IPv4,xxx = 1 - 255.
"https://xxx.xxx.xxx"	URL - Note that for TLS client socket, use URL instead of IP address if the server requires SNI

Table 249: %SOCKETCMD_Param4_Description

<param5>: integer.

Value	Description
1 - 65535	Destination UDP/TCP port number in the range from 1 - 65535

Table 250: %SOCKETCMD_Param5_Description

<param6>: string. Optional.

Value	Description
"1 - 65535"	Source (local) UDP/TCP port number in the range 1 - 65535
"0"	auto port selection by the socket and it is also used as the default value

Table 251: %SOCKETCMD_Param6_Description

<param7>: integer. Optional packet size to be used by the TCP/UDP/IP stack for data sending.

Value	Description
0	Automatically selects default value (MTU based)
1-1500	Packet size in bytes

Table 252: %SOCKETCMD_Param7_Description

<param8>: integer. Optional TCP Connection setup timeout. If timer expires, then command return ERROR.

In case that connection type is "OPEN" the timeout event is: No SYN-ACK reply from the peer.
In case that connection type is "LISTEN" the timeout event is: No SYN request from the peer.

Value	Description
30-360 sec	Default is 60 sec. Parameter is irrelevant for parent listening socket; it will be ignored if present.

Table 253: %SOCKETCMD_Param8_Description

<param9>: integer. Optional IP type used to configure preferred IP type for connection. The IPv4v6 type is default for zero Session ID. Otherwise IP type of selected Session ID is used as default.

Value	Description
0	IPv4v6
1	IPv4
2	IPv6

Table 254: %SOCKETCMD_Param9_Description

For <cmd> "ACTIVATE":, Activates the predefined socket.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 255: %SOCKETCMD_ACTIVATE_Param1_Description

<param2>: integer. The optional SSL session ID, if it was kept by "SSLKEEP" beforehand.

For <cmd> "INFO": Returns the details of the specific socket ID.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 256: %SOCKETCMD_INFO_Param1_Description

For <cmd> "DEACTIVATE": Request to deactivate the specific socket ID and release its resources.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 257: %SOCKETCMD_DEACTIVATE_Param1_Description

<param2>: integer.

Value	Description
0	no need to wait (default)
1	Wait

Table 258: %SOCKETCMD_DEACTIVATE_Param2_Description

For <cmd> "FASTSEND": This command activate the predefined socket, write to the socket and then deactivate it.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 259: %SOCKETCMD_FASTSEND_Param1_Description

<param2>: integer.

Value	Description
1 - 1500	The length in Bytes of the data which needs to be written

Table 260: %SOCKETCMD_FASTSEND_Param2_Description

<param3>: hexadecimal value.

Value	Description
"00"- "FF"	The data, in HEX format (in quotes), which will be written to the specified socket.

Table 261: %SOCKETCMD_FASTSEND_Param3_Description

For <cmd> "DELETE": Request to delete specific socket ID allocation. (including SSL session context if exist)
<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 262: %SOCKETCMD_DELETE_Param1_Description

<param2>: integer.

Value	Description
0	no need to wait (default)
1	Wait

Table 263: %SOCKETCMD_DELETE_Param2_Description

For <cmd> "LASTERROR": Request to get the last Socket error code.
<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 264: %SOCKETCMD_LASTERROR_Param1_Description

For <cmd> "CONFSEND": Similar to "FASTSEND" this command activates the predefined socket, writes to the socket and then deactivates it. In addition, this command guarantees that data has been transmitted within pre-defined timeout (command is blocking). If not, command returns ERROR.
<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 265: %SOCKETCMD_CONFSEND_Param1_Description

<param2>: integer.

Value	Description
10 - 360	timeout in sec

Table 266: %SOCKETCMD_CONFSEND_Param2_Description

<param3>: integer.

Value	Description
1 - 1500	The length in Bytes of the data which need to be written

Table 267: %SOCKETCMD_CONFSEND_Param3_Description

<param4>: hexadecimal value.

Value	Description
"00" - "FF"	The data, in HEX format (in quotes), which will be written to the specified socket.

Table 268: %SOCKETCMD_CONFSEND_Param4_Description

For <cmd> "SSLALLOC": Add SSL for specific socket session id with the following SSL parameters.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 269: %SOCKETCMD_SSLALLOC_Param1_Description

<param2>: integer. SSL mode

Value	Description
0	mutual authentication (default)
1	authenticate client side only
2	authenticate server side only

Table 270: %SOCKETCMD_SSLALLOC_Param2_Description

<param3>: integer. Certificate profile ID pre-settled by AT%CERTCFG. Default zero profile ID may be used for server authentication only and will apply root CAs stored into Root Trusted folder for authentication.

<param4>: integer. Optional cipher suite filtering option to be applied to the default list of supported ciphers for negotiation with server.

Value	Description
0	white list, to leave only selected cipher suites
1	black list, to remove mentioned cipher suites

Table 271: %SOCKETCMD_SSLALLOC_Param4_Description

<param5>: integer. Optional Optional cipher suite list (white or black).



List of cipher suites as per <https://www.iana.org/assignments/tls-parameters/tls-parameters.xhtml> definition. All cipher suites in the list are encoded into single string using hexadecimal cipher suite ID separated by ";", i.e. "C02C;C0AD...C003".

For <cmd> "SSLINFO": Return the SSL details of specific socket ID.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 272: %SOCKETCMD_SSLINFO_Param1_Description

For <cmd> "SETOPT": Set Socket options for specific socket ID.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) of the specified socket

Table 273: %SOCKETCMD_SETOPT_Param1_Description

<param2>: integer.

Value	Description
1 - 36000	TCP/UDP aggregation timer in msec (default: 5000). This timer allows improved data transmission efficiency by aggregating several transmissions to single packet.

Table 274: %SOCKETCMD_SETOPT_Param2_Description

<param3>: integer.

Value	Description
1 - 2048	TCP/UDP TX buffer aggregation size in Bytes (default: 1500). This aggregation allows improved data transmission efficiency by aggregating several transmissions to single packet.

Table 275: %SOCKETCMD_SETOPT_Param3_Description

<param4>: integer.

Value	Description
0 - 300	TCP idle timer in seconds (default: 60). When there is no client/server activity over the predefined time, the socket is deactivated (Socket option TCP_KEEPINTVL)

Table 276: %SOCKETCMD_SETOPT_Param4_Description

For <cmd> "SSLKEEP": Keep SSL session of specific socket ID.

"SSLKEEP" command should be used with OPEN and not LISTEN.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) for which SSL session will be kept over socket deletion.

Table 277: %SOCKETCMD_SSLKEEP_Param1_Description

For <cmd> "SSLDEL": Delete kept SSL session.

"SSLDEL" command return OK means that there's no kept ssl on this session now.

<param1>: integer.

Value	Description
"Session ID"	The SSL session ID (identifier) which SSL session was kept over socket deletion.

Table 278: %SOCKETCMD_SSLDEL_Param1_Description

<socket_id>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) for which SSL session will be kept over socket deletion.

Table 279: %SOCKETCMD_SSLDEL_Param2_Description

<socket_stat>: string.

Value	Description
"DEACTIVATED"	The socket is not active
"ACTIVATED"	The socket is active
"LISTENING"	The socket is listening

Table 280: %SOCKETCMD_SSLDEL_Param3_Description

<socket_type>: string.

Value	Description
"TCP"	For creation of the TCP socket (TLS mode when security is enabled)
"UDP"	For creation of the UDP socket (DTLS mode when security is enabled)

Table 281: %SOCKETCMD_SSLDEL_Param4_Description

<src_ip>: string.

Value	Description
Source IP address	Source IPv4 or IPv6 address

Table 282: %SOCKETCMD_SSLDEL_Param5_Description

<dst_ip>: string.

Value	Description
Destination IP address	Destination IPv4 or IPv6 address

Table 283: %SOCKETCMD_SSLDEL_Param6_Description

<src_port>: string.

Value	Description
"1 - 65535"	Source UDP/TCP port number

Table 284: %SOCKETCMD_SSLDEL_Param8_Description

<dst_port>: string.

Value	Description
"1 - 65535"	Destination UDP/TCP port number

Table 285: %SOCKETCMD_SSLDEL_Param9_Description

<socket_dir>: integer. The direction of the TCP socket.

Value	Description
0	No set
1	Dialer
2	Listener

Table 286: %SOCKETCMD_SSLDEL_Param10_Description

<socket_to>: integer. TCP connection setup timeout as specified in the "OPEN" command.

<socket_err>: integer.

Value	Description
0	No error
1	Out of memory error
2	Invalid value
3	Timeout
4	Input/output error
5	Resource temporarily unavailable
6	Resource busy
7	No such device
8	No data available
9	Address already in use
10	Already connected
11	Not connected
12	Network is unreachable
13	Connection aborted
14	Connection reset
15	Operation in progress
16	Connection closure timeout
255	Internal error

Table 287: %SOCKETCMD_Socket_Error_Description

<ssl_session_id>: integer. The SSL session ID.

<wlength>: integer. The actual length in Bytes of data written to the socket in "FASTSEND" command.

Example:

Below command is to allocate socket session, here Socket id: 1, destination IP Address: 172.127.131.100, destination Port Number: 15583, issue

```
AT%SOCKETCMD="ALLOCATE",1,"UDP","OPEN","172.127.131.100",15583
```

```
OK
```

Response should be like below:

```
%SOCKETCMD:1
```

Below command is to check the socket status with

```
AT%SOCKETCMD?
```

Response should be like below:

```
%SOCKETCMD:1,"DEACTIVATED"
```

Below command is to activate the socket:

```
AT%SOCKETCMD="ACTIVATE",1
```

```
OK
```

9.2 %SOCKETDATA: To send/receive to/from The Socket

Command	Command Type	Response
AT%SOCKETDATA=<cmd> [,<param1>[,<param2> [,<param3>...]]]	Set	For "RECEIVE" command: [%SOCKETDATA:<socket_id>[,<rlength>, <moreData>[,<rdata>[,<src_ip>,<src_port>]]]] OK or ERROR For "SEND" command: [%SOCKETDATA:<socket_id>[,<wlength>]] OK or ERROR
AT%SOCKETDATA?	Read	ERROR (Not Supported)
AT%SOCKETDATA=?	Test	%SOCKETDATA: (list of supported <cmd>)

Table 288: AT%SOCKETDATA

Description:

This command is used to send/receive to/from the socket.

- An operation that returns with ERROR can be evidence that the TCP socket was closed (by the user, the socket idle timer, or the peer). There is unsolicited indication for socket closure by idle timer or by peer.
- The "SEND" command returns "OK" after the actual transmission of the data, but before "ACK" reception from the peer. This can result in TX buffer fill-up which may cause an additional "SEND" command with an ERROR.
- The application can issue AT%SOCKET="LASTERROR" to get the reason for the last failure.

Defined values:

<cmd>: string.

Value	Description	Param
"SEND"	Write to the socket	Param1 - 5
"RECEIVE"	Read from the socket	Param1 - 2

Table 289: %SOCKETDATA_Cmd_Description

For <cmd> "SEND": Write to the socket.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) for which SSL session will be kept over socket deletion.

Table 290: %SOCKETDATA_SEND_Param1_Description

<param2>: integer.

Value	Description
1 - 1500	The length in Bytes of the data which needs to be written.

Table 291: %SOCKETDATA_SEND_Param2_Description

<param3>: hexadecimal. The data, in HEX format (in quotes), which will be written to the specified socket.

<param4>: string. Optional parameter. Applied for UDP datagrams only. Destination IPv4 or IPv6 address.

<param5>: integer. Optional parameter. Applied for UDP datagrams only. Destination port number in the range 1 - 65535.

For <cmd> "RECEIVE": Read from the socket.

<param1>: integer.

Value	Description
"Socket ID"	The socket ID (identifier) for which SSL session will be kept over socket deletion.

Table 292: %SOCKETDATA_RECEIVE_Param1_Description

<param2>: integer.

Value	Description
1 - 1500	The maximal length of the data buffer to be read from the socket.

Table 293: %SOCKETDATA_RECEIVE_Param2_Description



Note1: In UDP mode, RX buffer would only keep NEXT data packet. Use 1500 to receive maximum current data in module RX buffer at once otherwise Module will drop rest of current data.



Note2: In UDP mode, limit maximum data packet to be less than 1500 bytes because of maximum data RX buffer of module is 1500 bytes in case of the host cannot receive complete data.

<socket_id>: integer. The socket ID (identifier) of the specified socket.

<rlength>: integer.

Value	Description
1 - 1500	The actual length in Bytes of the data which was actually read.

Table 294: %SOCKETDATA_RECEIVE_rlength_Description

<moreData>: integer. The length on bytes of the data left in the RX buffer.

<rdata>: hexadecimal value.

Value	Description
"00" - "FF"	The read data in HEX format (in quotes).

Table 295: %SOCKETDATA_RECEIVE_rdata_Description

<wlength>: integer.

Value	Description
1 - 1500	The actual length in Bytes of the data written to the socket.

Table 296: %SOCKETDATA_RECEIVE_wlength_Description

<src_ip>: string. Optional parameter, returned for UDP datagrams only. Source IPv4 or IPv6 address

<src_port>: integer. Optional parameter, returned for UDP datagrams only. Source UDP port number in the range 1 - 65535.

9.3 %MF SOCKETDATA: To send/receive Binary Data



This AT command is not working in Adrastea-I firmware version: ADRASTEAI_06.006. To check the Adrastea-I firmware version refer to +CGMR AT command (2.3). The fix for this issue will be delivered in future along with 3GPP Release-14 firmware upgrade.

Command	Command Type	Response
AT%MF SOCKETDATA= <cmd>,<param1>,<param2>	Set	For "RECEIVE" command: %MF SOCKETDATA:<socket_id>[,<rlength>,<moreData>[,<rdata>[,<src_ip>,<src_port>]]] OK or ERROR For "SEND" command: @<wdata> [%MF SOCKETDATA:<socket_id>,<wlength>] OK or ERROR
AT%MF SOCKETDATA?	Read	ERROR (Not Supported)
AT%MF SOCKETDATA=?	Test	%MF SOCKETDATA: (list of supported <cmd>)

Table 297: AT%MF SOCKETDATA

Description: This command is a binary version used to send/receive binary data to/from the socket, alternative to the AT%SOCKETDATA.

Defined values:

<cmd>: string.

Value	Description
"SEND"	Write to the socket.
"RECEIVE"	Read from the socket.

Table 298: %MF SOCKETDATA_cmd_Description

For "SEND":

<param1>: integer. The socket ID (identifier) of the socket.

<param2>: integer. The length in Bytes of the data which need to be written, range is: 1 to 1500.

<wdata>: After the "@" prompt bytes of data should be entered.

For "RECEIVE":

<socket_id>: integer. The socket ID (identifier) of the specified socket.

<rlength>: integer. The actual length in Bytes of the data which was actually read.

<moreData>: integer. The length on bytes of the data left in the RX buffer.

<rdata>: raw data. The read data, in binary format (in quotes), a byte stream has any kind of characters in the ASCII range [0x00,0xFF].

<wdata>: raw data. The write data, in binary format (in quotes), a byte stream has any kind of characters in the ASCII range [0x00,0xFF].

<wlength>: integer. The actual length in Bytes of data written to the socket.

<src_ip>: string. Optional parameter, returned for UDP datagrams only: Source IPv4 or IPv6 address.

<src_port>: integer. Optional parameter, returned for UDP datagrams only: Source UDP port number in the range 1-65535.

9.4 %SOCKETEV: Notify About Socket Events

Command	Command Type	Response
AT%SOCKETEV= <event_id>,<mode>	Set	OK or ERROR
AT%SOCKETEV?	Read	ERROR (Not Supported)
AT%SOCKETEV=?	Test	%SOCKETEV: (list of supported <event_id>) , (list of supported <mode>)
Unsolicited	Unsolicited	AT%SOCKETEV: :<event_id>,<socket_id> [,<connected_socket_id>]

Table 299: AT%SOCKETEV

Description:

This command is used to notify about socket events. The reporting may be enabled/disabled per event type.



The unsolicited %SOCKETEV command is automatically enabled for all event types when the socket is opened using the "OPEN" or "LISTEN" sub-commands of the AT%SOCKETCMD command.

The unsolicited is sent in the following four cases:

- Rx buffer has more Bytes to read
- socket termination due to Idle timer expiration
- Socket terminated by peer.
- New connected socket is accepted/spawned from the listening socket.



There are two types of listener sockets: "synchronous" and "asynchronous". The user must wait for URC, which may occur at any time (or never) for asynchronous sockets. An Asynchronous listening socket is also called a Parent listening socket. Parent listening sockets, and connected sockets that are spawned from it, will have different IDs.



The %SOCKETEV=4 command unsolicited response will be used to notify "accept incoming connection" after activating the parent listening socket. This URC provides both listening and spawned from its connected sockets IDs.

Defined values:

<event_id>: integer.

Value	Description
0	All events, used only in execution command
1	Rx buffer has more Bytes to read
2	Socket deactivate due to idle timer expiry
3	Socket terminated by peer
4	New connected socket is accepted/spawned from parent listening socket

Table 300: %SOCKETEV_Event_Id_Description

<mode>: integer.

Value	Description
0	Disabled unsolicited result response presentation
1	Enabled unsolicited result response presentation

Table 301: %SOCKETEV_mode_Description

<socket_id>: integer. The socket ID (identifier) of the socket (parent for async).

<connected_socket_id>: integer. The socket ID (identifier) of the connected socket spawned from the specified parent listening socket.

10 HTTP/HTTPS Related AT commands

10.1 %HTTPCFG: To Configure HTTP Connection Parameters

AT command to configure HTTP connection parameters. To start new HTTP connection the "NODES" parameters shall be defined at least.

Command	Command Type	Response
AT%HTTPCFG=<obj>,<profile_id>[, [<param1>][,<param2>]...]	Set	OK or ERROR
AT%HTTPCFG?	Read	ERROR
AT%HTTPCFG=?	Test	%HTTPCFG: (list of supported <cmd>), (list of supported <profile_id>)

Table 302: AT%HTTPCFG

Description:

AT command to configure HTTP connection parameters. To start new HTTP connection the "NODES" parameters shall be defined at least.

Other configurations may be omitted, default settings are used.

- If "TLS" layer is not configured, unsecured connection will be established by default. It will be considered as misconfiguration if "NODES" URL requires security (https), but "TLS" layer is not configured. Any data access via AT%HTTPCMD/READ/SEND will be rejected for such misconfiguration.
- If "IP" layer is not configured, default PDN will be used.
- If "TIMEOUT" parameters are not configured, default parameters will be selected.



To make this omission confidentially working, it is strictly recommended to call "CLEAR" sub-command before entering new configuration for previously used <profile_id>. Profile ID parameter is introduced to handle multiple pre-defined HTTP configuration settings. The unique ID for multi-profile configuration is assigned by user and then used for all following profile configurations via same AT%HTTPCFG, for data transfer and other operations (AT%HTTPSEND, AT%HTTPCMD) and for events (AT%HTTPEV%HTTPEVU).

Default "FORMAT" configuration is:

- Text or pseudo-text raw data transfer.

- Automatic HTTP header generation in AT request (AT%HTTPCMD/SEND).
- The AT response HTTP header is present in response to observe errors (AT%HTTPREAD).



This default configuration may be overridden by explicit "FORMAT" settings and will be applied to any data transfer via same <profile_id>. Some AT response format parameters for specific "GET" operation may be also overridden in AT%HTTPCMD="GET" itself.

Defined values:

<obj>: string.

Value	Description
"NODES"	Configure client & server nodes parameters
"TLS"	Configure TLS layer security parameters
"IP"	Configure IP layer parameters
"FORMAT"	Configure HTTP data/header representation
"TIMEOUT"	Configure timeouts: server and host (switch)
"CLEAR"	Clear all previous configuration settings for specified <profile_id>
"ABORT"	Clear all unread data from incoming buffer for specified <profile_id>

Table 303: %HTTPCFG_Obj_Description

<profile_id>: integer. Default or previously assigned <profile_id>

- 1 - 5: multi-profile mode.

For "NODES":

<param1>: string. URL or IP address.

<param2>: string. Optional authentication user identification string for HTTP.

<param3>: string. Optional authentication password for HTTP.

For "TLS":

<param1>: string. TLS authentication mode.

- 0: mutual authentication (default)
- 1: authenticate client side only
- 2: authenticate server side only

<param2>: integer. TLS predefined authentication context (profile) previously configured by AT%CERTCFG.

For "IP":

<param1>: integer. Session ID numeric PDN identification defined in APN table for specified PDN. If omitted default data PDN is used unless configured differently by AT-SETROUTE.

<param2>: integer. Optional IP type used to configure preferred IP type for connection.

- 0: IPv4v6
- 1: IPv4
- 2: IPv6 (default)

<param3>: integer. Optional destination (server) TCP port number. If omitted default HTTP port number is used, starting PRODUCTS-19261.

- 1 - 65535

<param4>: integer. Optional source (local) TCP port number. If omitted default HTTP port number is used.

- 1 - 65535

For "FORMAT":

<param1>: integer. Data transfer technique.

- 0: Data text mode (default value)
- 1: Data PDU (ASCII encoded hex) mode

<param2>: integer. AT response header presence as part of <data> parameter in AT%HTTPREAD.

- 0: disable
- 1: enable (default value)

<param3>: integer. AT request header presence as a part of <data> parameter in AT%HTTPSEND. If feature is enabled, all HTTP header override parameters in AT%HTTPSEND are irrelevant and ignored.

- 0: disable
- 1: enable (default value)

For "TIMEOUT":

<param1>: integer. Server response timeout. The default value is 120 sec (2 min). If server response is not arrived during this time, server timeout error will be reported via URC. Unit: seconds.

- 1 - 65535

10.2 %HTTPCMD: To Communicate With HTTP Server

Command	Command Type	Response
AT%HTTPCMD=<cmd>,<profile_id>,[<uri>][,<param1>,...]	Set	OK or ERROR
AT%HTTPCMD?	Read	ERROR
AT%HTTPCMD=?	Test	%HTTPCFG: (list of supported <cmd>), (list of supported <profile_id>)

Table 304: AT%HTTPCMD

Description:

This is AT command to communicate with HTTP server.

All sub commands are unblocking.

The information about command success or fail will be provided in %HTTPEVU URC.

Defined values:

<cmd>: string.

Value	Description
"GET"	Trigger HTTP GET
"DELETE"	Trigger HTTP DELETE

Table 305: %HTTPCMD_Cmd_Description

<profile_id>: integer. Previously assigned <profile_id>.

- 1 - 5: multi-profile mode.

<uri>: string. Optional resource (URI) or requested object. If omitted the default IP/URI defined in AT%HTTPCFG will be used.

For "GET":

<param1>: integer. Optional parameter. Override the format/technique of downloaded data transfer via AT%HTTPREAD (default or as defined by AT%HTTPCFG="FORMAT").

- 0: Data text mode (default value)
- 1: Data PDU (ASCII encoded hex) mode

<param2>: integer. Optional parameter. Override response header presence in AT%HTTPREAD <data> parameter (default or as defined by AT%HTTPCFG="FORMAT").

- 0: disable
- 1: enable (default value)

<param3> - <paramN>: string. Optional HTTP extra header line. Number of extended headers is limited only by overall AT command buffer size of 3KB.

10.3 %HTTPSEND: Sending Data To The Server

Command	Command Type	Response
AT%HTTPSEND= HTTPSEND=<cmd>,<profile_id> [<data_len>],[<uri>],[<param1>...] <data>	Set	OK or ERROR
AT%HTTPSEND?	Read	[%HTTPSEND: <profile_id>,<busy_len>, <free_len>[%HTTPSEND: <profile_id>, <busy_len>,<free_len>...]]
AT%HTTPSEND=?	Test	%HTTPSEND: (list of supported <cmd>),(list of supported <profile_id>)

Table 306: AT%HTTPSEND

Description:

AT command performs a POST or PUT request to HTTP server and triggers sending data to the server.



The <data_len> parameter may be omitted in human debug mode of AT usage. In this use-case data end shall be signaled by Ctrl+Z pressing.

The information about command success or fail will be provided in %HTTPEVU URC.

Defined values:

<cmd>: string.

Value	Description
"PUT"	Trigger HTTP PUT
"POST"	Trigger HTTP POST

Table 307: %HTTPSEND_Cmd_Description

<profile_id>: integer. Previously assigned <profile_id>.

- 1 - 5: multi-profile mode.

<data_len>: integer. Actual data size in bytes to send.

- 1 - 3000 in Data text mode.
- 1 - 1500 in Data PDU (hex) mode

<uri>: string. Optional resource (URI) or requested object.
If omitted the default IP/URL defined in AT%HTTPCFG will be used.

For <param3>=0 of AT%HTTPCFG="FORMAT":

<data> does not contain HTTP header.

<param1>: string. Optional HTTP Content Type identifier. This parameter may be omitted, if default text/plain content is transferred.

For <param3>=1 of AT%HTTPCFG="FORMAT":

HTTP header is part of <data> content.

<param1>: string. Optional HTTP security definition. This parameter indicates the security level for this specific data transfer.

- "http"
- "https"

<param2>: integer. Optional parameter. More pending data indication, which is waiting to be sent using the same POST/PUT sub-command.

- 0: This is the last POST/PUT chunk (default value)
- 1: and more - Size of more pending data to send within the next POST/PUT

<param3>: integer. Optional parameter. Override the format/technique of uploaded data transfer (default or as defined by AT%HTTPCFG="FORMAT")

- 0: Data text mode (default value)
- 1: Data PDU (ASCII encoded hex) mode

<param4> - <paramN>: string. Optional HTTP extra header line. Number of extended headers is limited only by overall AT command buffer size of 3KB. If this AT is used with an essential number of extended headers, the size of <data> shall be decreased in such a way that overall AT string will not exceed 3KB.

<data>: HTTP plain payload without quotes.

10.4 %HTTPREAD: To Read The Body Of HTTP Response

Command	Command Type	Response
AT%HTTPREAD= <profile_id>[,<max_len>]	Set	%HTTPREAD: <data_len> ,<rcv_len> <data> OK or ERROR
AT%HTTPREAD?	Read	[%HTTPREAD: <profile_id>,<rcv_len>[%HTTPREAD: <profile_id>,<rcv_len>[...]]]
AT%HTTPREAD=?	Test	%HTTPREAD: list of supported <profile_id>)

Table 308: AT%HTTPREAD

Description:

AT command is used to read the body of HTTP response. Once URC %HTTPPEV informs about some operation confirmation or data received, this AT can be used to retrieve data provided by server.

If <max_len> is omitted or set to 0, whole server data will be transferred.

If <max_len> is less than actual <data_len>, the message will be truncated. The <rcv_len> different from <data_len> in AT command response indicates that message was truncated. If the data is not present for specified <profile_id>, command returns ERROR. Only single packet is stored internally per Profile ID. If it will not be retrieved by user after "GETRCV" URC arrival, next incoming HTTP packet will override previous one.

Use "Content length" (if present) provided in first "GETRCV" URC arrived after AT%HTTPCMD="GET" operation to estimate HTTP GET response size.

Defined values:

<profile_id>: integer. Previously assigned <profile_id>.

- 1 - 5: multi-profile mode.

<max_len>: integer. Max number of bytes of host allocated buffer to read.

- 1 - 3000 in Data text mode.
- 1 - 1500 in Data PDU (hex) mode

<data_len>: integer. Data size in bytes returned by AT.

It could be shorter than actual received data if was truncated by buffer size:

- 1 - 3000 in Data text mode.
- 1 - 1500 in Data PDU (hex) mode

<rcv_len>: integer. Actual data size in bytes received from server and present in the RX buffer.

<data>: HTTP plain payload without quotes.

10.5 %HTTPFOTAGET: To perform FOTA Procedure via HTTP/HTTPS.

Command	Command Type	Response
AT%HTTPFOTAGET=<profile_id>[,<uri>] [,<param1>][,<parma2>]	Set	OK or ERROR
AT%HTTPFOTAGET?	Read	<size_of_downloaded_fota_pk>B OK
AT%HTTPFOTAGET=?	Test	<profile_id>[,<uri>] OK

Table 309: AT%HTTPFOTAGET

Description:

AT command is used to perform FOTA procedure via HTTP/HTTPS.

Once received the URC %HTTPEVU:"FOTADLRES",<profile_id>,0, perform ATZ to reboot Adrastea-I and starting firmware upgrade.

Read command returns the current size of downloaded fota package.



Note: During firmware upgrade, AT com port would not have any response, until module responses the URC %SCMNOTIFYEV:"Adrastea-I Ready" then starting to use AT commands.

Defined values:

<profile_id>: integer. Previously assigned <profile_id>.

- 1 - 4: multi-profile mode.

<uri>: string. Optional resource (URI) or requested object.



If omitted the default IP/URL defined in AT%HTTPCFG will be used. When use the external header, the URL should reserve.

<param1>: string. Optional authorization header. It can omit if no necessary.

<param2>: string. Optional x-ue-token header.

<size_of_downloaded_fota_pk>: integer. The current size of downloaded fota package.

10.6 %HTTPEV: To Notify About HTTP Events.

Command	Command Type	Response
AT%HTTPEV=<ev_type>,<mode>	Set	OK or ERROR
AT%HTTPEV?	Read	ERROR
AT%HTTPEV=?	Test	%HTTPEV: (list of supported <ev_type>),(list of supported <mode>)
unsolicited	unsolicited	%HTTPEVU:<ev_type>,<profile_id>,<state>[,<res1>[,<res2>,...]]

Table 310: AT%HTTPEV

Description:

The command is intended to notify about HTTP events. Default HTTP mode is URC disabled for all event types. Most of the events are related to asynchronous operation triggered by AT%HTTPCMD/HTTPSEND. Such acknowledgement may be normally disabled. Only "GETRCV" event provides notification about data received from the server.



Note: If TCP session is disconnected because of link lost, no URC is sent.

Defined values:

<ev_type>: string.

Value	Description
"PUTCONF"	PUT procedure confirmation status
"POSTCONF"	POST procedure confirmation status
"DELCONF"	Delete procedure confirmation status
"GETRCV"	GET procedure data arrival event
"SESTERM"	Session terminated remotely or locally
"ALL"	All events, used only in execution command

Table 311: %HTTPEV_EV_Type_Description

<mode>: integer. Status of unsolicited result response presentation.

- 0: Disabled.
- 1: Enabled

<profile_id>: integer. Previously assigned <profile_id>.

- 1 - 5

<state>: integer. result code.

- 0: success, relevant for "xxxCONF"/"GETRCV".
- 1: GET/POST/PUT/DELETE transaction failure, relevant for "xxxCONF"/"GETRCV".
- 2: Session terminated by server, relevant for "SESTERM".
- 3: Session terminated locally due to buffer overflow caused by the delay in reading of received data. Relevant for "SESTERM".
- 4: Session terminated locally due to timeout waiting for the respond to be received. Relevant for "SESTERM".
- 5: Session terminated locally due to TLS authentication failure. Relevant for "SESTERM".

<res1>: integer type; optional status or error code:

For <state>=0,1 (HTTP protocol success or error status):

HTTP status code as defined in RFC 7231, sec.8.2.3

For <state>=3 (HTTP client local error):

- 1: Wrong parameter like value out of range
- 2: Buffer allocation fail
- 3: Failed to create socket
- 4: Failed to convert the IP address
- 6: Failed to send message
- 7: Failed to receive message
- 8: URL translation error or certification files not exist on path
- 10: DNS client could not retrieve IP address from DNS server
- 11: HTTP header version not supported by http client
- 12: HTTP header not include the length of file download

For <state>=5 (TLS error):

- 255: Other TLS errors
- 256: An invalid SSL record was received.
- 257: The server has no ciphersuites in common with the client.
- 258: No client certification received from the client, but required by the authentication mode.

- 259: The own certificate is not set, but needed by the server.
- 260: No CA Chain is set, but required to operate. 261 - A fatal alert message was received from our peer.
- 261: A fatal alert message was received from our peer
- 262: Verification of our peer failed.

<res2>: string type; optional error reason.

For "GETRCV", successful use-case(<state>=0):

<res1>: integer type; actual data size in bytes received from server until now. More data may be received before data retrieval by AT%HTTPREAD. Length depends on read mode (with or without header).

<res2>: integer type; optional "Content length" from HTTP header, if present.

10.7 HTTP Example

Below sequence of AT commands is an example to POST data on http server:

- Enable HTTP service events:

```
AT%HTTPEV="ALL",1
```

```
OK
```

- Clear existing http configurations:

```
AT%HTTPCFG="CLEAR",1
```

```
OK
```

- Configure node connection:

```
AT%HTTPCFG="NODES",1,"http://ptsv3.com/t/adrastea/"
```

```
OK
```



Note: url <http://ptsv3.com/t/adrastea/> was created for test purposes, you should choose your own http server and configure it here

- Configure automatically created header (FORMAT, <parameter 3> = 0):

```
AT%HTTPCFG="FORMAT",1,0,1,0  
OK
```

- POST message without header (only payload):

```
AT%HTTPSEND="POST",1,53  
{"message": "Here_is_some_json_i_posted", "code": 42}  
  
OK
```

- Observe POST confirmation URC:

```
%HTTPEVU:"POSTCONF",1,0,200
```

- Validate posted data:

```
AT%HTTPREAD=1
```

11 GNSS Related AT Commands



GNSS cannot co-exist with LTE data transfer. LTE communication has higher priority over GNSS and, therefore, GNSS is automatically shut down once LTE is active(if it were active). While LTE is active, GNSS cannot be activated and all GNSS AT commands are responded with error.

11.1 AT%IGNSSACT: Activate GNSS Functionality

Activate GNSS functionality.

Command	Command Type	Response
AT%IGNSSACT=<mode>[,<param1>]	Set	OK or ERROR
AT%IGNSSACT?	Read	%IGNSSACT: <active_mode>
AT%IGNSSACT=?	Test	%IGNSSACT: (list of supported <mode>),(range of supported <delay>)

Table 312: AT%IGNSSACT

Description:

Activate GNSS hardware functionality.

Defined values:

<mode>: integer.

Value	Description
0	Stop GNSS.
1	Start GNSS - default mode is periodic infinite recurrence with 1sec interval. Returns OK, if LTE RF usage is currently allowed and ERROR if LTE RF usage is not allowed.
2	Start GNSS with tolerance delay. Same as start, but returns OK even if LTE RF usage is not currently allowed and tries to start GNSS within tolerance delay provided by user.

Table 313: IGNSSACT_Mode_Description

For <cmd>=1 (Start):

<param1>: integer. Optional activation mode.

Value	Description
1	Cold start
2	Hot start (default)

Table 314: IGNSSACT_Cmd_Start

For <cmd>=2 (Delayed Start):

<tolerance>: integer. Tolerance delay in seconds.

Value	Description
0 - 99999	Tolerance delay in second.

Table 315: IGNSSACT_Tolerance_Description

<active_mode>: integer.

Value	Description
0	GNSS is not active.
1	GNSS is active.

Table 316: IGNSSACT_Active_Mode_Description

Example:

Below command is used for cold GNSS start.

```
AT%IGNSSACT=1,1
```

```
OK
```

Below command is used for hot GNSS Start.

```
AT%IGNSSACT=1,2
```

```
OK
```

Below AT Command is used to stop GNSS Functionality:

```
AT%IGNSSACT=0
```

```
OK
```

11.2 AT%IGNSSCFG: Set and Get GNSS run-time mode configuration.

Command	Command Type	Response
AT%IGNSSCFG= <operation>, <category> [,<param1>[,<param2>...]]	Set	For "GET": [AT%IGNSSCFG: <param1>[,<param2>...]] OK
AT%IGNSSCFG?	Read	ERROR
AT%IGNSSCFG=?	Test	%IGNSSCFG: (list of supported <operation>s),(list of supported <category>s),(list of supported <type>s)

Table 317: AT%IGNSSCFG

Description:

Set and Get GNSS run-time mode configuration.

Defined values:

<operation>: string.

Value	Description
"SET"	set the <category> configuration. If this command is used when GNSS is active, new settings will be applied only after GNSS deactivation. The SET command is not persistent, i.e. configurations are lost after power-cycle. This run-time setting overrides the configuration file static setting and/or default SW functionality.
"GET"	get the <category> configuration.

Table 318: IGNSSCFG_Operation_Description

<category>: string.

Value	Description
"SAT"	satellite systems used in the calculation.
"NMEA"	enabled NMEA sentences.

Table 319: IGNSSCFG_Category_Description

<param1>: string.

For "SAT": Satellite System Types.

Value	Description
"GPS"	GPS system(default)
"GLONASS"	GLONASS system.

Table 320: IGNSSCFG_SAT_Description

For "NMEA": NMEA sentence types.

Value	Description
"GGA"	Global Positioning System Fix Data
"GLL"	Geographic Position (Latitude/Longitude)
"GSA"	GNSS DOP and Active Satellites
"GSV"	GNSS Satellites in View
"GNS"	GNSS Fix Data
"RMC"	Recommended Minimum Specific GNSS Data
"VTG"	Course Over Ground and Ground Speed
"ZDA"	Time and Date
"GST"	GPS Pseudo range Noise Statistics

Table 321: IGNSSCFG_NMEA_Description

Example:

Below AT Command is used to configure GPS and GLONASS satellite systems:

```
AT%IGNSSCFG="SET","SAT","GPS","GLONASS"
```

```
OK
```

Below AT Command is used to enable NMEA sentences:

```
AT%IGNSSCFG="SET","NMEA","GGA","GSA","GSV","GNS","RMC"
```

```
OK
```


11.3 AT%IGNSSINFO: Query GNSS Information

Command	Command Type	Response
AT%IGNSSINFO=<type>	Set	For "SAT": %IGNSSINFO: <num_of_sat> [%IGNSSINFO:<PRN>,<elevation>,<azimuth>,<SNR>] [..] For "FIX" and "LASTFIX": %IGNSSINFO:<fix_type>,<time>,<date>,<latitude>,<longitude>,<altitude>,<utc>[,<accuracy>[,<speed>],<eph_type> For "TTFF" : %IGNSSINFO: <ttff> For "EPH": %IGNSSINFO: <eph_status> OK
AT%IGNSSINFO?	Read	ERROR
AT%IGNSSINFO=?	Test	%IGNSSINFO: (list of supported <type>s)

Table 322: AT%IGNSSINFO

Description:

Query GNSS Information.

Defined values:

<type>: string.

Value	Description
"SAT"	returns log of satellite in view.
"FIX"	returns information of current location acquired by the device.
"TTFF"	returns the Time-To-First-Fix of the most recent GNSS activation.
"EPH"	indicates if the last stored Ephemeris is valid or not.
"LASTFIX"	returns the last location on the last fix. Used when fix cannot be obtained and the last location is needed.

Table 323: IGNSSINFO_Type_Description

<num_of_sat>: integer. Number of satellites in view.

<PRN>: integer. Pseudo-random noise code of the satellite.

Value	Description
1-37	GPS system(default)
38-61	GLONASS system.

Table 324: IGNSSINFO_PRN_Description

<elevation>: integer. Satellite elevation.

Value
0 - 90

Table 325: IGNSSINFO_Elevation_Mode_Description

<azimuth>: integer. Satellite azimuth.

Value
0 - 360

Table 326: IGNSSINFO_Azimuth_Mode_Description

<SNR>: integer. Signal strength of the satellite.

Value	Description
0-10	No signal
11-15	Very low signal
16-25	Low signal
26-40	Good signal
>40	Excellent signal

Table 327: IGNSSINFO_SNR_Description

<fix_type>: integer.

Value	Description
0	No FIX
1	MSA
2	MSB

Table 328: IGNSSINFO_Fix_Type_Description

<time>: string. Last fix time, in format hh:mm:ss.

<date>: string. Last fix date, in format dd/mm/yyyy.

<latitude>: string. Which contains floating value, value is omitted if unknown. Latitude as defined and returned by NMEA command GGA. Positive values represent "North", negative values represent "South".

<longitude>: string. Which contains floating value, value is omitted if unknown. Longitude as defined and returned by NMEA command GGA. Positive values represent "East", negative values represent "West".

<altitude>: string. Which contains floating value, value is omitted if unknown. Altitude as defined and returned by NMEA command GGA.

<utc>: integer. The UTC timestamp of the position.

<accuracy>: integer. Radius accuracy in meters.

<speed>: string. Which contains floating value, speed in m/sec.

<tfff>: string. Which contains floating value, time to the first fix of the most recent GNSS activation (in milliseconds).

<eph_type>: string.

Value	Description
"B"	BEP ephemeris
"C"	CEP ephemeris

Table 329: IGNSSINFO_EPH_Type_Description

<eph_status>: integer.

Value	Description
0	Last stored ephemeris is not valid.
1	Last stored ephemeris is valid.

Table 330: IGNSSINFO_EPH_Status_Description

Example:

Get satellites available:

```
AT%IGNSSINFO="SAT"  
%IGNSSINFO: 11  
%IGNSSINFO:03,36,294,49  
%IGNSSINFO:06,53,263,50  
%IGNSSINFO:14,42,180,50  
%IGNSSINFO:15,13,042,50  
%IGNSSINFO:16,08,251,50  
%IGNSSINFO:18,56,044,50  
%IGNSSINFO:19,25,314,50  
%IGNSSINFO:21,46,104,51  
%IGNSSINFO:22,71,306,49  
%IGNSSINFO:24,14,080,49  
%IGNSSINFO:27,51,282,50
```

Below command is used to get the fix:

```
AT%IGNSSINFO="FIX"  
  
%IGNSSINFO: 2,"11:17:02","04/05/2020","32.195970","34.892572","-10.500000"  
      ,1588580222000,1,"0.000000","B"
```

11.4 AT%IGNSSEV: Enable GNSS Unsolicited Notification Events

Command	Command Type	Response
AT%IGNSSEV=<event>,<mode>	Set	OK ERROR
AT%IGNSSEV?	Read	%IGNSSEV: <event>,<mode>[,<event>,<mode>...]
AT%IGNSSEV=?	Test	%IGNSSEV: (list of supported <event>),(list of supported <mode>)
unsolicited	unsolicited	%IGNSSEVU: <event>,<event body>

Table 331: AT%IGNSSEV

Description:

Enable GNSS unsolicited notification events.

The unsolicited command is used to deliver information from GNSS to the application.

Defined values:

<event>: string.

Value	Description
"NMEA"	NMEA sentence report.
"SESSIONSTAT"	Status event reported upon GNSS session status change.
"ALLOWSTAT"	Status event reported upon GNSS allowed status change.

Table 332: IGNSSEV_Event_Description

<mode>: integer.

Value	Description
0	Disable <event>
1	Enable <event>

Table 333: IGNSSEV_Mode_Description

<event body>, for **"NMEA"**: string. The event body is of string type representing the NMEA sentence (using quote before and after the sentence).

For **<event body>**, for **"SESSIONSTAT"**: integer. The event body is of integer type as following.

Value	Description
0	NONE (GNSS status unknown)
1	SESSION_BEGIN (GNSS started)
2	SESSION_END (GNSS stopped)

Table 334: IGNSSEV_SESSIONSTAT_Description

For **<event body>** for **"ALLOWSTAT"**: integer. The event body is of integer type as following.

Value	Description
0	GNSS is not allowed.
1	GNSS is allowed.
2	GNSS started automatically, when auto-restart is enabled in the configuration file or when GNSS starts working in delay when tolerance is given.

Table 335: IGNSSEV_ALLOWSTAT_Description

11.5 AT%IGNSSMEM: To Delete specific data from the GNSS storage.

Allows the host to delete specific data from the GNSS storage.

Command	Command Type	Response
AT%IGNSSMEM=<op>,<bitmask>	Set	OK ERROR
AT%IGNSSMEM?	Read	ERROR
AT%IGNSSMEM=?	Test	%IGNSSMEM: (list of supported <op>),(range of supported <bitmask>)

Table 336: AT%IGNSSMEM

Description:

Allows the host to delete specific data from the GNSS storage.

Defined values:

<op>: string.

Value	Description
"ERASE"	ERASE data from GNSS storage.

Table 337: IGNSSMEM_Op_Description

<bitmask>: hex. The data which is required to be deleted. Bitmask can contain any combination of the bits reflected below.

Value	Description
"0"	DELETE_ALL , No support
"0001"	EPHEMERIS
"0002"	ALMANAC
"0004"	POSITION
"0008"	TIME
"10000"	TCXO , No support

Table 338: IGNSSMEM_Bitmask_Description

11.6 AT%IGNSSCEP: CEP data file saved in memory

Allows the host to download, erase or query about CEP data file saved in memory.

Command	Command Type	Response
AT%IGNSSCEP= <op>[,<days>]	Set	For "STAT" %IGNSSCEP:<status>[,<rem_days>, <rem_hours>,<rem_minutes>] OK
AT%IGNSSCEP?	Read	ERROR
AT%IGNSSCEP=?	Test	%IGNSSCEP:(list of supported <op>),(range of supported <days>)

Table 339: AT%IGNSSCEP

Description:

Allows the host to download, erase or query about CEP data file saved in memory.

Defined values:

<op>: string.

Value	Description
"DLD"	Download CEP file for <num_of_days> from Sony Server.
"ERASE"	Erase CEP file from memory.
"STAT"	Query for CEP validity status. In case of CEP valid, returns also the number of days/hours and minutes which will remain valid.

Table 340: IGNSSCEP_Op_Description

<days>: integer. the data which is required to be deleted. Bitmask can contain any combination of the bits reflected below.

Value	Description
1	In day(s)
2	In day(s)
3	In day(s)
7	In day(s)
14	In day(s)
28	In day(s)

Table 341: IGNSSCEP_Days_Description

<rem_days>: integer type. Remaining number of days for CEP validity.

<rem_hours>: integer. Remaining number of hours for CEP validity.

<rem_minutes>: integer. Remaining number of minutes for CEP validity.

12 LWM2M Related AT Commands

12.1 AT%LWM2MCMD: Control the LWM2M client

This command is used to control the LWM2M client.

Command	Command Type	Response
AT%LWM2MCMD=<cmd> [,<param1>[,<param2> [,<param3>]]]	Set	<p>For "SERVERSINFO" list of server details:</p> <pre>%LWM2MCMD:<ServerUri>,<ServerID>,<Liftime>,<binding>,<ServerStat>[,<LastRegDate>] [%LWM2MCMD:<cmd>,<ServerUri>,<ServerID>,<Liftime>,<binding>,<ServerStat>[,<LastRegDate>] [...]]]</pre> <p>For "GET_RESOURCE", list of details:</p> <pre>%LWM2MCMD:<ObjectID>[,<ObjectInstanceID>[,<ResourceID>[,<ResourceInstance ID>[,<val>]]]]</pre> <p>For "DISCOVER", list of LWM2M client object(s), object instance(s) [and resource(s)]:</p> <pre>%LWM2MCMD: <res1>[,<res2>[...]]</pre> <p>For "PROGRESS", download progress:</p> <pre>%LWM2MCMD: received=<CurDlSize>,total=<TotalImgSize></pre> <p>For "GET_FOTA_STATE" :</p> <pre>%LWM2MCMD: <FotaState></pre> <p>For other commands :</p> <pre>OK ERROR</pre>
AT%LWM2MCMD?	Read	ERROR
AT%LWM2MCMD=?	Test	OK

Table 342: AT%LWM2MCMD

Description:

This command is used to control the LWM2M client. It is used by the FOTA manager.

Defined values:

<cmd>: string.

Value	Description
"REGISTER"	Application initiated command to register with the LWM2M server, <param1>, decimal, Short Server ID.
"DEREGISTER"	Application initiated command to Re-register the LWM2M server <param1>, decimal, Short Server ID.
"REGISTERUDP"	Application initiated command to Re-register LWM2M server, <param1>, integer, short Server ID.
"BOOTSTARP"	Initiate bootstrap procedure <param1>, integer, post bootstrap mode; 0: continue to registration normally after bootstrap (default) 1: avoid registration after bootstrap
"COAPDUMP"	enable lwm2m coap dump. local ip: 11.11.11.11 destination server ip: 22.<sec obj="" short="" id="">.22.22 <param1> - mode "DISABLE": disable "CLI": print to cli "LOG": print to logger <param2> - persistence 0: non 1: persist <param3> - integer. logger size(default 16K), relevant for LOG mode
"UPDATEREP"	FOTA manager report of the update result <param1>, string ; "SUCCESS": Firmware updated successfully "FAIL": Firmware update failed <param2>, integer. For <param1> = "FAIL", provides FOTA Update Result. source 5/0/5) as defined in section E.6 of [10].
"DLRSP"	A command answers to the request from OMA-DM client to start/cancel/defer package download. <param1>, "ACCEPT": Accept the request to start package download "CANCEL": Cancel the request to start package download <param2>, integer. For <param1>="CANCEL". provides FOTA Update Result. (resource 5/0/5) as defined in section E.6 of [10].
"RESUME"	Resume download after internal download error (e.g. out of coverage, reboot etc).

Table 343: +LWM2MCMD_cmd_Description

Value	Description
"UPDRSP"	<p>A command answers to the request of OMA-DM client to update firmware with the downloaded package.</p> <p><param1>, "ACCEPT": Accept the request to start package download "CANCEL": Cancel the request to start package download <param2>, integer. For <param1="CANCEL". provides FOTA Update Result (resource 5/0/5) as defined in section E.6 of [10].</p>
"SERVERSINFO"	A query for server information
"SET_RESOURCE"	<p>Set resource value to LwM2M tree. This command when executed on multi resource instance will generate instance if not already exist. Note that this command can also write single resource instance in case of multi-resource instance. This command is not applicable for Host resources.</p>
"GET_RESOURCE"	<p>Get resource value from LwM2M tree. This command is not applicable for Host resources. This command is not applicable for security resources: /0/x/3, /0/x/5... . This can be a multiline reply (each describing single resource value) when query is sent with omitted optional parameter:</p> <p>Object-instances ID - return all the resource values of of that Object-instances ID Resource ID - return all the multi-resource values of of that Resource ID</p>
"DEL_RESOURCE_INSTANCE"	Delete specific resource instance of multi-resource instance.
"EXEC_RESOURCE"	<p>Execute resource value to LwM2M tree.</p> <p><param1>, integer ; see definition of <ObjectID> <param2>, integer ; See definition of <ObjectInstanceID> <param3>, integer ; See definition of <ResourceID> <param4>, integer ; See definition of <ResourceInstanceID> <param5>, string type ; See definition of <val></p>
"SETINSTANCES"	<p>update the list of object instances at run-time (currently limited to Host Objects). This command completely override previously defined object instance list.</p> <p><param1> - integer, see definition of <ObjectID> <param2>-<param...> - integer; optional parameters. If no <param2> at all, there won't be any instances of this object, see definition of <ObjectInstanceID></p>

Table 344: +LWM2MCMD_cmd_Description

Value	Description
"DISCOVER"	to discover object/object instances/object resources. <param1> - string type; the path to the object or object instance tree to discover. Optional parameter. if path is missing, command reports the list of all discovered objects with their instance IDs if path is "/object", command reports the list of all instance IDs located on the path if path is "/object/instance ID", command reports the list of all resource IDs located on the path
"GET_FOTA_STATE"	Return FOTA state
"PROGRESS"	Return download progress
"PORTFOLIO"	Perform operations on object 16 (portfolio), resource 0 (Identity) - Data Storage extension for other Object Instances.
"DLSUS"	Download suspend (applicable for HTTP/S PULL method only). <param1> - string; operation: "SETINSTANCE": Create new instance of object portfolio and set resource 0 values "READ": Read portfolio object parameters "DELETE": Delete portfolio instance For <param1>="SETINSTANCE" <param2> - integer, see definition of <ObjectInstanceID> <param3> - integer, see definition of <ResourceID>, currently supports only resource ID 0 <param4> - integer, see definition of <ResourceInstanceID> <param5> - integer, see definition of <val>. Only last written values are saved in the object instance file. Previous values are deleted. For <param1>="READ" <param2>: integer, see definition of <ObjectInstanceID> (Optional parameter) For <param1>="DELETE" <param2> - integer, see definition of <ObjectInstanceID>

Table 345: +LWM2MCMD_cmd_Description

<ServerUri>: string. The Server URI.

<ServerID>: integer. The Server Short ID.

<Lifetime>: integer. The server registration period from the last registration date in seconds.

«binding>: integer.

Binding Value	Description	LWM2M Ver 1.0	LWM2M Ver 1.1
0	Unknown	Supported	Supported
1	UDP (U)	Supported	Supported
2	UDP queue mode (UQ)	Supported	N/A
3	SMS (S)	Not Supported	Not Supported
4	SMS queue mode (SQ)	Not Supported	N/A
5	UDP with SMS (US)	Supported (SMS only for triggering)	Not Supported
6	UDP queue mode with SMS (UQS)	Supported (SMS only for triggering)	N/A
7	NIDD mode (N)	N/A	Supported

Table 346: +LWM2MCMD_Binding_Description



In LWM2M spec version 1.1 Queue mode is no longer part of server binding mode

In LWM2M spec version 1.1 there is a differentiation between SMS binding and SMS Triggering (wakeup SMS). Since Altair supports SMS only for triggering, binding mode with SMS is not supported.

<ServerStat>: integer.

Value	Description
0	not registered or bootstrap not started
1	Registration pending
2	Successfully registered
3	Last registration failed
4	Registration update pending
5	Deregistration pending
6	Bootstrap hold off time
7	Bootstrap request sent
8	Bootstrap on going
9	Bootstrap done
10	Bootstrap failed

Table 347: +LWM2MCMD_ServiceStat_Description

<LastRegDate>: integer. The UTC time in 10 msec units counted since 00:00:00 on 1 January, 1900.

«**ObjectID**»: integer. Specifies the LWM2M Object ID.

<**ObjectInstanceID**>: integer. Specifies the LWM2M Instance ID of the object (Optional parameter).

<**ResourceID**>: integer. Specifies the LWM2M resource Instance ID of the object instance (Optional parameter).

<**ResourceInstanceID**>: integer. Specifies the LWM2M resource Instance ID of the object instance (Optional parameter).

<**val**>: string. Max size 511 bytes, specifies the value of the resource (Optional parameter).

Type	Value
Boolean	"TRUE", "FALSE"
Integer	signed 64 bits integer format.String within " "
Float	double float format.String within " "
Text	String within " "
Buffer (opaque field)	Hexadecimal opaque data is represented as ASCII hex string. The length of hex string is twice longer than actual binary data length in bytes: each hex byte is encoded into 2 ASCII bytes. Data length is limited by 255 Bytes.
Object link	"object;object-instance"
"Observe" Event	"pmin=minimum period & pmax=maximum period>=greater than<=less than&st=step" All the parameters in the string are optional

Table 348: +LWM2MCMD_Val_Description

<**res1**>: <**res...**>: string. Shortened textual representation of the discovered LWM2M tree/sub-tree structure located on the path (<param1> of "DISCOVER").

- if path is missing, <res...> params report the list of all discovered objects with their instance IDs in form of: "/object/instance ID"
- if path is "/object", <rea...> params report the list of all instance IDs located on the path in form of: "/object/instance ID"
- if path is "/object/instance ID", <res...> params report the list of all resource IDs located on the path in form of: "/object/instance ID/resource ID"

<**CurDlSize**>: integer. Currently downloaded size in bytes.

<**TotalImgSize**>: integer. Total image size in bytes.

<**FotaState**>: integer.

Value	Description
0	Idle
1	Pending download
2	During download
3	Download failed
4	Download completed
5	Pending update
6	Update confirmed

Table 349: +LWM2MCMD_Fota_State_Description

Example:

Discover Object ID=16 structure (list of object instances):

```
AT%LWM2MCMD="DISCOVER","/16"  
%LWM2MCMD: "/16/0","/16/1"  
OK
```


12.2 AT%LWM2MOPEV: Unsolicited Command

Command	Command Type	Response
AT%LWM2MOPEV= <mode>, <event>	Set	OK or ERROR
AT%LWM2MOPEV?	Read	ERROR (not supported)
AT%LWM2MOPEV=?	Test	OK
(unsolicited result code)	unsolicited	%LWM2MEOPV:<event>[, [<serverShortId>], [<ObjectID>],[<ObjectInstanceID>], [<ResourceID>],[<ResourceInstanceID>],[<val>] [,<MsgId>]]

Table 350: AT%LWM2MOPEV

Description:

This unsolicited command notifies the host about operations performed by the server on the LWM2M tree.



Notes: In both command and response, a parameter which is not specified will be written as ",". URC will not notify about security object events.

Defined values:

<mode>: integer.

Value	Description
0	Disable unsolicited "server operation" event indications
1	Enable unsolicited "server operation" event indications

Table 351: %LWM2MOPEV_Mode_Description

<event>: integer.

Value	Description
0	"Write" operation was received
1	"Execute" operation was received
2-3	Reserved
4	"Write Attributes" operation was received
5	"Discover" operation was received
6	"Read" operation was received
7	"Observe" operation was received
8	"Cancel observation" operation was received
9	Client is offline
10	Client is online
11	Client sent observation notification to a server
12	Client received wakeup SMS
13	Client received notification acknowledge
14	Client ON: LWM2M client exits Client OFF state and tries to re-connect server due to explicitly AT Command registration request
15	Client OFF: LWM2M client has exhausted server connection retries
16	Confirmable NOTIFY failed
17-19	Reserved
20	Bootstrap finished and completed successfully
21	Registration finished and completed successfully all server observation requests are cleaned, the host should clean host objects observation rules too
22	Register update finished and completed successfully
23	De-register finished and completed successfully
24	Notification is was not saved and not sent to server
25-99	Reserved
100	enable all notifications

Table 352: %LWM2MOPEV_Event_Description

<serverShortId>: integer. short server ID (values 0 - 65535).

<ObjectID>: integer. Specifies the LWM2M Object ID.

<ObjectInstanceID>: integer. Specifies the LWM2M Instance ID of the object (Optional parameter).

<ResourceID>: integer. Specifies the LWM2M resource ID of the object instance (Optional parameter).

<ResourceInstanceID>: integer. Specifies the LWM2M resource Instance ID of the object instance (Optional parameter).

<val>: string. Max size 3000 bytes, specifies the value of the resource (Optional

parameter).

Type	Value
Boolean	"TRUE", "FALSE"
Integer	signed 64 bits integer format.String within " "
Float	double float format.String within " "
Text	String within " "
Buffer (opaque field)	Hexadecimal opaque data is represented as ASCII hex string. The length of hex string is twice longer than actual binary data length in bytes: each hex byte is encoded into 2 ASCII bytes. Data length is limited by 256 Bytes.
Object link	"object;object-instance"
"Observe" Event	"pmin=minimum period & pmax=maximum period>greater than<less than&st=step" All the parameters in the string are optional

Table 353: +LWM2MOPEV_Val_Description

<MsgId>: integer. COAP message ID (for NOTIFY event). Values (0 - 65535).

Example:

Enable notification for "Write":

```
AT%LWM2MOPEV=1,0
OK
```

12.3 AT%LWM2MEV: Notify Status of Firmware Upgrade process

Command	Command Type	Response
AT%LWM2MEV=<mode>	Set	OK or ERROR
AT%LWM2MEV?	Read	ERROR
AT%LWM2MEV=?	Test	%LWM2MEV: (list of supported <mode>)
(Unsolicited)	Unsolicited	%LWM2MEV:<event>,[<package_size>], [<reserved>],[<package_name>],[<error_type>]

Table 354: AT%LWM2MEV

Description:

AT Command to enable/disable %LWM2MEV URC to host. The URC notifies the status of firmware upgrade process.

Defined values:

<mode>: integer. Status of unsolicited result response presentation.

- 0: Disable unsolicited FOTA event indications (default for external Host)
- 1: Enable unsolicited FOTA event indications (default for internal App)

<event>: integer.

Type	Value
0	PENDING DOWNLOAD
1	PENDING UPDATE
2	DOWNLOAD COMPLETED
3	DOWNLOAD FAILED
4	FOTA CANCELLED BY LWM2M SERVER
5-9	Reserved

Table 355: %LWM2MEV_Event_Description

<package_size>: integer. For <event>="PENDING UPDATE", The package size in bytes.

<package_name>: string.

- For <event>="PENDING DOWNLOAD", The file name of download package.
- For <event>="PENDING UPDATE", The file name of update package.

<error_type>: integer. For <event>="DOWNLOAD FAILED"

Type	Value
0	NON FATAL - Download can be resumed by FOTA manager
1	FATAL - Download resume is not possible, FOTA manager shall move to idle

Table 356: %LWM2MEV_Error_Type_Description

12.4 AT%LWM2MOBJEV: Notify to Application

Command	Command Type	Response
AT%LWM2MOBJEV=[<token>],[<serverId>],[<confirmation>],[<fragment_info>],<uri>,<value>[,<uri>,<value>[...]]	Set	OK or ERROR
AT%LWM2MOBJEV?	Read	ERROR (not supported)
AT%LWM2MOBJEV=?	Test	OK

Table 357: AT%LWM2MOBJEV

Description:

This command is used by Host application to send "NOTIFY" or "SEND" (starting LWM2M v1.1 support) with resource value.



The <uri>s in the command can be single or/and multi-resource instance. All <uri> must be from the same object instance, meaning /<Obj ID>/<Obj Inst> must be the same for all resources.

Defined values:

<token>: hexadecimal. If omitted <token> triggers "SEND" message. Up to 8 bytes. (Value range "0"- "FFFFFFFFFFFFFFFF").

<serverId>: integer. LWM2M Short Server ID. Parameter can be omitted is single server is in use. If parameter is omitted for multiple servers use-case, command returns ERROR. (Value range 1-65535).

<confirmation>: integer. Optional. Default value is defined in LWM2M configuration file in "ConfirmNotify" parameter.

Type	Value
0	Notify confirmation default configuration value
1	Notify confirmation is NOT required from the server
2	Notify confirmation is required from the server

Table 358: %LWM2MOBJEV_Confirmation_Description

<fragment_info>: integer. Fragment event information.

All AT commands in a group of AT commands sent with <fragment_info>=1/2 must be for the

same Object ID.

Object Instance ID must be not repeated in a group of AT commands sent with <fragment_info>=1/2.

Type	Value
0	Single AT Command for event notification. (default).
1	AT Command is part of group AT commands event and contains a fragment of event message.
2	AT Command is part of group AT commands event and contains the last fragment of event message.

Table 359: %LWM2MOBJEV_Fragment_Description

<uri>: string. Resource URI path example: /<Obj_ID>/<Obj_Inst>/<Resource ID>/[Resource Inst >]]].

<val>: string. Max size 3000 bytes, specifies the value of the resource (Optional parameter).

Type	Value
Boolean	"TRUE", "FALSE"
Integer	signed 64 bits integer format.String within " "
Float	double float format.String within " "
Text	String within " "
Buffer (opaque field)	Hexadecimal opaque data is represented as ASCII hex string. The length of hex string is twice longer than actual binary data length in bytes: each hex byte is encoded into 2 ASCII bytes. Data length is limited by 256 Bytes.
Object link	"object;object-instance"
"Observe" Event	"pmin=minimum period & pmax=maximum period>greater than<less than&st=step" All the parameters in the string are optional

Table 360: LWM2MOBJEV_Val_Description

12.5 AT%LWM2MOBJRSP: Application response for %LWM2MCMDU

Command	Command Type	Response
AT%LWM2MOBJRSP=<seq_num>,<ret_code> [,<uri>,<value>[,<uri>,<value>[...]]]	Set	OK or ERROR
AT%LWM2MOBJRSP?	Read	ERROR (not supported)
AT%LWM2MOBJRSP=?	Test	OK

Table 361: AT%LWM2MOBJRSP

Description:

This command is used to provide Host application response for %LWM2MCMDU URC.

Defined values:

<seq_num>: integer. Used for this URC and %LWM2MOBJRSP AT command synchronization. Value range 1-1000 (with wrap around).

<ret_code>: string. CoAP response code.

Type	Value
"2.04"	Changed - operation completed successfully
"2.05"	Content - operation completed successfully
"4.00"	Bad Request - Undetermined error occurred/The format of data to be written is different
"4.01"	Unauthorized - access right permission denied
"4.04"	Not Found - URI not found
"4.05"	Method Not Allowed - Target is not allowed for such operation
"4.06"	Not Acceptable - None of the preferred Content-Formats can be returned.
"4.15"	Unsupported Content-Format - The specified format is not supported.
"5.00"	Internal Server Error (this is also the default value if ret_code value is not supported)

Table 362: %LWM2MOBJRSP_ret_code_Description

<uri>: string. Resource URI path example: /<Obj_ID>/<Obj_Inst>/<Resource ID>/<Resource Inst >]]].

<val>: string. Max size 3000 bytes, specifies the value of the resource (Optional parameter).

Type	Value
Boolean	"TRUE", "FALSE"
Integer	signed 64 bits integer format.String within " "
Float	double float format.String within " "
Text	String within " "
Buffer (opaque field)	Hexadecimal opaque data is represented as ASCII hex string. The length of hex string is twice longer than actual binary data length in bytes: each hex byte is encoded into 2 ASCII bytes. Data length is limited by 256 Bytes.
Object link	"object;object-instance"
"Observe" Event	"pmin=minimum period & pmax=maximum period>=greater than<=less than&st=step" All the parameters in the string are optional

Table 363: LWM2MOBJRSP_Val_Description

12.6 AT%LWM2MOBJDEF: Sets and gets resources definition of Host Objects

Command	Command Type	Response
AT%LWM2MOBJDEF=<cmd>,<object_id>[,<resource_id>,<operation>,<instance_type>,<data_type><resource_id>,<operations>,<instance_type>,<data_type>[...]]	Set	OK or ERROR
AT%LWM2MOBJDEF?	Read	ERROR (not supported)
AT%LWM2MOBJDEF=?	Test	ERROR

Table 364: AT%LWM2MOBJDEF

Description:

Sets and gets resources definition of Host Objects. Set operation creates new resource and store it into NV.

Defined values:

<cmd>: string.

Type	Value
"GET"	Read Resources definition of Host Object.
"SET"	Define Resources definition of Host Object and create it storing into NV.

Table 365: %LWM2MOBJDEF_cmd_Description

<object_id>: integer. Specifies the LWM2M Object ID. Value range 0-65534.

<resource_id>: integer. Specifies the LWM2M resource ID. Value range 0-65534.

<operation>: string. The type of operation that may be performed on the resource.

Type	Value
"R"	Read-only.
"W"	Write-only.
"RW"	Read and Write.
"X"	Execute.

Table 366: %LWM2MOBJDEF_Operation_Description

<instance_type>: integer.

Type	Value
0	single resource
1	multi resource

Table 367: %LWM2MOBJDEF_instance_Description

<data_type>: string.

Type	Value
"NONE"	Data Type is not relevant (in case if <operation> is "EXE")
"STR"	String.
"INT"	Integer.
"UINT"	Unsigned integer (supported from LWM2M ver 1.1 only) "FLT"
"BOOL"	Boolean
"OPQ"	Opaque
"TIME"	Time
"OL"	Object Link

Table 368: %LWM2MOBJDEF_data_type_Description

Example:

Define object 3305 (Power Measurement) resources 5800, 5806 and 5822:

```
AT%LWM2MOBJDEF="SET",3305,5800,"R",0,"FLT",5680,"W",0,"FLT",5822,"X",0,"NONE"
"
OK
```

Read object 3305 resources definition

```
AT%LWM2MOBJDEF="GET",3305
%LWM2MOBJDEF: 3305,5800,"R",0,"FLT",5680,"W",0,"FLT",5822,"X",0,"NONE"
OK
```

13 MQTT Related AT Commands

13.1 MQTT AT Commands

13.1.1 %MQTTCFG: Configure MQTT Connection Parameters

AT command to configure MQTT connection parameters.

Command	Command Type	Response
AT%MQTTCFG=<obj>,<conn_id>[, [<param1>][,<param2>]...]	Set	OK ERROR
AT%MQTTCFG?	Read	ERROR
AT%MQTTCFG=?	Test	%MQTTCFG: (list of supported <cmd>),(list of supported <conn_id>)

Table 369: AT%MQTTCFG

Description:

AT command to configure MQTT connection parameters. To start new MQTT connection the "NODES" parameters shall be defined at least. Other configurations may be omitted, default settings are use :

- If "TLS" layer is not configured, unsecured connection will be established by default.
- If "IP" layer is not configured, default PDN, IP type and default MQTT ports will be used.
- If "PROTOCOL" parameters are not configured, default protocol parameters will be selected.
- If "WILLMSG" parameters are not configured, no Will message will be used.

To make this omission confidentially working, it is strictly recommended to call "CLEAR" sub-command before entering new configuration for previously used or default <conn_id>.

Connection ID parameter is introduced to handle multi-connection MQTT. Use zero value for <conn_id> if single connection is expected. The ID for multi-connection is assigned by user and then used for all connection configuration in current AT%MQTTCFG, command (AT%MQTTCMD) and event (AT%MQTTEV/%MQTTEVU).

Defined values:**<obj>**: string.

Value	Description
"NODES"	Configure client & server nodes parameters
"TLS"	Configure TLS layer security parameters
"IP"	Configure IP layer parameters
"WILLMSG"	Configure MQTT will message
"PROTOCOL"	Configure MQTT protocol parameters
"CLEAR"	Clear all previous settings for specified <conn_id>

Table 370: MQTTCMD_Obj_Description

<conn_id>: integer. Default or previously assigned <conn_id>.

- 0: Single MQTT connectivity mode.
- 1 -5: Multi-connected mode.

For "NODES" :**<param1>**: string. Unique client ID used to connect to the broker.**<param2>**: string. Broker URL or IP address.**<param3>**: string. Optional username for broker authentication.**<param4>**: string. Optional password for broker authentication.**For "TLS" :****<param1>**: string. TLS authentication mode;

- 0: mutual authentication (default).
- 1: Authenticate client side only.
- 2: Authenticate server side only.

<param2>: integer. TLS predefined authentication context (profile) previously configured by AT%CERTCFG. Default zero profile ID may be used for server authentication only and will apply root CAs stored into Root Trusted folder for authentication.

For "IP" :

<param1>: integer. Optional Session ID. Numeric PDN identification defined in APN table for specified PDN. If Session ID=0 or omitted default data PDN is used unless configured differently by AT%SETRROUTE;

- 0: Use default data PDN.
- 1: max value defined in NP config file.

<param2>: integer. Optional IP type used to configure preferred IP type for connection.

- 0: IPv4v6 (default).
- 1: IPv4.
- 1: IPv6.

<param3>: integer. Optional destination (server) TCP/UDP port number. If omitted default MQTT port number is used. Value range 1 - 65535.

For "WILLMSG":

<param1>: integer. Will message presence.

- 0: disable (default value).
- 1: enable.

<param2>: integer. Will QoS value.

- 0: at most once delivery (default value).
- 1: at least once delivery.
- 1: exactly once delivery.

<param3>: integer. Will message retain - whether or not the Will Message will be retained across disconnects.

- 0: (default value): the Will Message will not be retained at the MQTT server across disconnects from MQTT client
- 1: the Will Message will be retained by the MQTT server across disconnects from MQTT client (until superseded by another message).

<param4>: string. Will Topic - Standard MQTT Topic Name. It could include various Topic Separators "/" to form various Topic levels.

<param5>: string. The Will message defines the content of the message that is published to the Will topic if the client is unexpectedly disconnected.

For "PROTOCOL":

<param1>: integer. MQTT protocol type for connection.

- 0:MQTT (default).

<param2>: integer. Keep-alive time. The default value is 600 sec (10 min). Unit: second. It defines the maximum time interval between messages received from a client.

- 0: no timeout, keep-alive deactivated.
- 1 - 65535 (18 hours, 12 minutes and 15 seconds.).

<param3>: integer. Clean session type.

- 0: the server must store the subscriptions of the client after it disconnects.
- 1: the server must discard any previously maintained information about the client and treat the connection as "clean". Default policy.

13.1.2 %MQTTCMD: Communicate With MQTT Server (Broker)

Command	Command Type	Response
AT%MQTTCMD=<cmd>, <conn_id>[,<param1>, <param2>[,<param3>[, <param4>][,<param5>]]] [<data>]	Set	%MQTTCMD:<"CONNECT"/"DISCONNECT"/ "SUBSCRIBE"/"UNSUBSCRIBE"/"PUBLISH" /"PUBACK"/"REGISTER">,<conn_id>[, [<param1>][,<param2>]...] OK
AT%MQTTCMD?	Read	ERROR
AT%MQTTCMD=?	Test	%MQTTCMD: (list of supported <cmd>),(list of supported <conn_id>)

Table 371: AT%MQTTCMD

Description:

AT command to communicate with MQTT server (broker).All commands are un-blocking.The information about command success or fail will be provided in %MQTTEVU URC.The Will message used in "CONNECT" shall be predefined in AT%MQTTCFG.

The "PUBRCV" URC can provide incoming publication data in the <data> parameter only for textual or pseudo-textual data transfer (i.e. JSON, PEM, B64, etc.). The arbitrary binary data transfer is possible only to file. Use AT%MQTTCMD="SUBSCRIBE" to define filename for binary data download.

The "PUBLISH" command provides 2 mechanisms to publish data.

- Only textual or pseudo-textual (i.e. JSON, PEM, B64, etc.) data transfer is permitted for direct AT call using <data> parameter.
- The arbitrary binary data transfer is possible only from file.

For non-file "PUBLISH" operation the data size parameter <param4> may be omitted in human debug mode of AT usage. In this use-case Ctrl+Z pressing shall signal data end.

The "SUBSCRIBE" with defined filename parameter will cause that all following server publications will be stored into the file and signaled by %MQTTEVU: "PUBRCV" URC. Use different filenames for different <conn_id> and topic names to prevent file override, if needed. The file for server publication will be always located on temporary storage disk b:/. User shall specify only filename for "SUBSCRIBE" sub-command. Any attempt to specify full path in this command will be rejected with ERROR.

Defined values:

<cmd>: string.

Value	Description
"CONNECT"	Start connection with endpoint
"DISCONNECT"	End connection with endpoint
"SUBSCRIBE"	Subscribe to a topic on the endpoint
"UNSUBSCRIBE"	Stop subscription to a topic on the endpoint.
"PUBLISH"	Send publish packet to endpoint
"PUBACK"	Not support
"REGISTER"	Not support

Table 372: %MQTTCMD_Cmd_Description

<conn_id>: integer. Default or previously assigned <conn_id>.

- 0:single MQTT connectivity mode. Each configuration overrides previous setting
- 1 - 5: multi-connected mode.

<msg_id>: message ID. Value range 1-65535.

For "CONNECT"/"DISCONNECT"

No <param>

For "SUBSCRIBE" :

<param1>: integer. The QoS level at which the client wants to publish the message.

- 0: At most once delivery (default value).
- 1: At least once delivery.
- 2: Exactly once delivery.

<param2>: string. The subscription topic name.

<param3>: string. Optional parameter. Filename to store received publications on b:/.

For "UNSUBSCRIBE" :

<param1>: string. The subscription topic name.

For "PUBLISH":

<param1>: integer. The QoS level at which the client wants to publish the message.

- 0: At most once delivery (default value).
- 1: At least once delivery.
- 2: Exactly once delivery.

<param2>: integer. Whether or not the server will retain the message after it has been delivered to the current subscribers.

- 0: The server will not retain the message after it has been delivered to the current subscribers.
- 1: The server will retain the message after it has been delivered to the current subscribers.

<param3>: string. The publication topic name.

<param4>: integer. Actual data size in bytes for transfer to server.

- 0: Undefined, publish from file.
- 1: 3000

<param5>: string. Optional parameter. Full path to file to publish from.

<data>: string MQTT raw data payload without quotes.

13.1.3 %MQTTEV: Notify About MQTT Events

Command	Command Type	Response
AT%MQTTEV= <ev_type>,<mode>	Set	OK or ERROR
AT%MQTTEV?	Read	ERROR
AT%MQTTEV=?	Test	%MQTTEV: (list of supported <ev_type>), (list of supported <mode>)
Unsolicited	Unsolicited	%MQTTEVU:<ev_type>,<conn_id>,<res1> [,<res2>[,<res3> [,<res4>,<res5>]]][<data>]

Table 373: AT%MQTTEV

Description:

The command is intended to notify about MQTT events. Default MQTT mode is URC disabled for all event types except of "PUBRCV", which is enabled by first call of AT%MQTTCMD="SUBSCRIBE". Most of the events are related to asynchronous operation triggered by AT%MQTTCMD. Such acknowledgement may be normally disabled.

Only "PUBRCV" event provides the data from the topic, to which the client was pre-subscribed by AT%MQTTCMD="SUBSCRIBE".

The "PUBRCV" URC can provide incoming publication data in the <data> parameter only for textual or pseudo-textual (i.e. JSON, PEM, B64, etc.) data transfer. The arbitrary binary data transfer is possible only to file on b:/. Use AT%MQTTCMD="SUBSCRIBE" to define filename for binary data download.



Note: AT%MQTTCMD="PUBLISH" with QoS=0 will not send any acknowledge message and <ev_type>="PUBCONF" is not expected.

Defined values:

<ev_type>: string.

Value	Description
"CONCONF"	Connect procedure confirmation status
"DISCONF"	Graceful disconnect procedure confirmation status
"SUBCONF"	Subscribe procedure confirmation status
"UNSCONF"	Unsubscribe procedure confirmation status
"PUBCONF"	Outgoing publication procedure confirmation status. Optional URC, depends on "PUBLISH" QoS selected
"PUBRCV"	Incoming publication message received
"CONNFAIL"	Connection failure
"PUBRCVSTORFAIL"	Storage failure of received publication. Ordinary if disk out of space or file is opened for writing.
"ALL"	All events, used only in execution command

Table 374: %MQTTCMD_Ev_Type_Description

<mode>: integer. Status of unsolicited result response presentation.

- 0: disable (default value).
- 1: enable.

<conn_id>: integer. Default or previously assigned <conn_id>.

- 0: Single MQTT connectivity mode.
- 1 -5: Connection ID in multi-connected mode

For "CONCONF"/"DISCONF" :

<res1>: integer. Result code.

- 0: Success
- 1: Fail

<res2>: integer. Optional error code.

- 0: No Error
- 1: Error

For "UNSCONF" :

<res1>: integer. Message ID value range 1-65535.

<res2>: integer. Result code.

- 0: Success
- 1: Fail

<res3>: integer. Optional error code.

For "SUBCONF"/"PUBCONF" :

<res1>: Message ID value range 1-65535.

<res2>: integer. Result code.

- 0: Success
- 1: Fail

<res3>: integer. Optional error code.

For "PUBRCV"/"PUBRCVSTORFAIL" :

<res1>: Message ID. It may be zero (undefined) for QoS=0 ;

- 0: Undefined
- 1-65535

<res2>: string. The publication topic name.

<res3>: integer. Data size in bytes transferred by this URC. If this parameter is equal to zero, no any <data> arrival is expected in the same URC.

<res4>: integer. Optional data size in bytes stored into file.

<res5>: string. Optional parameter. Filename, where received publication has been stored (or attempted to be stored for "PUBRCVSTORFAIL") on b:/.

<data>: string. MQTT raw data payload without quotes.

13.2 MQTT AT Commands for AWS

13.2.1 %AWSIOTCFG: Configure AWS IoT Cloud

AT command to configure AWS IOT cloud connection parameters.

Command	Command Type	Response
AT%AWSIOTCFG=<cmd>, [<param1>][,<param2> [,<param3>]]	Set	OK ERROR
AT%AWSIOTCFG?	Read	ERROR
AT%AWSIOTCFG=?	Test	%AWSIOTCFG: (list of supported <cmd>)

Table 375: AT%AWSIOTCFG

Description:

AT command to configure AWS IOT cloud connection parameters. To start new AWS IOT connection the "CONN" parameters shall be defined at least. Mandatory TLS profile ID, which shall be pre-configured by AT%CERTCFG, is a special TLS profile, which does not contain both.: root certificate file and root certificate path. The root certificate path is hard-coded in SW and implies the usage of trusted root CA pre-installed into device to support proper AWS security level. If selected TLS certificate profile contains <ca_file> or <ca_path> fields (see AT%CERTCFG), AT command returns ERROR. If "PROTOCOL" parameters are not configured, default protocol parameters will be selected.

Defined values:

<cmd>: string.

Value	Description
"CONN"	Pre-configure connection parameters
"PROTOCOL"	Pre-configure protocol parameters
"IP"	IP Layer parameters.

Table 376: %AWSIOTCFG_Cmd_Description

For "CONN": Pre-configure connection parameters

<param1>: string. Endpoint URL.

<param2>: integer. TLS predefined authentication context (profile) previously configured by AT%CERTCFG.

<param3>: string. Optional unique client ID used to connect to the broker. The IMEI is used as client ID by default.

For "PROTOCOL":Pre-configure protocol parameters

<param1>: integer. Optional MQTT keep-alive time in seconds. Default 1200 (20 min). Value range 1-1200.

<param2>: integer. Optional QoS setting for "PUBLISH".

- 0: With no confirmation (default value)
- 1: Confirmed (acknowledged)

For "IP": IP layer parameters.

<param1>: integer. Optional Session ID: numeric PDN identification defined in APN table for specified PDN. If Session ID=0 or omitted default data PDN is used unless configured differently by AT%SETROUTE:

- 0: use default data PDN
- 1: max value defined in NP config file

<param2>: Integer. Optional IP type used to configure preferred IP type for connection.

- 0: IPv4v6 (default).
- 1: IPv4.
- 1: IPv6.

13.2.2 %AWSIOTCMD: Communicate with AWS IoT Message Broker

AT command to communicate with AWS IoT message broker.

Command	Command Type	Response
AT%AWSIOTCMD=<cmd> [,<param1> [,<param2>]]	Set	For "SUBSCRIBE"/"UNSUBSCRIBE"/"PUBLISH": [%AWSIOTCMD: <msg_id>]
AT%AWSIOTCMD?	Read	ERROR
AT%AWSIOTCMD=?	Test	%AWSIOTCMD: (list of supported <cmd>s)

Table 377: AT%AWSIOTCMD

Description:

AT command to communicate with AWS IoT message broker.

All commands are unblocking.

The information about command success or fail will be provided in %AWSIOTEVU URC.

Non-zero message ID may be used to pair subscribe, unsubscribe and publish (confirmed) messages with their URCS. At this stage, message ID is not supported, zero value is returned.

Defined values:

<cmd>: string.

Value	Description
"CONNECT"	Start connection with endpoint
"DISCONNECT"	End connection with endpoint
"SUBSCRIBE"	Subscribe to a topic on the endpoint
"UNSUBSCRIBE"	Stop subscription to a topic on the endpoint.
"PUBLISH"	Send publish packet to endpoint

Table 378: %AWSIOTCMD_Cmd_Description

For "SUBSCRIBE": Subscribe (register) to the topic on the endpoint.

<param1>: string. The subscription topic name.

For "UNSUBSCRIBE": Stop subscription (unregister) from the topic on the endpoint

<param1>: string. The subscription topic name.

<cmd> **For "PUBLISH":** Publish (send) packet to endpoint

<param1>: string. The publication topic name.

<param2>: string. Message that appears in the publication, max length is supported 3000(1500bytes).

<msg_id>: message ID.

- 0: Not in use

- 1-65535

13.2.3 %AWSIOTEV: Notify About AWS IOT Events

The command is intended to notify about AWS IOT events.

Command	Command Type	Response
AT%AWSIOTEV==<ev_type><mode>	Set	OK ERROR
AT%AWSIOTEV?	Read	ERROR
AT%AWSIOTEV=?	Test	%AWSIOTEV: (list of supported <ev_type>s), (list of supported <mode>s)
Unsolicited	Unsolicited	%AWSIOTEVU:<ev_type>,<res1>[,<res2> [,<res3]]

Table 379: AT%AWSIOTEV

Description:

The command is intended to notify about AWS IOT events. Default mode is URC disabled for all event types except of "PUBRCV", which is enabled by first call of AT%AWSIOTCMD="SUBSCRIBE". Most of the events are related to asynchronous operation triggered by AT%AWSIOTCMD. Such acknowledgement may be normally disabled.

Only "PUBRCV" event provides the data from the topic, to which the client was pre-subscribed (pre-registered) by AT%AWSIOTCMD="SUBSCRIBE".



Note: AT%AWSIOTCMD="PUBLISH" in unconfirmed mode (no ACK) will not send any acknowledge message and <ev_type>="PUBCONF" is not expected.

Non-zero message ID may be used to pair subscribe, unsubscribe and publish (confirmed) messages sent by AT%AWSIOTCMD with their URCs. At this stage, message ID is not supported, zero value is always reported.



Note: If TCP session is disconnected because of link lost, no URC is sent.

Defined values:

<ev_type>: string.

Value	Description
"CONCONF"	Connect procedure confirmation status
"DISCONF"	Graceful disconnect procedure confirmation status
"SUBCONF"	Subscribe procedure confirmation status
"UNSCONF"	Unsubscribe procedure confirmation status
"PUBCONF"	Outgoing publication procedure confirmation status. Optional URC, depends on "PUBLISH" QoS selected
"PUBRCV"	Incoming publication message received
"CONNFAIL"	Connection failure
"PUBRCVSTORFAIL"	Storage failure of received publication. Ordinary if disk out of space or file is opened for writing.
"ALL"	All events, used only in execution command

Table 380: %AWSIOTEV_Ev_Type_Description

<mode>: integer. Status of unsolicited result response presentation.

- 0: disable (default value).
- 1: enable.

For "CONCONF"/"DISCONF" :

<res1>: integer. result code.

- 0: Success
- 1: Fail

For "SUBCONF"/"UNSCONF"/"PUBCONF":

<res1>: Message ID.

- 0: not in use
- 1-65535

<res2>: integer. Result code.

- 0: Success
- 1: Fail

For "PUBRCV":

<res1>: string. The publication topic name.

<res2>: string. Publication message content received from endpoint.

13.3 Example: MQTT AT Commands for AWS

In this example, the Adrastea-I creates and subscribes a specific topic, then sends the data to AWS and receives data from AWS.

1. Load the User Certificate

```
at%CERTCMD="write","ca-certificate.pem.crt",0,"-----BEGIN_CERTIFICATE
-----*****-----END_CERTIFICATE-----"

OK
```

2. Load the user private key.

```
at%CERTCMD="write","ca-private.pem.key",1,"-----BEGIN_RSA_PRIVATE_
KEY-----*****-----END_RSA_PRIVATE_KEY-----"

OK
```



When using the AT%CERTCMD="WRITE" command, avoid CR characters when pasting command. To do so, copy the command to an editor that supports EOL (end-of-line) format conversion and convert it to UNIX format (i.e., LF format). Then copy and paste this converted content to PuTTY/teraterm.

3. Read the User Certificate:

```
AT%CERTCMD="READ","ca-certificate.pem.crt"
%CERTCMD:"-----BEGIN_CERTIFICATE-----*****-----
END_CERTIFICATE-----"

OK
```

4. Add certificates to the profile:

```
AT%CERTCFG="ADD",1,,,"ca-certificate.pem.crt","ca-private.pem.key"

OK
```

5. Allow AWS events:

```
AT%AWSIOTEV="ALL",1

OK
```

6. Connect an AWS session:

```
AT%AWSIOTCFG="CONN","a18jcdjlx073x-ats.iot.eu-central-1.amazonaws.com",1,"we-iot-device-t1"  
OK
```

7. Configure AWS IOT cloud connection parameters:

```
AT%AWSIOTCFG="PROTOCOL",1200,1  
OK
```

8. Connect to the server:

```
AT%AWSIOTCMD="CONNECT"  
OK
```

9. Wait to get the connection event:

```
%AWSIOTEVU:"CONCONF",0
```

10. Subscribe to topic "test":

```
AT%AWSIOTCMD="SUBSCRIBE","test"  
%AWSCMD: 1  
OK
```

11. Get subscription success notification:

```
%AWSIOTEVU:"SUBCONF",1,0
```

12. Publish some "DATA" to topic "test":

```
AT%AWSIOTCMD="PUBLISH","test","DATA"  
%AWSCMD: 2  
OK
```

13. Get the Notification:

```
%AWSIOTEVU:"PUBCONF",1,0
```

14. Received data from the Server:

```
%AWSIOTEVU:"PUBRCV","test","{"message":_"Hello From AWS"}"
```

14 COAP Related AT commands

14.1 %COAPCFG: To configure COAP parameters

This AT command is used to configure COAP connection parameters.

Command	Command Type	Response
AT%COAPCFG= <obj>, <profile_id> [,<param1>[,<param2>]...]	Set	OK ERROR
AT%COAPCFG?	Read	ERROR
AT%COAPCFG=?	Test	%COAPCFG: (list of supported <cmd>s),(list of supported <profile_id>s)

Table 381: AT%COAPCFG

Description:

This AT command is used to configure COAP connection parameters. To create new COAP connection the "IP" layer with IP address/URL parameter shall be defined at least. Other configurations may be omitted, default settings are used:

- If "DTLS" layer is not configured, unsecured connection will be established by default. It will be considered as misconfiguration if "IP" URL requires security (coaps), but "DTLS" layer is not configured. Any attempt to use AT%COAPCMD will be rejected for such misconfiguration.
- If "OPTIONS" parameter(s) are not configured, all URI options will be filled from <uri> parameter of AT%COAPCMD (if present) by default.

To make this omission confidentially working, it is strictly recommended to call "CLEAR" sub-command before entering new configuration for previously used <profile_id>. Profile ID parameter is introduced to handle multiple pre-defined COAP configuration settings in RAM. The unique ID for multi-profile configuration is assigned by user and then used for all following profile configurations via same AT%COAPCFG.

Defined values:

<obj>, string type ;

Value	Description
"IP"	Configure IP layer parameters
"DTLS"	Configure DTLS layer security parameters
"OPTIONS"	Pre-defined options to be sent with COAP command
"PROTOCOL"	Configure COAP protocol parameters
"CLEAR"	Clear all previous configuration settings for specified <profile_id>
"ABORT"	Clear all data from buffers for selected <profile_id> and abort current transaction

Table 382: COAPCFG_Obj_Description

<profile_id>, integer type; new or previously assigned <profile_id>:

- 1-5

For "IP":

<param1>, string type; destination (server) IP address or URL.

<param2>, integer type; optional destination (server) UDP port number. If omitted default COAP port number is used. Range: 1-65535

<param3>, integer type; optional Session ID - numeric PDN identification defined in APN table for specified PDN. If omitted default data PDN is used.

- 0: use default data PDN
- 1: MAX value defined in NP config file

<param4>, integer type; optional IP type used to configure preferred IP type for connection in URL use-case:

- 0: IPv4v6
- 1: IPv4
- 2: IPv6 (default)

For "DTLS":

<param1>, integer type; predefined DTLS context (profile) previously configured by AT%CERTCFG. The profile ID=0 is reserved for root trusted certs already stored into default root trusted folder. Range: 0-255

<param2>, integer type; DTLS mode:

- 0: PSK mode

- 1: Certificate mode

<param3>, string type; optional, DTLS certificate authentication mode:

- 0: mutual authentication (default)
- 1: authenticate client side only
- 2: authenticate server side only
- 3: no authentication

<param4>, integer type; optional, parameter to enable DTLS session resumption. If this flag is configured to enable, a DTLS resumption will be used instead of full DTLS handshake in case of DTLS session expiry (timeout value is taken from configuration file) or when reopening a socket due to LTE connectivity loss or similar issue. The DTLS session is released only after "CLEAR" commands will be applied to specified COAP <profile_id>:

- 0: disable (default value)
- 1: enable

<param5>, integer type; optional, cipher suite filtering option to be applied to the default list of supported ciphers for negotiation with server:

- 0: white list, to leave only selected cipher suites
- 1: black list, to remove mentioned cipher suites

<param6>, string type; Optional cipher suite list (white or black).



List of cipher suites as per <https://www.iana.org/assignments/tls-parameters/tls-parameters.xhtml> definition. All cipher suites in the list are encoded into single string using hexadecimal cipher suite ID separated by ";", i.e. "C02C;C0AD...C003".

For "OPTIONS": <param1>, string type; binary mask to add Uri-xxx options into COAP packet. Enabled options are extracted from URI parameter defined in AT%COAPCMD. Any bit combination from below may be selected:

- "0001":Uri-Host
- "0010":Uri-Port
- "0100":Uri-Path
- "1000":Uri-Query
- "1111":all (default)

For "PROTOCOL": <param1>, integer type;response waiting timeout for:

- Separate confirmable response
- Non-confirmable GET response

Protocol timeout is selected as minimum value between this parameter and MAX_TRANSMIT_SPAN defined in RFC7252. Parameter is applied to all profiles, <profile_id> value is ignored. If omitted, the MAX_TRANSMIT_SPAN will be used by default.

Units: sec. Range:

- 0: default value: MAX_TRANSMIT_SPAN
- 1: MAX_TRANSMIT_SPAN

14.2 %COAPCMD: To communicate with COAP server

This AT command is used to communicate with COAP server.

Command	Command Type	Response
AT%COAPCMD=<cmd>,<profile_id>, [<uri>,<confirm>],[<token>],[<content>], <data_len>,[blk_szx],[<blk_num>], [<blk_m>],[<param1>,<param2>,...]] [<CR><LF><data>]	Set	%COAPCMD: <token> OK ERROR
AT%COAPCMD?	Read	ERROR
AT%COAPCMD=?	Test	%COAPCMD: (list of supported <cmd>s)

Table 383: AT%COAPCMD

Description:

AT command to communicate with COAP server. All commands are unblocking. The information about command success (for confirmable operations) or fail will be provided in %COAPEVU URC. Command supports both: Host provided and internally generated <token>s. This <token> is always returned in command response regardless of how it was assigned: by Host or by COAP client internally. Using <token> Host may always identify related to message URC for any confirmable message. Only single confirmable message per profile can be proceed at any given time. Other incoming messages will be stored into internal message queue. Next queued message processing will be started once previous confirmable message processing will be finished and reported to the Host via URC (if enabled).

The command provide opportunity to define COAP options for specified method. Some mandatory options (uri, contentformat,BLOCK1, etc.) are encoded in dedicated parameters explicitly. For URI-xxx options filling this command provides two alternative mechanisms:

- If <uri> parameter is present, it will be decomposed into URI-xxx options in accordance with RFC7252, sec 6.4. For this procedure, if some special URI-xxx option exclusive zero bit is set in the bitmask by AT%COAPCFG="OPTIONS" subcommand, such URI-xxx option will be filtered out and not used, even if provided as part of <uri> string.
- The URI-xxx options can be provided also explicitly in the list of the options type/value as a part of first command line.

The URI related option list has a preference: if some URI-xxx option is provided explicitly in the command, the <uri> parameter will be silently ignored. Both <uri> and URI-xxx options may be omitted. The default values for the Uri-Host (IP literal representing the destination IP address) and Uri-Port (destination UDP port) are sufficient for requests to most servers. Other more rarely used options (including URI-xxx) may be added as a pair of option type/value at the end of first command line as defined in RFC 7252:

- 1: If-Match
- 3: Uri-Host
- 4: ETag
- 5: If-None-Match
- 6: Observe
- 7: Uri-Port
- 8: Location-Path
- 11: Uri-Path
- 14: Max-Age
- 15: Uri-Query
- 20: Location-Query
- 28: Size2
- 35: Proxy-Uri
- 39: Proxy-Scheme
- 60: Size1



User may repeat type and value (<param1>/<param2>) pairs few times, if few options are needed to be sent. Number of such pairs is limited only by overall AT command buffer size of 3KB.

Defined values:

<cmd>, COAP method;

Value	Description
"GET"	Trigger COAP GET
"PUT"	Trigger COAP PUT
"POST"	Trigger COAP POST
"DELETE"	Trigger COAP DELETE

Table 384: COAPCMD_cmd_Description

<profile_id>, integer type; previously assigned <profile_id>:

- 1-5

<uri>, string type; optional URI of the target resource at server

<confirm>, integer type; confirmation mode:

- 0: non-confirmed
- 1: confirmed

<token>, hexadecimal type; optional parameter, generated internally if omitted. It is mandatory for GET operation with OBSERVE option. Max size: 8 bytes.

For "GET"/"PUT"/"POST":

<content>, integer type; the value of sent content format ("Context-format" (12) option) for POST/PUT or the optional value of expected content format ("Accept" (17) option) for GET as defined in RFC 7252:

- 0: Text/plain
- 40: Application/link-format
- 41: Application/xml
- 42: Application/octet-stream
- 47: Application/exi
- 50: Application/json

<data_len>, integer type; actual <data> payload size in bytes to send in "PUT" and "POST". Always zero for "GET":

- 0
- 1-1024

<blk_szx>, integer type; optional parameter applied to blockwise data transfer. Block size of transferred data (PUT/POST) to be acknowledged with server (GET/PUT/POST). Only power-of-two block sizes are acceptable:

- 32-1024

<blk_num>, integer type; optional parameter applied to blockwise data transfer. Block sequence number:

- 0 - 1048575 (20 bits)

<blk_m>, integer type; optional parameter applied to blockwise data transfer. Indicates that the data in the message is the last block or more blocks are available. Always zero for "GET":

- 0 - last block
- 1 - more blocks available

<param1>, integer type; optional parameter. Option type as defined in "Description".

<param2>, string type; optional parameter, used together with **<param1>**. The option value as defined in RFC 7252. Any parameter value is represented in quotes including:

- string
- uint
- opaque

For "empty" option value (i.e. ETag option or with zero length), this parameter shall be omitted in command string (omitted parameter is signaled by "").



Note: Repeat **<param2>** and **<param3>** pairs few times, if few options are needed to be sent in the message.

<data>, hexadecimal type; COAP plain payload without quotes.

14.3 %COAPEV: To notify about COAP events

This AT command is used to communicate with COAP server.

Command	Command Type	Response
AT%COAPEV=<ev_type>,<mode>	Set	OK ERROR
AT%COAPEV?	Read	ERROR
AT%COAPEV=?	Test	%COAPEV: (list of supported <ev_type>s), (list of supported <mode>s)
unsolicited	unsolicited	For "xxxCONF"/"GETRCV": %COAPEVU: <ev_type>,<profile_id>,<token>,<status>,<rsp_code>,<data_len>,<content>,<blk_szx>,<blk_num>,<blk_m>,<res1>...] [<CR><LF><data>] For "CMDTERM": %COAPEVU: <ev_type>,<profile_id>,<token>,<error>

Table 385: AT%COAPEV

Description: The command is intended to notify about COAP events. Default COAP mode is URC disabled for all event types. Most of the events are related to asynchronous operation triggered by AT%COAPCMD. Such acknowledgement may be normally disabled. Note that the messages sent in non-confirmable mode will not return acknowledge message and no URC is expected. Server may report even failed operation with Diagnostic Payload transferred in <data> parameter. If no Contentformat option is provided with such payload, the error is expected to be a brief human-readable diagnostic message, explaining the error situation. Note, that such payload will be hex encoded as any other COAP raw payload and needs to be converted into readable text.

Defined values:

<ev_type>, string type;

Value	Description
"PUTCONF"	PUT procedure confirmation status
"POSTCONF"	POST procedure confirmation status
"DELCONF"	Delete procedure confirmation status
"GETRCV"	GET procedure data arrival event
"CMDTERM"	Command execution terminated remotely or locally
"ALL"	All events, used only in execution command

Table 386: COAPEV_ev_type_Description

<mode>, integer type; status of unsolicited result response presentation.

- 0: disabled (default)
- 1: enabled

<profile_id>, integer type; previously assigned <profile_id>:

- 1-5

<token>, hexadecimal type; optional parameter, may be omitted if generated internally for command sent via AT%COAPCMD. It is always present in the response of GET operation with OBSERVE option. Max size: 8 bytes.

<status>, integer type; command execution status indication, relevant for "xxxCONF"/"GETRCV":

- 0: success
- 0: fail

<rsp_code>, integer type; response code of CoAP Protocol. Refer to the RFC 7252:

- 201: 2.01 Created
- 202: 2.02 Deleted
- 203: 2.03 Valid
- 204: 2.04 Changed
- 205: 2.05 Content
- 231: 2.31 - Continue
- 400: 4.00 Bad Request
- 401: 4.01 Unauthorized
- 402: 4.02 Bad Option

- 403: 4.03 Forbidden
- 404: 4.04 Not Found
- 405: 4.05 Method Not Allowed
- 406: 4.06 Not Acceptable
- 408: 4.08 - Request Entity Incomplete
- 412: 4.12 Precondition Failed
- 413: 4.13 Request Entity Too Large
- 415: 4.15 Unsupported Content-Format
- 500: 5.00 Internal Server Error
- 501: 5.01 Not Implemented
- 502: 5.02 Bad Gateway
- 503: 5.03 Service Unavailable
- 504: 5.04 Gateway Timeout
- 505: 5.05 Proxying Not Supported

For "CMDTERM" : <error>, integer type, error code.

- 1: Command execution terminated locally due to LTE connectivity lost.
- 2: Command execution terminated locally due to timeout waiting for the respond to be received.
- 3: ICMP error
- 4: Command execution terminated by client (RST sent) due to Unrecognized option(s) of class "critical" detected in server response.
- 5-255: Reserved
- 256-262: Command execution terminated locally due to DTLS authentication failure.
- 256: An invalid SSL record was received.
- 257: The server has no ciphersuites in common with the client.
- 258: No client certification received from the client, but required by the authentication mode.
- 259: The own certificate is not set, but needed by the server.
- 260: No CA Chain is set, but required to operate.
- 261: A fatal alert message was received from our peer.

- 262: Verification of our peer failed.

For "GETRCV"/"DELCONF"/"POSTCONF"/"PUTCONF" : <data_len>, integer type; <data> payload size in bytes of <data> payload. If missed or equal to 0, no any <data> payload is expected.

- 0
- 1-1024

<content>, integer type; the value of sent content format ("Context-format" (12) option) for POST/PUT or the optional value of expected content format ("Accept" (17) option) for GET as defined in RFC 7252:

- 0: Text/plain
- 40: Application/link-format
- 41: Application/xml
- 42: Application/octet-stream
- 47: Application/exi
- 50: Application/json

<blk_szx>, integer type; optional parameter applied to blockwise data transfer. Block size of transferred data (PUT/POST) to be acknowledged with server (GET/PUT/POST). Only power-of-two block sizes are acceptable:

- 32-1024

<blk_num>, integer type; optional parameter applied to blockwise data transfer. Block sequence number:

- 0 - 1048575 (20 bits)

<blk_m>, integer type; optional parameter applied to blockwise data transfer. Indicates that the data in the message is the last block or more blocks are available. Always zero for "GET":

- 0 - last block for "GETRCV"
- 1 - more blocks available for "GETRCV"

<res1>-<res2>: COAP Option of incoming message (option type/value) of received packet, if present. See option list in AT%COAPCMD command Description. The <res1> and <res2> pairs may be repeated few times.

15 Typical application use cases

In this section some of the typical use cases for the Adrastea-I module are considered and a simple example is described in each case.

15.1 Select LTE-M or NB-IoT Mode

Adrastea-I can be operated through one of the two available cellular communication technologies:

- LTE-Cat.M or
- LTE-Cat.NB-IoT.

Two different configurations can be applied for selection of LTE-Cat.M or LTE-Cat.NB-IoT mode.

- Manual selection of LTE-M or NB-IoT mode or
- Automatic selection of LTE-M or LTE-NB-IoT mode

15.1.1 Manual selection of LTE-M or NB-IoT mode

Adrastea-I supports AT commands for manual selection of LTE-M and NB-IoT. AT Command AT%RATACT is used for manual selection of the LTE-M or NB-IoT mode.



Note: The default mode for the Adrastea-I module is LTE-M single mode.



Any attempt to switch to the mode already in use will be ignored and OK will be returned.

1. Select relevant RAT:

The following AT command will change the module mode to NB-IoT.

```
AT%RATACT="NBIOT",1  
OK
```

The following AT command can be used to verify that NB-IoT has been selected.

```
AT%RATACT?  
%RATACT: "NBIOT",1,0  
OK
```


The following AT command will change the module mode to LTE-M.

```
AT%RATACT="CATM",1  
OK
```

The following AT command can be used to verify that LTE-M has been selected.

```
AT%RATACT?  
%RATACT: "CATM",1,0  
OK
```

2. Reset the device:

The following AT command is used to reset the device.

```
ATZ  
  
OK
```

15.1.2 Automatic Selection of LTE-M or NB-IoT Mode

The automatic selection is used to switch between the LTE-M and NB-IoT when no coverage in the current RAT is detected. RAT switch related configurations are included in the radiom configuration file inside the ALT1250 chipset.

Default configurations of Adrastea-I are as below:

```
at%getacfg=radiom.config.multi_rat_enable  
true  
OK
```



```
at%getacfg=radiom.config.preferred_rat_list  
none  
OK
```

```
at%getacfg=radiom.config.auto_preference_mode  
none  
OK
```

Configure Adrastea-I as below for automatic selection of LTE-M or NB-IoT mode:

1. Disable LTE radio:

```
AT+CFUN=0  
  
OK
```

2. Enable multi-technologies:

```
at+setacfg="radiom.config.multi_rat_enable","true"
```

OK

3. Set technology priority order for automatic selection. The below command sets the first priority for NB-IoT and the second priority for LTE-M:

```
at+setacfg="radiom.config.preferred_rat_list","NBIOT;CATM"
```

OK



Note: In case of the above configuration, Adrastea-I will scan all the frequencies in the NB-IoT technology first. If Adrastea-I does not find coverage in NB-IoT, it will scan all the frequencies in the LTE-M technology. Because of this frequency scanning process, power consumption in automatic selection process is higher than in manual selection process.

4. The Adrastea-I applies automatic technology switch at the switch-on and in the out-of coverage case:

```
at+setacfg="radiom.config.auto_preference_mode","light"
```

OK

5. Restart the Adrastea-I:

```
ATZ
```

OK

To set default factory configurations follow below commands:

```
at%setacfg="radiom.config.multi_rat_enable",true
```

OK



```
at%setacfg="radiom.config.preferred_rat_list","none"
```

OK

```
at%setacfg="radiom.config.auto_preference_mode","none"
```

OK

15.2 Register to Network



The configurations "Select LTE-M or NB-IoT Mode" (see Chapter 15.1) should be done before registering to the LTE network.



A valid LTE-M/NB-IoT SIM card should be inserted. Check SIM status with AT+CPIN? AT Command.

The registration process in LTE-M and NB-IoT technologies could take some minutes to complete. This happens especially in case of the very first registration: new SIM, new location, new module. This is because of scanning of available frequencies and selection of a suitable frequency.

1. Check SIM status:

The following command is used to read the SIM status.

```
AT+CPIN?
```

```
+CPIN: READY
```

```
OK
```

2. To start the registration procedure:

The following command will trigger the registration procedure with the network.

```
AT%CMATT=1
```

```
OK
```

3. Enable network registration unsolicited result code:

The following command will enable network registration and location information unsolicited result code.

```
AT+CEREG=2
```

```
OK
```

4. Read the network registration status:

The following command will read the network registration status.

```
AT+CEREG?  
+CEREG: 2,5,"CB48","01CD6007",9  
OK
```

The following command will trigger the de-registration procedure with the network.

```
AT%CMATT=0
```

```
OK
```

15.3 Manual Network Scan

The following sequence of AT commands is used to scan all available networks. Note that the frequency scanning procedure consumes more power and takes time to scan all bands. To reduce scan time, we recommend defining a specific EARFCN range to be scanned, e.g., AT%SCANCFG=1,1,5230,5230,1.

1. Scan all bands:

```
AT%SCANCFG=1  
OK
```

2. Enable end scan event:

```
AT%SCANCMD=0,1  
OK
```

3. Start scanning:

```
AT%SCANCMD=1  
OK
```

4. When scanning is completed, event will be received:

```
%SCANEND: 1
```

5. View scan results:

```
AT%SCANCMD?  
%SCANCMD: 1300, 39, 019B6701, 26201, -110, -11, 5, 21030, 0  
%SCANCMD: 1444, 159, 019B6704, 26201, -111, -12, 3, 21030, 0  
%SCANCMD: 6200, 37, 01882517, 26203, -118, -18, 3, 51510, 0  
%SCANCMD: 6300, 137, 0141D401, 26202, -117, -13, 3, 48037, 0  
%SCANCMD: 6400, 340, 01CD460C, 26201, -119, -16, 3, 21005, 0  
OK
```

15.4 Activate GNSS

This section shows how to enable the GNSS feature of the Adrastea-I module.



GNSS cannot co-exist with LTE data transfer. LTE communication has higher priority over GNSS and, therefore, GNSS is automatically shut down once LTE is active (if it was active). While LTE is active, GNSS cannot be activated and all GNSS AT commands are responded with error.

1. Disable LTE prior to activating GNSS:

The following command will disable LTE radio.

```
AT+CFUN=0  
  
OK
```

2. Allow unsolicited notifications:

```
AT%IGNSSEV="SESSIONSTAT",1  
  
OK
```

3. Get available satellites:



It is necessary to check that there are at least 4 satellites available with an SNR>25.

```
AT%IGNSSINFO="SAT"  
%IGNSSINFO: 11  
%IGNSSINFO:03,36,294,49  
%IGNSSINFO:06,53,263,50  
%IGNSSINFO:14,42,180,50  
%IGNSSINFO:15,13,042,50  
%IGNSSINFO:16,08,251,50  
%IGNSSINFO:18,56,044,50  
%IGNSSINFO:19,25,314,50  
%IGNSSINFO:21,46,104,51  
%IGNSSINFO:22,71,306,49  
%IGNSSINFO:24,14,080,49  
%IGNSSINFO:27,51,282,50
```

4. Enable NMEA sentences (This command is required only when messages are required in GNSS tab of Adrastea Commander tool):

```
AT%IGNSSCFG="SET","NMEA","GGA","GSA","GSV","GNS","RMC"  
  
OK
```

5. Start GNSS:



For first time GNSS fix, cold start should be triggered to start GNSS.

The following command is used for cold GNSS start.

```
AT%IGNSSACT=1,1  
  
OK
```

The following command is used for hot GNSS Start.

```
AT%IGNSSACT=1,2
```

```
OK
```

6. Get fix:

```
AT%IGNSSINFO="FIX"
```

```
%IGNSSINFO: 2,"11:17:02","04/05/2020","32.195970","34.892572","  
-10.500000",1588580222000,1,"0.000000","B"
```

The following AT command is used to stop GNSS functionality:

```
AT%IGNSSACT=0
```

```
OK
```

15.5 Adrastea-I Power Saving Modes

15.5.1 DH0 Mode Setting

1. Check whether the DH0 state is configured

```
at%getacfg="pm.conf.max_allowed_pm_mode"  
dh0
```

```
OK
```

2. If the DH0 state is not already configured, configure the module to DH0 state with below AT command.

```
AT+CFUN=0
```

```
OK
```

```
at%setacfg="pm.conf.max_allowed_pm_mode","dh0"
```

```
OK
```

3. Reset the Adrastea-I.

```
ATZ
```

```
OK
```

4. Turn off the RF with the below AT command.

```
AT+CFUN=0
```

```
OK
```

5. Enter "CTRL+D" to close the CLI.

```
CTRL+D
```

```
MAP CLI Closed
```



To execute below commands default MCU firmware "PowerManager" shall be present in MCU.

6. The "pwrMode shutdown" command is used to configure MCU in shutdown state.

```
>>pwrMode shutdown
```

```
Configured to Shutdown mode, duration 0ms
```

7. The "sleepSet enable" command is used to enable MCU shutdown state.

```
>>sleepSet enable
```

```
Configured to Shutdown mode, duration 0ms
```



After following the above steps, the Adrastea-I module will now be in DH0 state and the MCU is shutdown.

15.5.2 DH1 Mode Setting

1. Check whether the DH1 state is configured

```
at%getacfg="pm.conf.max_allowed_pm_mode"  
dh1
```

```
OK
```

2. If the DH1 state is not already configured, configure the module to DH1 state with below AT command.

```
AT+CFUN=0
```

```
OK
```

```
at%setacfg="pm.conf.max_allowed_pm_mode","dh1"
```

```
OK
```

3. Reset the Adrastea-I.

```
ATZ
```

```
OK
```

4. Turn off the RF with the below AT command.

```
AT+CFUN=0
```

```
OK
```

5. Enter "CTRL+D" to close the CLI.

```
CTRL+D
```

```
MAP CLI Closed
```



To execute below commands default MCU firmware "PowerManager" shall be present in MCU.

6. The "pwrMode shutdown" command is used to configure MCU in shutdown state.

```
>>pwrMode shutdown
```

```
Configured to Shutdown mode, duration 0ms
```

7. The "sleepSet enable" command is used to enable MCU shutdown state.

```
>>sleepSet enable
```

```
Configured to Shutdown mode, duration 0ms
```



After following the above steps, the Adrastea-I module will now be in DH1 state and the MCU is shutdown.

15.5.3 DH2 Mode Setting

1. Check whether the DH2 state is configured

```
at%getacfg="pm.conf.max_allowed_pm_mode"  
dh2
```

```
OK
```

2. If the DH2 state is not already configured, configure the module to DH2 state with the below AT command.

```
AT+CFUN=0
```

```
OK
```

```
at%setacfg="pm.conf.max_allowed_pm_mode","dh2"
```

```
OK
```

3. Reset the Adrastea-I.

```
ATZ
```

```
OK
```

4. Turn off the RF with the below AT command.

```
AT+CFUN=0
```

```
OK
```

5. Enter "CTRL+D" to close the CLI.

```
CTRL+D
```

```
MAP CLI Closed
```



To execute below commands default MCU firmware "PowerManager" shall be present in MCU.

6. The "pwrMode shutdown" command is used to configure the MCU in shutdown state.

```
>>pwrMode shutdown
```

```
Configured to Shutdown mode, duration 0ms
```

7. The "sleepSet enable" command is used to enable the MCU shutdown state.

```
>>sleepSet enable
```

```
Configured to Shutdown mode, duration 0ms
```



After following the above steps, the Adrastea-I module will be in DH2 state and the MCU is shutdown.

15.6 Data connection with SOCKET commands

First check the internet connection is active, ping google server with IP address 8.8.8.8:

```
AT%PINGCMD=0,"8.8.8.8"  
%PINGCMD:1,"8.8.8.8",1042,58  
  
OK
```

15.6.1 UDP communication

1. Enable socket events:

```
AT%SOCKETEV=AT%SOCKETEV=0,1  
OK
```

2. Allocate socket session:

```
AT%SOCKETCMD="ALLOCATE",1,"UDP","OPEN","xxx.xxx.xxx.xxx",abc  
%SOCKETCMD:1  
  
OK
```

Where: Destination IP Address: xxx.xxx.xxx.xxx
Destination Port Number: abc

3. Below command can be used to check the status of created socket.

```
AT%SOCKETCMD?  
%SOCKETCMD:1,"DEACTIVATED"  
  
OK
```

4. Activate socket:

```
AT%SOCKETCMD="ACTIVATE",1  
OK
```

5. Send data via the socket:

Below command will send on socket_id 1 string "48656C6C6F2C20776F726C6421" string (i.e. Hello, World!), here length of string is 13.

```
AT%SOCKETDATA="SEND",1,13,"48656C6C6F2C20776F726C6421"  
%SOCKETDATA:1,13
```

```
OK
```

6. When data is received from the server on the specified socket ID, the following notification will appear:

```
%SOCKETEV:1,1
```

7. To read 2 bytes of data on socket:

```
AT%SOCKETDATA="RECEIVE",1,2  
%SOCKETDATA:1,2,2,"2002"
```

```
OK
```

8. To read all data upto maximum 1500 bytes:

```
AT%SOCKETDATA="RECEIVE",1,1500  
%SOCKETDATA:1,10,0,"400280B1D000400280B1"
```

```
OK
```

9. Below command can be used to read socket information:

```
AT%SOCKETCMD="INFO",1  
  
%SOCKETCMD:"ACTIVATED","UDP",,"128.112.132.235",49153,7  
  
OK
```

10. Below command can be used to delete specific socket ID allocation (including SSL session context if exist)

```
AT%SOCKETCMD="DELETE",1  
OK
```

15.6.2 DTLS communication

1. Load the User Certificate:

```
at%CERTCMD="write","ca-certificate.pem.crt",0,"-----BEGIN_
CERTIFICATE-----*****-----END_CERTIFICATE
-----"
OK
```

2. Load the User Certificate:

```
at%CERTCMD="write","ca-private.pem.key",1,"-----BEGIN_RSA_
PRIVATE_KEY-----*****-----END_RSA_PRIVATE_KEY
-----"
OK
```

3. Add certificates to the profile:

```
AT%CERTCFG="ADD",9,,,"ca-certificate.pem.crt","ca-private.pem.key"
OK
```



AT%CERTCMD="WRITE" command, avoid CR characters while pasting command. To do so, copy the command to an editor that supports EOL (end-of-line) format conversion and convert it to UNIX format (i.e., LF format). Then copy and paste this converted content to Adrastea Commander/PuTTY/teraterm.

4. Enable socket events:

```
AT%SOCKETEV=0,1
OK
```

5. Allocate socket session:

```
AT%SOCKETCMD="ALLOCATE",0,"UDP","OPEN","xxx.xxx.xxx.xxx",abc
%SOCKETCMD:1
OK
```

Where: Destination IP Address: xxx.xxx.xxx.xxx
Destination Port Number: abc

6. Add SSL for the specific socket:

```

-----BEGIN CERTIFICATE-----
MIIFAzCCA1OgAwIBAgIRAIQz7DSQONZRGFGu2OCiAwAwDQYJKoZIhvcNAQELBQAw
TzELMAkGA1UEBhMCVVMxKTAnBgNVBAoTIEludGVybmV0IFNlY3VyaXR5IFJlc2Vh
cmNoIEFkb3VwMRUwEwYDVQQDEwxCUjU1JHIFb3V3QgWDEwHhcNMTEwNjA0MTEwNDM4
WWhcNMzUwNjA0MTEwNDM4WjBPMQswCQYDVQQGEwJVVzEpMCCGA1UEChMgSW50ZXJu
ZXQgU2VjdXJpdHkgUmVzZWZyY2ggR3JvdXAxFtATBgNVBAMTDElUkcgUm9vdCBY
MTCCAIwDQYJKoZIhvcNAQEBBQADggIPADCCAggCgGIBAK3oJHP0FDfzm54rVygc
h77ct984kIxuPOZXoHj3dcKi/vVgbvYATyjb3miGbESTtrFj/RQSa78f0uoxmyF+
0TM8ukj13Xnfs7j/EvEhmkvBioZxaUpmZmyPffjxwv60pIgbz5MDmgK7iS4+3mX6U
A5/TR5d8mUgJU+g4rk8Kb4Mu0U1XjIB0ttov0DiNewNwIRt18jA8+o+u3dpjq+sW
T8KOEut+zwvo/7V3LvSye0rgTBi1DHCNAymg4VMk7BPZ7hm/ELNKjD+Jo2FR3qyH
B5T0Y3HsLuJvW5iB4Y1cNH1sdu87kGJ55tukmi8mxdAQ4Q7e2RCOFvu396j3x+UC
B5iPngiV5+I3lg02dZ77DnKxH2u8A/lJBdiB3QW0KtZB6awBdpUKD9jflb0SHzUv
KBds0pjBqAlkd25HN7rOrFleaJl/ctaJxQZBKT5ZPt0m9STJEadao0xAH0ahmbWn
O1FuhjuefXKnEgV4We0+UXgVCwOPjdAvBbI+e0ocS3MFEvzG6uBQE3xDk3SznTn
jh8BCNAw1FtxNrQHusEwMFxIt4I7mKZ9YIqioymCzLq9gwQbooMDQaHwBfEbwrbw
qHyG0aoSCqI3Haadr8faQU9GY/rOPNk3sgrDQoo//fb4hVC1CLQJl3hef4Y53CI
rU7m2Ys6xt0nUW7/vGT1M0NPAGMBAAGjQjBAMA4GA1UdDwEB/wQEAWIBBjAPBgNV
HRMBAf8EBTADAQH/MB0GA1UdDgQWBRR5tFnme7b15AFzgAiIyBpY9umbbjANBgkq
hkiG9w0BAQsFAAOCAgEAVR9YqbyyqFDQDLHYGmkjYkIrfGLXlpu+ILlaS/V91ZL
ubhzEFnTIZd+50xx+7LSYK05qAvqFyFWhfFQDlnrzuBZ6brJFe+GnY+EGPbk6ZG
3BebYhtF8GAV0nxvwo77x/Py9auJ/GpsMiu/Xl+mvoiB0v/2X/qkSsisRcOj/KK
NFtY2PwByVS5uCbMioGziUwthDyC3+6WVwW6LLv3xLFTjuCvjHIInNzktHCgKQ5
ORazI4JMPJ+GslWYHb4phowim57iaztXOoJwTdwJx4nLCgdNbOhdjsnvzqvHu7U
TkXWStAmzOVyyghqpZxjFaH3pO3JLF+1/+sKAiuvtd7u+Nxe5AW0wdeRlN8NwdC
jNPElpzVmbUq4JUagEiutDkHszHpFKVK7q4+63SM1N95R1NbdWhscdCb+ZAjzV
oyi3B43njTOQ5yOf+1CceWxG1bQVs5ZufpsMljg4Ui0/1lvh+wjChP4kqKOJ2qxg
4RgqsahDYVvTH9w7jXbyLeiNdd8XM2w9U/t7y0Ff/9yi0GE44Za4rF2LN9d11TPA
mRGunUHBcnWEvgJBQl9nJEiU0Zsnvgc/ubhPgXRR4Xq37Z0j4r7glSgEEzwxAS7d
emyPxcYxn/eR44/KJ4EBs+1VDR3veyJm+kXQ99b21/+jh5Xos1AnX5iitreGCC=
-----END CERTIFICATE-----

```

Figure 3: certificate-and-key-formate example

```
AT%SOCKETCMD="SSLALLOC",1,1,9
```

```
OK
```

7. Activate socket:

```
AT%SOCKETCMD="ACTIVATE",1
```

```
OK
```

8. Send data:

```
AT%SOCKETDATA="SEND",1,13,"48656C6C6F2C20776F726C6421"
%SOCKETDATA:1,13
```

```
OK
```

9. When data is received from the server on the specified socket ID, the following notification will appear:

```
%SOCKETEV:1,1
```

10. To read 2 bytes of data on socket:

```
AT%SOCKETDATA="RECEIVE",1,2  
%SOCKETDATA:1,2,2,"2002"
```

```
OK
```

11. To read all data upto maximum 1500 bytes:

```
AT%SOCKETDATA="RECEIVE",1,1500  
%SOCKETDATA:1,10,0,"400280B1D000400280B1"
```

```
OK
```


15.6.3 TCP communication

1. Enable socket events:

```
AT%SOCKETEV=0,1  
OK
```

2. Allocate socket session:

```
AT%SOCKETCMD="ALLOCATE",1,"TCP","OPEN","xxx.xxx.xxx.xxx",abc  
%SOCKETCMD:1  
  
OK
```

Where: Destination IP Address: xxx.xxx.xxx.xxx
Destination Port Number: abc

3. Below command can be used to check the status of created socket.

```
AT%SOCKETCMD?  
%SOCKETCMD:1,"DEACTIVATED"  
  
OK
```

4. Activate socket:

```
AT%SOCKETCMD="ACTIVATE",1  
OK
```

5. Send data via the socket:

Below command will send on socket_id 1 string "48656C6C6F2C20776F726C6421" string (i.e. Hello, World!), here length of string is 13.

```
AT%SOCKETDATA="SEND",1,13,"48656C6C6F2C20776F726C6421"  
%SOCKETDATA:1,13  
  
OK
```

6. When data is received from the server on the specified socket ID, the following notification will appear:

```
%SOCKETEV:1,1
```

7. To receive 2 bytes of data on socket:

```
AT%SOCKETDATA="RECEIVE",1,2  
%SOCKETDATA:1,2,2,"2002"
```

```
OK
```

8. To receive all data upto maximum 1500 bytes:

```
AT%SOCKETDATA="RECEIVE",1,1500
```

9. Below command can be used to read socket information:

```
AT%SOCKETCMD="INFO",1
```

```
%SOCKETCMD:"ACTIVATED","UDP",,"128.112.132.235",49153,7
```

```
OK
```

10. Below command can be used to delete specific socket ID allocation (including SSL session context if exist)

```
AT%SOCKETCMD="DELETE",1
```

```
OK
```

15.6.4 TLS communication

1. Load the User Certificate:

```
at%CERTCMD="write","ca-certificate.pem.crt",0,"-----BEGIN_
CERTIFICATE-----*****-----END_CERTIFICATE
-----"

OK
```

2. Load the User Certificate:

```
at%CERTCMD="write","ca-private.pem.key",1,"-----BEGIN_RSA_
PRIVATE_KEY-----*****-----END_RSA_PRIVATE_KEY
-----"

OK
```

3. Add certificates to the profile:

```
AT%CERTCFG="ADD",2,,,"ca-certificate.pem.crt","ca-private.pem.key"

OK
```



AT%CERTCMD="WRITE" command, avoid CR characters while pasting command. To do so, copy the command to an editor that supports EOL (end-of-line) format conversion and convert it to UNIX format (i.e., LF format). Then copy and paste this converted content to Adrastea Commander/PuTTY/teraterm.

4. Enable socket events:

```
AT%SOCKETEV=0,1

OK
```

5. Allocate a TCP socket:

```
AT%SOCKETCMD="ALLOCATE",0,"TCP","OPEN","xx.xx.xx.xx",abc
%SOCKETCMD:1

OK
```

Where: Destination IP Address: xxx.xxx.xxx.xxx
Destination Port Number: abc

6. Enable TLS and server certification verification:

```

-----BEGIN CERTIFICATE-----
MIIFAzCCA1OgAwIBAgIRAIQz7DSQONZRGFGu2OCiAwDQYJKoZIhvcNAQELBQAw
TzELMAkGA1UEBhMCVVMxKTAnBgNVBAoTIEludGVybmV0IFNlY3VyaXR5IFJlc2Vh
cmNoIEYdyb3VwMRUwEwYDVQQDEwxxJlU1JHIFJvb3QgWDEwHhcNMTEwNjA0MTEwNDM4
WWhcNMTEwNjA0MTEwNDM4WjBPMQswCQYDVQQGEwJVVzEpmMcCGA1UEChMgSW50ZXJu
ZXQgU2VjdXJpdHkgUmVzZWYyY2ggR3JvdXAxFTATBgNVBAMTDElUkcgUm9vdCBY
MTCCAIwDQYJKoZIhvcNAQEBBQADggIPADCCAggCggIBAK3oJHP0FDfzm54rVygc
h77ct984kIxuPOZXoHj3dcKi/vVgbvYATyjb3miGbESTtrFj/RQSa78f0uoxmyF+
0TM8ukj13Xnfs7j/EvEhmkvBioZxaUpmZmyPfxwv60pIgbz5MDmgk7iS4+3mX6U
A5/TR5d8mUgjU+g4rk8Kb4Mu0U1XjIB0ttov0DiNewNwIRt18jA8+o+u3dpjq+sW
T8KOEut+zwvo/7V3LvSye0rgTBi1DHCNAymg4VMk7BPZ7hm/ELNKjD+Jo2FR3qyH
B5T0Y3HsLuJvW5iB4Y1cNH1sdu87kGJ55tukmi8mxdAQ4Q7e2RCOFvu396j3x+UC
B5iPNgiV5+I3lg02dZ77DnKxH2u8A/lJBdiB3QW0KtZB6awBdpUKD9jflb0SHzUv
KBds0pjBqAlkd25HN7rOrFleaJl/ctaJxQZBKT5ZPt0m9STJEadao0xAH0ahmbWn
O1FuhjuefXKNEgV4We0+UXgVCwOPjdAvBbI+e0ocS3MFEvzG6uBQE3xDk3SznTn
jh8BCNAw1FtxNrQHusEwMFxIt4I7mKZ9YIqioymCzLq9gwQbooMDQaHwBfEbwrbw
qHyG0aoSCqI3Haadr8faQU9GY/rOPNk3sgrDQoo//fb4hVC1CLQJl3hef4Y53CI
rU7m2Ys6xt0nUW7/vGT1M0NPAGMBAAGjQjBAMA4GA1UdDwEB/wQEAwIBBjAPBgNV
HRMBAf8EBTADAQH/MB0GA1UdDgQWBRR5tFnme7b15AFzgAiIyBpY9umbbjANBgkq
hkiG9w0BAQsFAAOCAgEAVR9YqbyyqFDQDLHYGmkGjYkIrGFlXIpU+ILlaS/V91ZL
ubhzEFnTIZd+50xx+7LSYK05qAvqFyFWhfFQDlnrzuBZ6brJFe+GnY+EGPbk6ZGQ
3BebYhtF8GAV0nxvwuo77x/Py9auJ/GpsMiu/Xl+mvoiB0v/2X/qkSsisRcOj/KK
NFtY2PwByVS5uCbMioz2iUwthDyC3+6WVwW6LLv3xLFTjuCvJHIInNzktHCgKQ5
ORazI4JMPJ+GslWYHb4phowim57iaztXOoJwTdwJx4nLCgdNbOhdjsnvzqvHu7Ur
TkXWStAmzOVyyghqpZxjFaH3pO3JLF+1/+sKAiuvtd7u+Nxe5AW0wdeRlN8NwdC
jNPElpzVmbUq4JUagEiuTDkHszxHpFKVK7q4+63SM1N95R1NbdWhscdCb+ZAjzVc
oyi3B43njTOQ5yOf+1CceWxG1bQVs5ZufpsMljg4Ui0/1lvh+wjChP4kqKOJ2qxg
4RgqsahDYVvTH9w7jXbyLeiNdd8XM2w9U/t7y0FF/9yi0GE44za4rF2LN9d11TPA
mRGunUHBcnWEvgJBQl9nJEiU0Zsnvgc/ubhPgXRR4Xq37Z0j4r7g1SgEEzwxA57d
emyPxcYxn/eR44/KJ4EBs+1VDR3veyJm+kXQ99b21/+jh5Xos1AnX5iitreGCC=
-----END CERTIFICATE-----

```

Figure 4: certificate-and-key-formate example

```
AT%SOCKETCMD="SSLALLOC",1,0,2
```

```
OK
```

7. Activate socket:

```
AT%SOCKETCMD="ACTIVATE",1
```

```
OK
```

8. Send data to server:

```
AT%SOCKETDATA="SEND",1,13,"48656C6C6F2C20776F726C6421"
%SOCKETDATA:1,13
OK
```

9. Receive data sent by server:

```
%SOCKETEV:1,1
```

10. Read received data from socket:

```
AT%SOCKETDATA="RECEIVE",1,1500
```

11. Get socket info:

```
AT%SOCKETCMD="INFO",1
```

12. Delete socket:

```
AT%SOCKETCMD="DELETE",1
```

```
OK
```

15.7 HTTP connection

First check the internet connection is active, ping google server with IP address 8.8.8.8:

```
AT%PINGCMD=0,"8.8.8.8"  
%PINGCMD:1,"8.8.8.8",1042,58
```

```
OK
```

1. Enable HTTP event notification:

```
AT%HTTPEV="ALL",1
```

```
OK
```

2. Cleare previous HTTP configurations:

```
AT%HTTPCFG="CLEAR",1
```

```
OK
```

3. Configure the HTTP node (example.org/):

```
AT%HTTPCFG="NODES",1,"http://example.org/"
```

```
OK
```

4. Setup HTTP request format, set the format for the HTTP request to ensure proper communication. The parameters include method type, content type, and format::

```
AT%HTTPCFG="FORMAT",1,0,0,0
```

```
OK
```

5. HTTP GET request:

```
AT%HTTPCMD="GET",1
```

```
OK
```

```
%HTTPEVU:"GETRCV",1,0,218,218
```

6. Read HTTP response:

```
AT%HTTPREAD=1
```

```
%HTTPREAD: 218,218
```

```
{  
  "args": {},  
  "headers": {  
    "Accept": " */* ",  
    "Host": "httpbin.org",  
    "X-Amzn-Trace-Id": "Root=1-66fd117b-611  
      dbe8b5de9b62759e1cabf"  
  },  
  "origin": "3.76.246.25",  
  "url": "http://httpbin.org/get"  
}
```

7. HTTP POST:

```
AT%HTTPSEND="POST",1,1500
```

```
{ "message": "Here_is_some_json_l_post_upto_1500_bytes_60aaf4fe24...",  
  "code":42}
```

15.8 Secure HTTP (HTTPS) connection

First check the internet connection is active, ping google server with IP address 8.8.8.8:

```
AT%PINGCMD=0,"8.8.8.8"  
%PINGCMD:1,"8.8.8.8",1042,58  
  
OK
```

1. Enable HTTP event notification:

```
AT%HTTPEV="ALL",1  
  
OK
```

2. Clear previous HTTP configurations:

```
AT%HTTPCFG="CLEAR",1  
  
OK
```

3. Load the Certificate:

```
at%CERTCMD="write","ca-certificate.pem.crt",0,"-----BEGIN_  
CERTIFICATE-----*****-----END_CERTIFICATE  
-----"  
  
OK
```

4. Add certificates to the profile:

```
AT%CERTCFG="add",3,"ca-certificate.pem.crt","."  
  
OK
```

5. Configure TLS:

```
AT%HTTPCFG="TLS",1,2,3  
  
OK
```

[illegible]

Figure 5: certificate-example

6. Configure HTTP NODE:

AT%HTTPCFG="NODES",1,"https://www.we-online.com/en"

OK

7. HTTP GET request:

```
AT%HTTPCMD="GET",1
OK
%HTTPEVU:"GETRCV",1,0,218,218
```

8. Read HTTP response:

```
AT%HTTPREAD=1

%HTTPREAD: 218,218

{
  "args": {},
  "headers": {
    "Accept": " */* ",
    "Host": "httpbin.org",
    "X-Amzn-Trace-Id": "Root=1-66fd117b-611
      dbe8b5de9b62759e1cabf"
  },
  "origin": "3.76.246.25",
}
```



```
"url": "http://httpbin.org/get"  
}
```

9. HTTP POST:

```
AT%HTTPSEND="POST",1,1500  
{ "message": "Here_is_some_json_l_post_upto_1500_bytes_60aaf4fe24...",  
  "code":42}
```

15.9 MQTT connection

First check the internet connection is active, ping google server with IP address 8.8.8.8:

```
AT%PINGCMD=0,"8.8.8.8"  
%PINGCMD:1,"8.8.8.8",1042,58  
  
OK
```

1. Enable MQTT Event Notification:

```
AT%MQTTEV="all",1  
  
OK
```

2. Configuring the MQTT Broker: Configure the MQTT client to use a specific broker and set a client name. In this example, we use the HiveMQ broker.

```
AT%MQTTCFG="nodes",1,"Client_name","broker.hivemq.com"  
  
OK
```

3. Setting MQTT Protocol and Keep-Alive Interval: Configure the MQTT protocol and connection parameters. The command below sets the protocol version (0 for MQTT 3.1.1), a keep-alive interval of 1200 seconds, and enables clean sessions.

```
AT%MQTTCFG="PROTOCOL",1,0,1200,1  
  
OK
```

4. Establishing Connection to MQTT Broker:

```
AT%MQTTCMD="connect",1
```

```
OK
```

Expected Output, '0' at the end signifies that the connection with server has been established, 1 signifies it is not connected.

```
%MQTTEVU:"CONCONF",1,0
```

5. Subscribing to a Topic: Use the following command to subscribe to the desired topic "Subscribe_Topic". So, while publishing a message from any other 3rd party MQTT client from topic "Subscribe_Topic" on the above server/broker, the message will be visible on Adrastea-I.

```
AT%MQTTCMD="subscribe",1,2,"Subscribe_Topic"
```

Expected Output:

```
%MQTTCMD: 1
```

```
OK
```

```
%MQTTEVU:"SUBCONF",1,1,0
```

6. Publishing a Message to a Topic: To publish a message to a subscribed topic, use the publish command. The length of the message must be specified before publishing (In the following case, length is 11). So, while subscribing from any other MQTT Client on topic "Topic_name" on the above server, the message will be visible on the MQTT Client.

```
AT%MQTTCMD="publish",1,2,0,"Topic_name",11  
Hello world
```

Expected Output:

```
%MQTTCMD: 2
```

```
OK
```

```
%MQTTEVU:"PUBRCV",1,101,"Topic_name",11
```

```
Hello world
```

```
%MQTTEVU:"PUBCONF",1,2,0
```

15.10 Secure MQTT connection

First check the internet connection is active, ping google server with IP address 8.8.8.8:

```
AT%PINGCMD=0,"8.8.8.8"
%PINGCMD:1,"8.8.8.8",1042,58

OK
```

1. Load the User Certificate:

```
at%CERTCMD="write","ca-certificate.pem.crt",0,"-----BEGIN_
CERTIFICATE-----*****-----END_CERTIFICATE
-----"

OK
```

2. Load the private key:

```
at%CERTCMD="write","ca-private.pem.key",1,"-----BEGIN_RSA_
PRIVATE_KEY-----*****-----END_RSA_PRIVATE_KEY
-----"

OK
```

3. Add certificates to the profile:

```
AT%CERTCFG="ADD",9,,,"ca-certificate.pem.crt","ca-private.pem.key"

OK
```



AT%CERTCMD="WRITE" command, avoid CR characters while pasting command. To do so, copy the command to an editor that supports EOL (end-of-line) format conversion and convert it to UNIX format (i.e., LF format). Then copy and paste this converted content to Adrastea Commander/PuTTY/teraterm.

4. Add certificates to the profile:

```
AT%CERTCFG="ADD",1,,,"ca-certificate.pem.crt","ca-private.pem.key"

OK
```

5. Enable MQTT Event Notification:

```

-----BEGIN CERTIFICATE-----
MIIFAzCCA1OgAwIBAgIRAIQz7DSQONZRGFgu2OCiAwDQYJKoZIhvcNAQELBQAw
TzELMAkGA1UEBhMCVVMxKTAnBgNVBAoTIEludGVybmV0IFNlY3VyaXR5IFJlc2Vh
cmNoIEdyb3VwMRUwEwYDVQDEwXJ1JHIFJvb3QgWDEwHhcNMTEwNjA0MTEwNDM4
WWhcNMTEwNjA0MTEwNDM4WjBPMQswCQYDVQQGEwJUVjZEpMcGCA1UEChMgSW50ZXJu
ZXQgU2VjdXJpdHkgUmVzZWYyY2ggR3JvdXAxFTATBgNVBAMTDElUkcgUm9vdCBY
MTCCAIwDQYJKoZIhvcNAQEBBQADggIPADCCAgoCggIBAK3oJHP0FDfzm54rVygc
h77ct984kIxuPOZxHj3dcKi/vVgbvYATyjb3miGbESTtrFj/RQSa78f0uoxmyF+
0TM8ukj13Xnfs7j/EvEhmkvBioZxaUpmZmyPfxwv60pIgbz5MDmgK7iS4+3mX6U
A5/TR5d8mUgjU+g4rk8Kb4Mu0U1XjIB0ttov0DiNewNwIRt18jA8+o+u3dpjq+sW
T8KOEut+zwvo/7V3LvSye0rgTBiLDHCNAymg4VMk7BPZ7hm/ELNKjD+Jo2FR3qyH
B5T0Y3HsLuJvW5iB4Y1cNH1sdu87kGJ55tukmi8mxdAQ4Q7e2RCOFvu396j3x+UC
B5iPngiV5+I3lg02dZ77DnKxH2u8A/lJBdiB3QW0KtZB6awBdpUKD9jflb0SHzUv
KBds0pjBqAlkd25HN7rOrFleaJl/ctaJxQZBKT5ZPt0m9STJEadao0xAH0ahmbWn
O1FuhjuefXKNEgV4We0+UXgVCwOPjdAvBbI+e0ocS3MFEvzG6uBQE3xDk3SznTn
jh8BCNAw1FtxNrQHusEwMfxIt4I7mKZ9YIqioymCzLq9gwQbooMDQaHwBfEbwrwb
qHyG0aoSCqI3Haadr8faQU9GY/rOPNk3sgrDQoo//fb4hVC1CLQJl3hef4Y53CI
rU7m2Ys6xt0nUW7/vGT1M0NPagMBAAGjQjBAMA4GA1UdDwEB/wQEAwIBBjAPBgNV
HRMBAf8EBTADAQH/MB0GA1UdDgQWBRR5tFnme7b15AFzgAiIyBpY9umbbjANBgkq
hkiG9w0BAQsFAAOCAgEAVR9YqbyyqFDQDLHYGmkGjYkIrGf1XIpU+ILlaS/V91ZL
ubhzEFnTIZd+50xx+7LSYK05qAvqFyFWhfFQDlnrzuBZ6brJFe+GnY+EGPbk6ZGQ
3BebYhtF8GAV0nxvwuo77x/Py9auJ/GpsMiu/Xl+mvoiB0v/2X/qkSsisRcOj/KK
NFtY2PwByVS5uCbMioGziUwthDyC3+6WVwW6LLv3xLFTjuCvjHIInNzktHCgKQ5
ORazI4JMPJ+GslWYHb4phowim57iaztXOoJwTdwJx4nLCgdNbOhdjsnvzqvHu7Ur
TkXWStAmzOVyyghqp2XjFaH3pO3JLF+1/+sKAiuvtd7u+Nxe5AW0wdeR1N8NwdC
jNPElpzVmbUq4JUagEiuTDkHszHpFKVK7q4+63SM1N95R1NbdWhscdCb+ZAjzVc
oyi3B43njTOQ5yOf+1CceWxG1bQVs5ZufpsMljg4Ui0/1lvh+wjChP4kqKOJ2qxg
4RgqsahDYVvTH9w7jXbyLeiNdd8XM2w9U/t7y0Ff/9yi0GE44Za4rF2LN9d11TPA
mRGunUHBcnWEvgJBQl9nJEiU0Zsnvgc/ubhPgXRR4Xq37Z0j4r7glSgEEzwxAS7d
emyPxgcYxn/eR44/KJ4EBs+1VDR3veyJm+kXQ99b21/+jh5Xos1AnX5iItreGCC=
-----END CERTIFICATE-----

```

Figure 6: certificate-and-key-formate example

```
AT%MQTTEV="all",1
```

```
OK
```

6. Configure node parameters:

```
AT%MQTTCFG="NODES",1,"ALTTest","broker.hivemq.com"
```

```
OK
```

7. For secure connection port 8883 used (configurable):

```
AT%MQTTCFG="IP",1,,0,8883
```

```
OK
```

8. Configure TLS:

```
AT%MQTTCFG="TLS",1,0,0
```

```
OK
```

9. Establishing Connection to MQTT Broker:

```
AT%MQTTCMD="connect",1  
  
OK
```

Expected Output, '0' at the end signifies that the connection with server has been established, 1 signifies it is not connected.

```
%MQTTEVU:"CONCONF",1,0
```

10. Subscribing to a Topic: Use the following command to subscribe to the desired topic "Subscribe_Topic". So, while publishing a message from any other 3rd party MQTT client from topic "Subscribe_Topic" on the above server/broker, the message will be visible on Adrastea-I.

```
AT%MQTTCMD="subscribe",1,2,"Subscribe_Topic"
```

Expected Output:

```
%MQTTCMD: 1  
OK  
  
%MQTTEVU:"SUBCONF",1,1,0
```

11. Publishing a Message to a Topic: To publish a message to a subscribed topic, use the publish command. The length of the message must be specified before publishing (In the following case, length is 11). So, while subscribing from any other MQTT Client on topic "Topic_name" on the above server, the message will be visible on the MQTT Client.

```
AT%MQTTCMD="publish",1,2,0,"Topic_name",11  
Hello world
```

Expected Output:

```
%MQTTCMD: 2  
OK  
%MQTTEVU:"PUBRCV",1,101,"Topic_name",11  
Hello world  
%MQTTEVU:"PUBCONF",1,2,0
```

15.11 Steps for FOTA Update

Sequence of AT commands required to perform a FOTA update on the Adrastea-I module using an HTTP server.

To perform the FOTA (Firmware Over-The-Air) update, the "update.ua" file is required. This file contains the delta changes between the base firmware and the target firmware. Once the "update.ua" file is available, it should be uploaded to an HTTP server (an HTTP server must be available for this purpose).

For testing purposes, the "update.ua" file can be generated once the base version and target version of the MCU firmware are provided.

FOTA testing can then be performed using below sequence of AT commands.

1. Clearing Previous HTTP Configurations:

```
AT%HTTPCFG="CLEAR",3
```

```
OK
```

2. Enabling HTTP Event Notification:

```
AT%HTTPEV="ALL",1
```

```
OK
```

3. Enabling HTTP Event Notification: Configure the HTTP node with the URL of the HTTP server where the FOTA update file (update.ua) is stored. Replace xxxx with the actual http server address:

```
AT%HTTPCFG="NODES",3,"http://xxxx/fota/update.ua"
```

```
OK
```

4. Re-enable HTTP Event Notifications: To ensure event notifications are active during the update, re-enable HTTP event notifications:

```
AT%HTTPEV="ALL",1
```

```
OK
```

5. Setting the Request Format: Set the request format to ensure proper communication during the FOTA process:

```
AT%HTTPCFG="FORMAT",3,0,0,0
```

```
OK
```

6. Initiating the FOTA Download: To initiate the FOTA download from the configured HTTP server, use the following command:

```
AT%HTTPFOTAGET=3
```

```
OK
```

Expected Output:

```
OK  
%HTTPEVU:"FOTADLRES",3,0
```

The FOTADLRES response indicates that the firmware download has been successfully initiated.

7. Reboot the system:

```
ATZ
```



Be noted: During firmware upgrade, AT com port would not have any response, until Adrastea-I responses the URC %SCMNOTIFYEV:"Adrastea-IReady" then starting to use AT commands.

16 References

- [1] Würth Elektronik. Adrastea Commander. <http://www.we-online.com/Adrastea-Commander>.
- [2] Würth Elektronik. ADRASTEIA-I EVALUATION BOARD MANUAL. <https://we-online.com/katalog/en/manual/2615029236001>.
- [3] Würth Elektronik. Adrastea-I user manual. <https://www.we-online.de/katalog/de/manual/2615011136000>.

17 Important notes

The following conditions apply to all goods within the wireless connectivity and sensors product range of Würth Elektronik eiSos GmbH & Co. KG:

General customer responsibility

Some goods within the product range of Würth Elektronik eiSos GmbH & Co. KG contain statements regarding general suitability for certain application areas. These statements about suitability are based on our knowledge and experience of typical requirements concerning the areas, serve as general guidance and cannot be estimated as binding statements about the suitability for a customer application. The responsibility for the applicability and use in a particular customer design is always solely within the authority of the customer. Due to this fact, it is up to the customer to evaluate, where appropriate to investigate and to decide whether the device with the specific product characteristics described in the product specification is valid and suitable for the respective customer application or not. Accordingly, the customer is cautioned to verify that the documentation is current before placing orders.

Customer responsibility related to specific, in particular safety-relevant applications

It has to be clearly pointed out that the possibility of a malfunction of electronic components or failure before the end of the usual lifetime cannot be completely eliminated in the current state of the art, even if the products are operated within the range of the specifications. The same statement is valid for all software source code and firmware parts contained in or used with or for products in the wireless connectivity and sensor product range of Würth Elektronik eiSos GmbH & Co. KG. In certain customer applications requiring a high level of safety and especially in customer applications in which the malfunction or failure of an electronic component could endanger human life or health, it must be ensured by most advanced technological aid of suitable design of the customer application that no injury or damage is caused to third parties in the event of malfunction or failure of an electronic component.

Best care and attention

Any product-specific data sheets, manuals, application notes, PCNs, warnings and cautions must be strictly observed in the most recent versions and matching to the products revisions. These documents can be downloaded from the product specific sections on the wireless connectivity and sensors homepage.

Customer support for product specifications

Some products within the product range may contain substances, which are subject to restrictions in certain jurisdictions in order to serve specific technical requirements. Necessary information is available on request. In this case, the Business Development Engineer (BDM) or the internal sales person in charge should be contacted who will be happy to support in this matter.

Product improvements

Due to constant product improvement, product specifications may change from time to time. As a standard reporting procedure of the Product Change Notification (PCN) according to the JEDEC-Standard, we inform about major changes. In case of further queries regarding the PCN, the Business Development Engineer (BDM), the internal sales person or the technical support team in charge should be contacted. The basic responsibility of the customer as per section 17 and 17 remains unaffected.

All software like "wireless connectivity SDK", "Sensor SDK" or other source codes as well as all PC software tools are not subject to the Product Change Notification information process.

Product life cycle

Due to technical progress and economical evaluation, we also reserve the right to discontinue production and delivery of products. As a standard reporting procedure of the Product Termination Notification (PTN) according to the JEDEC-Standard we will inform at an early stage about inevitable product discontinuance. According to this, we cannot ensure that all products within our product range will always be available. Therefore, it needs to be verified with the Business Development Engineer (BDM) or the internal sales person in charge about the current product availability expectancy before or when the product for application design-in disposal is considered. The approach named above does not apply in the case of individual agreements deviating from the foregoing for customer-specific products.

Property rights

All the rights for contractual products produced by Würth Elektronik eiSos GmbH & Co. KG on the basis of ideas, development contracts as well as models or templates that are subject to copyright, patent or commercial protection supplied to the customer will remain with Würth Elektronik eiSos GmbH & Co. KG. Würth Elektronik eiSos GmbH & Co. KG does not warrant or represent that any license, either expressed or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, application, or process in which Würth Elektronik eiSos GmbH & Co. KG components or services are used.

General terms and conditions

Unless otherwise agreed in individual contracts, all orders are subject to the current version of the "General Terms and Conditions of Würth Elektronik eiSos Group", last version available at www.we-online.com.

18 Legal notice

Exclusion of liability

Würth Elektronik eiSos GmbH & Co. KG considers the information in this document to be correct at the time of publication. However, Würth Elektronik eiSos GmbH & Co. KG reserves the right to modify the information such as technical specifications or functions of its products or discontinue the production of these products or the support of one of these products without any written announcement or notification to customers. The customer must make sure that the information used corresponds to the latest published information. Würth Elektronik eiSos GmbH & Co. KG does not assume any liability for the use of its products. Würth Elektronik eiSos GmbH & Co. KG does not grant licenses for its patent rights or for any other of its intellectual property rights or third-party rights.

Notwithstanding anything above, Würth Elektronik eiSos GmbH & Co. KG makes no representations and/or warranties of any kind for the

provided information related to their accuracy, correctness, completeness, usage of the products and/or usability for customer applications. Information published by Würth Elektronik eiSos GmbH & Co. KG regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof.

Suitability in customer applications

The customer bears the responsibility for compliance of systems or units, in which Würth Elektronik eiSos GmbH & Co. KG products are integrated, with applicable legal regulations. Customer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of Würth Elektronik eiSos GmbH & Co. KG components in its applications, notwithstanding any applications-related information or support that may be provided by Würth Elektronik eiSos GmbH & Co. KG. Customer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences lessen the likelihood of failures that might cause harm and take appropriate remedial actions. The customer will fully indemnify Würth Elektronik eiSos GmbH & Co. KG and its representatives against any damages arising out of the use of any Würth Elektronik eiSos GmbH & Co. KG components in safety-critical applications.

Trademarks

AMBER wireless is a registered trademark of Würth Elektronik eiSos GmbH & Co. KG. All other trademarks, registered trademarks, and product names are the exclusive property of the respective owners.

Usage restriction

Würth Elektronik eiSos GmbH & Co. KG products have been designed and developed for usage in general electronic equipment only. This product is not authorized for use in equipment where a higher safety standard and reliability standard is especially required or where a failure of the product is reasonably expected to cause severe personal injury or death, unless the parties have executed an agreement specifically governing such use. Moreover, Würth Elektronik eiSos GmbH & Co. KG products are neither designed nor intended for use in areas such as military, aerospace, aviation, nuclear control, submarine, transportation (automotive control, train control, ship control), transportation signal, disaster prevention, medical, public information network etc. Würth Elektronik eiSos GmbH & Co. KG must be informed about the intent of such usage before the design-in stage. In addition, sufficient reliability evaluation checks for safety must be performed on every electronic component, which is used in electrical circuits that require high safety and reliability function or performance. By using Würth Elektronik eiSos GmbH & Co. KG products, the customer agrees to these terms and conditions.

19 License terms

These License terms will take effect upon the purchase and usage of the Würth Elektronik eiSos GmbH & Co. KG wireless connectivity products. You hereby agree that these license terms are applicable to the product and the incorporated software, firmware and source codes (collectively, "Software") made available by Würth Elektronik eiSos in any form, including but not limited to binary, executable or source code form. The software included in any Würth Elektronik eiSos wireless connectivity product is purchased to you on the condition that you accept the terms and conditions of these license terms. You agree to comply with all provisions under these license terms.

Limited license

Würth Elektronik eiSos hereby grants you a limited, non-exclusive, non-transferable and royalty-free license to use the software and under the conditions that will be set forth in these license terms. You are free to use the provided software only in connection with one of the products from Würth Elektronik eiSos to the extent described in these license terms. You are entitled to change or alter the source code for the sole purpose of creating an application embedding the Würth Elektronik eiSos wireless connectivity product. The transfer of the source code to third parties is allowed to the sole extent that the source code is used by such third parties in connection with our product or another hardware provided by Würth Elektronik eiSos under strict adherence of these license terms. Würth Elektronik eiSos will not assume any liability for the usage of the incorporated software and the source code. You are not entitled to transfer the source code in any form to third parties without prior written consent of Würth Elektronik eiSos.

You are not allowed to reproduce, translate, reverse engineer, decompile, disassemble or create derivative works of the incorporated software and the source code in whole or in part. No more extensive rights to use and exploit the products are granted to you.

Usage and obligations

The responsibility for the applicability and use of the Würth Elektronik eiSos wireless connectivity product with the incorporated firmware in a particular customer design is always solely within the authority of the customer. Due to this fact, it is up to you to evaluate and investigate, where appropriate, and to decide whether the device with the specific product characteristics described in the product specification is valid and suitable for your respective application or not.

You are responsible for using the Würth Elektronik eiSos wireless connectivity product with the incorporated firmware in compliance with all applicable product liability and product safety laws. You acknowledge to minimize the risk of loss and harm to individuals and bear the risk for failure leading to personal injury or death due to your usage of the product.

Würth Elektronik eiSos' products with the incorporated firmware are not authorized for use in safety-critical applications, or where a failure of the product is reasonably expected to cause severe personal injury or death. Moreover, Würth Elektronik eiSos' products with the incorporated firmware are neither designed nor intended for use in areas such as military, aerospace, aviation, nuclear control, submarine, transportation (automotive control, train control, ship control), transportation signal, disaster prevention, medical, public information network etc. You shall inform Würth Elektronik eiSos about the intent of such usage before design-in stage. In certain customer applications requiring a very high level of safety and in which the malfunction or failure of an electronic component could endanger human life or health, you must ensure to have all necessary expertise in the safety and regulatory ramifications of your applications. You acknowledge and agree that you are solely responsible for all legal, regulatory and safety-related requirements concerning your products and any use of Würth Elektronik eiSos' products with the incorporated firmware in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by Würth Elektronik eiSos. **YOU SHALL INDEMNIFY WÜRTH ELEKTRONIK EISOS AGAINST ANY DAMAGES ARISING OUT OF THE USE OF WÜRTH ELEKTRONIK EISOS' PRODUCTS WITH THE INCORPORATED FIRMWARE IN SUCH SAFETY-CRITICAL APPLICATIONS.**

Ownership

The incorporated firmware created by Würth Elektronik eiSos is and will remain the exclusive property of Würth Elektronik eiSos.

Firmware update(s)

You have the opportunity to request the current and actual firmware for a bought wireless connectivity product within the time of warranty. However, Würth Elektronik eiSos has no obligation to update a modules firmware in their production facilities, but can offer this as a service on request. The upload of firmware updates falls within your responsibility, e.g. via ACC or another software for firmware updates. Firmware updates will not be communicated automatically. It is within your responsibility to check the current version of a firmware in the latest version of the product manual on our website. The revision table in the product manual provides all necessary information about firmware updates. There is no right to be provided with binary files, so called "firmware images", those could be flashed through JTAG, SWD, Spi-Bi-Wire, SPI or similar interfaces.

Disclaimer of warranty

THE FIRMWARE IS PROVIDED "AS IS". YOU ACKNOWLEDGE THAT WÜRTH ELEKTRONIK EISOS MAKES NO REPRESENTATIONS AND WARRANTIES OF ANY KIND RELATED TO, BUT NOT LIMITED TO THE NON-INFRINGEMENT OF THIRD PARTIES' INTELLECTUAL PROPERTY RIGHTS OR THE MERCHANTABILITY OR FITNESS FOR YOUR INTENDED PURPOSE OR USAGE. WÜRTH ELEKTRONIK EISOS DOES NOT WARRANT OR REPRESENT THAT ANY LICENSE, EITHER EXPRESS OR IMPLIED, IS GRANTED UNDER ANY PATENT RIGHT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT RELATING TO ANY COMBINATION, MACHINE, OR PROCESS IN WHICH THE WÜRTH ELEKTRONIK EISOS' PRODUCT WITH THE INCORPORATED FIRMWARE IS USED. INFORMATION PUBLISHED BY WÜRTH ELEKTRONIK EISOS REGARDING THIRD-PARTY PRODUCTS OR SERVICES DOES NOT CONSTITUTE A LICENSE FROM WÜRTH ELEKTRONIK EISOS TO USE SUCH PRODUCTS OR SERVICES OR A WARRANTY OR ENDORSEMENT THEREOF.

Limitation of liability

Any liability not expressly provided by Würth Elektronik eiSos shall be disclaimed.

You agree to hold us harmless from any third-party claims related to your usage of the Würth Elektronik eiSos' products with the incorporated firmware, software and source code. Würth Elektronik eiSos disclaims any liability for any alteration, development created by you or your customers as well as for any combination with other products.

Applicable law and jurisdiction

Applicable law to these license terms shall be the laws of the Federal Republic of Germany. Any dispute, claim or controversy arising out of or relating to these license terms shall be resolved and finally settled by the court competent for the location of Würth Elektronik eiSos registered office.

Severability clause

If a provision of these license terms is or becomes invalid, unenforceable or null and void, this shall not affect the remaining provisions of the terms. The parties shall replace any such provisions with new valid provisions that most closely approximate the purpose of the terms.

Miscellaneous

Würth Elektronik eiSos reserves the right at any time to change these terms at its own discretion. It is your responsibility to check at Würth Elektronik eiSos homepage for any updates. Your continued usage of the products will be deemed as the acceptance of the change.

We recommend you to be updated about the status of new firmware and software, which is available on our website or in our data sheet and manual, and to implement new software in your device where appropriate.

By ordering a product, you accept these license terms in all terms.

List of Figures

1	Adrastea-I	12
2	certificate-formate	123
3	certificate-and-key-formate example	298
4	certificate-and-key-formate example	303
5	certificate-example	307
6	certificate-and-key-formate example	311

List of Tables

1	Module Key Features	13
2	AT Command Syntax and Types	19
3	AT+CGMI	20
4	AT+CGMM	21
5	AT+CGMR	22
6	AT+CGSN	24
7	+CGSN_Description	24
8	AT+GSN	26
9	AT+CIMI	27
10	AT+CSCS	28
11	+CSCS_Description	28
12	AT+GCAP	30
13	AT+CFUN	31
14	+CFUN_FUN_Description	31
15	+CFUN_RST_Description	31
16	AT+CGATT	33
17	+CGATT_State_Description	33
18	ATZ	34
19	ATI	35
20	ATF0	36
21	ATV	37
22	ATV_Description	37
23	ATVE	37
24	ATE_Description	38
25	AT&K	38
26	ATK_Description	38
27	ATQ	38
28	ATK_Description	39
29	ATQ_Value_Description	39
30	AT+COPN	40
31	AT+COPS	41
32	+COPS_Mode_Description	43
33	+COPS_Format_Description	43
34	+COPS_Format_Description	44
35	+COPS_Stat_Description	44
36	+COPS_Act_Description	44

37	AT+CSQ	45
38	+CSQ_rssi_Description	45
39	+CSQ_Ber_Description	45
40	AT+CESQ	46
41	+CESQ_rsrq_Description	46
42	+CESQ_rsrp_Description	47
43	AT+CPSMS	48
44	+CPSMS_Mode_Description	49
45	CPSMS_T3412_Timer_value	49
46	CPSMS_Active_Timer_value	50
47	AT+CEDRXRDP	51
48	+CEDRXRDP_Act_Type_Description	51
49	NW_Provided_eDRX_Value	52
50	LTEM_PTW_Value	53
51	NB-IoT_PTW_Value	54
52	AT+CEDRXS	55
53	+CEDRXS_Act_Description	56
54	+CEDRXS_Act_Type_Description	56
55	Requested_eDRX_Value	57
56	AT+CRCES	58
57	+CRCES_Act_Description	58
58	+CRCES_CE_Level_Description	59
59	+CRCES_CC_Description	59
60	AT+CSODCP	60
61	+CSODCP_RAI_Description	61
62	+CSODCP_Type_of_data_Description	61
63	AT+CRTDCP	62
64	+CRTDCP_Reporting_Description	62
65	AT+CCIOPT	63
66	+CCIOPT_n_Description	64
67	+CCIOPT_Supported_UE_OPT_Description	64
68	+CCIOPT_Prefered_UE_OPT_Description	64
69	+CCIOPT_Supported_Network_OPT_Description	64
70	AT+CIMI	65
71	AT+CLCK	66
72	+CLCK_fac_Description	66
73	+CLCK_Mode_Description	66
74	+CLCK_Status_Description	67
75	AT+CNUM	68
76	+CNUM_Service_Description	68
77	+CNUM_ITC_Description	69
78	AT+CPIN	70
79	+CPIN_code_Description	71
80	AT+CPWD	72
81	+CPWD_fac_Description	72
82	AT+CRSM	74
83	+CRSM_command_Description	74
84	AT+CRSM	76

85	+CCID_iccid_Description	76
86	AT%CSQ	77
87	CSQ_RSSI_Description	77
88	CSQ_Ber_Description	77
89	CSQ_RSSQ_Description	78
90	AT%CMATT	79
91	%CMATT_State_Description	79
92	AT%CPININFO	80
93	AT%STATUS	83
94	%STATUS_Sub_System_Description	83
95	%STATUS_State_Description	84
96	%STATUS_USIM_State_Description	84
97	%STATUS_IPS_State_Description	84
98	%STATUS_AMBR_State_Description	85
99	%STATUS_RRC_State_Description	85
100	%STATUS_SEC_State_Description	85
101	%STATUS_ROAM_State_Description	85
102	%STATUS_CSPS_State_Description	86
103	%STATUS_WDIS_State_Description	86
104	%STATUS_UICC_State_Description	86
105	%STATUS_TEMPM_State_Description	86
106	%STATUS_DSIMA_State_Description	87
107	%STATUS_PSM_State_Description	87
108	%STATUS_EMM_State_Description	88
109	%STATUS_ATT_Status_Info_Description	88
110	%STATUS_BOOT_Status_Info_Description	89
111	%STATUS_REGCMD_Status_Info_Description	89
112	AT%RATACT	90
113	%RATACT_RAT_Description	91
114	%RATACT_Storage_Description	91
115	%RATACT_Source_Description	91
116	%RATACT_RAT_Mode_Description	91
117	AT%MEAS	94
118	%MEAS_Measurement_Type_Description	96
119	AT%NWOPER	99
120	%NWOPER_Oper_Name_Description	100
121	AT%PDNSET	102
122	%PDNSET_IP_TYPE_Description	103
123	%PDNSET_pscsf_discovery_Description	103
124	%PDNSET_IPv4AddrAlloc_discovery_Description	103
125	%PDNSET_NSLPI_discovery_Description	104
126	AT%SETBDELAY	105
127	AT%SCAN	106
128	%SCAN_Cmd_Description	106
129	%SCAN_Mode_Description	106
130	%SCAN_BW_Description	107
131	%SCAN_Res_Description	107
132	AT%SCANCFG	109

133	%SCANCFG_RS_CONFIG_Description	110
134	%SCANCFG_SL_CONFIG_Description	110
135	AT%SCANCMD	111
136	%SCANCMD_cmd_Description	111
137	%SCANCMD_mode_Description	112
138	%SCANCMD_stat_Description	112
139	%SCANCMD_cstat_Description	112
140	AT%DNSRSLV	113
141	%DNSRSLV_ADDR_IP_TYPE_Description	113
142	%DNSRSLV_IP_TYPE_Description	113
143	AT%NOTIFYEV	115
144	%NOTIFYEV_EV_TYPE_Description	116
145	%NOTIFYEV_Mode_Description	116
146	%NOTIFYEV_Param_Description	117
147	%NOTIFYEV_SIMD_Description	117
148	%NOTIFYEV_ROAM_Description	117
149	%NOTIFYEV_CSPS_Description	117
150	%NOTIFYEV_SIMSTATE_Description	118
151	%NOTIFYEV_RRC_STATE_Description	118
152	%NOTIFYEV_EMM_State_Description	119
153	%NOTIFYEV_SIMREFRESH_Description	120
154	AT%PINGCMD	121
155	%PINGCMD_IP_TYPE_Description	121
156	AT%CERTCMD	123
157	%CERTCMD_CMD_Description	124
158	%CERTCMD_Type_Description	124
159	AT%CERTCFG	128
160	%CERTCFG_Op_Description	129
161	AT%CPSMS	132
162	%CPSMS_Cmd_Description	133
163	%CPSMS_param1_Description	133
164	%CPSMS_state_Description	133
165	%CPSMS_Act_Description	133
166	%CPSMS_Event_Description	134
167	AT%TSTRF	134
168	%TSTRF_cmd_Description	135
169	%TSTRF_time_Description	135
170	%TSTRF_Param1_Description	135
171	%TSTRF_Param3_Description	136
172	%TSTRF_Param4_Description	136
173	%TSTRF_Param5_Description	137
174	%TSTRF_status_Description	137
175	AT%VER	138
176	AT+CEREG	140
177	+CEREG_N_Description	141
178	+CEREG_Stat_Description	141
179	+CEREG_ActDescription	142
180	+CEREG_Cause_Type_Description	142

181	+CEREG_Active_Timer_value	142
182	CEREG_T3412_Timer_value	143
183	AT+CGEREP	145
184	+CGEREP_Mode_Description	145
185	+CGEREP_bfr_Description	145
186	AT+CGDCONT	147
187	AT+CGACT	150
188	+CGACT_State_Description	151
189	AT+CGAUTH	152
190	+CGAUTH_auth_prot_Description	153
191	AT+CEMODE	153
192	+CEMODE_Mode_Description	154
193	AT+CGCMOD	154
194	AT+CEMODE	155
195	+IM_CN_Signalling_Flag_Description	156
196	+IM_CN_Signalling_Flag_Description	157
197	AT+CGEQOS	157
198	+CGEQOS_QCI_Description	158
199	AT+CGPADDR	158
200	AT%FILECMD	160
201	%FILEDATA_Cmd_Description	161
202	%FILEDATA_put_param2_Description	162
203	%FILEDATA_get_param2_Description	162
204	%FILEDATA_notify_param1_Description	162
205	%FILEDATA_preerase_param1_Description	163
206	%FILEDATA_dir_param1_Description	163
207	%FILEDATA_dinfo_param1_Description	164
208	%FILEDATA_dinfo_entrytype_Description	164
209	%FILEDATA_dinfo_drive_Description	164
210	AT%FILEDATA	165
211	%FILEDATA_cmd_Description	165
212	%FILEDATA_write_param1_Description	165
213	%FILEDATA_more2read_Description	166
214	%FILEDATA_res_Description	166
215	AT+CMGF	167
216	+CMGF_mode_Description	167
217	AT+CMGD	169
218	+CMGD_DeIFlag_Description	169
219	AT+CMGL	170
220	+CMGL_stat_Description	171
221	AT+CMGR	172
222	+CMGR_stat_Description	173
223	AT+CMGS	175
224	AT+CMGW	178
225	+CMGW_stat_Description	178
226	AT+CMSS	180
227	AT+CNMI	181
228	+CNMI_mode_Description	181

229	+CNMI_mt_Description	182
230	+CNMI_ds_Description	182
231	+CNMI_bfr_Description	183
232	AT+CPMS	184
233	+CPMS_mem1_Description	184
234	+CPMS_mem2_Description	185
235	+CPMS_mem3_Description	185
236	AT+CSCA	186
237	AT+CSDH	187
238	+CSDH_show_Description	187
239	AT+CSMP	188
240	AT+CSMS	189
241	+CSMS_Service_Description	189
242	+CSMS_mt_mo_Description	189
243	AT+CSMS	190
244	AT%SOCKETCMD	192
245	%SOCKETCMD_cmd_Description	194
246	%SOCKETCMD_Param1_Description	195
247	%SOCKETCMD_Param2_Description	195
248	%SOCKETCMD_Param3_Description	195
249	%SOCKETCMD_Param4_Description	195
250	%SOCKETCMD_Param5_Description	195
251	%SOCKETCMD_Param6_Description	196
252	%SOCKETCMD_Param7_Description	196
253	%SOCKETCMD_Param8_Description	196
254	%SOCKETCMD_Param9_Description	196
255	%SOCKETCMD_ACTIVATE_Param1_Description	196
256	%SOCKETCMD_INFO_Param1_Description	197
257	%SOCKETCMD_DEACTIVATE_Param1_Description	197
258	%SOCKETCMD_DEACTIVATE_Param2_Description	197
259	%SOCKETCMD_FASTSEND_Param1_Description	197
260	%SOCKETCMD_FASTSEND_Param2_Description	197
261	%SOCKETCMD_FASTSEND_Param3_Description	198
262	%SOCKETCMD_DELETE_Param1_Description	198
263	%SOCKETCMD_DELETE_Param2_Description	198
264	%SOCKETCMD_LASTERROR_Param1_Description	198
265	%SOCKETCMD_CONFSEND_Param1_Description	198
266	%SOCKETCMD_CONFSEND_Param2_Description	199
267	%SOCKETCMD_CONFSEND_Param3_Description	199
268	%SOCKETCMD_CONFSEND_Param4_Description	199
269	%SOCKETCMD_SSLALLOC_Param1_Description	199
270	%SOCKETCMD_SSLALLOC_Param2_Description	199
271	%SOCKETCMD_SSLALLOC_Param4_Description	200
272	%SOCKETCMD_SSLINFO_Param1_Description	200
273	%SOCKETCMD_SETOPT_Param1_Description	200
274	%SOCKETCMD_SETOPT_Param2_Description	200
275	%SOCKETCMD_SETOPT_Param3_Description	201
276	%SOCKETCMD_SETOPT_Param4_Description	201

277	%SOCKETCMD_SSLKEEP_Param1_Description	201
278	%SOCKETCMD_SSLDEL_Param1_Description	201
279	%SOCKETCMD_SSLDEL_Param2_Description	202
280	%SOCKETCMD_SSLDEL_Param3_Description	202
281	%SOCKETCMD_SSLDEL_Param4_Description	202
282	%SOCKETCMD_SSLDEL_Param5_Description	202
283	%SOCKETCMD_SSLDEL_Param6_Description	202
284	%SOCKETCMD_SSLDEL_Param8_Description	202
285	%SOCKETCMD_SSLDEL_Param9_Description	203
286	%SOCKETCMD_SSLDEL_Param10_Description	203
287	%SOCKETCMD_Socket_Error_Description	203
288	AT%SOCKETDATA	205
289	%SOCKETDATA_Cmd_Description	206
290	%SOCKETDATA_SEND_Param1_Description	206
291	%SOCKETDATA_SEND_Param2_Description	206
292	%SOCKETDATA_RECEIVE_Param1_Description	206
293	%SOCKETDATA_RECEIVE_Param2_Description	206
294	%SOCKETDATA_RECEIVE_rlength_Description	207
295	%SOCKETDATA_RECEIVE_rdata_Description	207
296	%SOCKETDATA_RECEIVE_wlength_Description	207
297	AT%MF_SOCKETDATA	208
298	%MF_SOCKETDATA_cmd_Description	208
299	AT%SOCKETEV	210
300	%SOCKETEV_Event_Id_Description	211
301	%SOCKETEV_mode_Description	211
302	AT%HTTPCFG	212
303	%HTTPCFG_Obj_Description	213
304	AT%HTTPCMD	215
305	%HTTPCMD_Cmd_Description	215
306	AT%HTTPSEND	216
307	%HTTPSEND_Cmd_Description	216
308	AT%HTTPREAD	218
309	AT%HTTPFOTAGET	219
310	AT%HTTPPEV	220
311	%HTTPPEV_EV_Type_Description	220
312	AT%IGNSSACT	224
313	IGNSSACT_Mode_Description	224
314	IGNSSACT_Cmd_Start	225
315	IGNSSACT_Tolerance_Description	225
316	IGNSSACT_Active_Mode_Description	225
317	AT%IGNSSCFG	226
318	IGNSSCFG_Operation_Description	226
319	IGNSSCFG_Category_Description	226
320	IGNSSCFG_SAT_Description	227
321	IGNSSCFG_NMEA_Description	227
322	AT%IGNSSINFO	228
323	IGNSSINFO_Type_Description	228
324	IGNSSINFO_PRN_Description	229

325	IGNSSINFO_Elevation_Mode_Description	229
326	IGNSSINFO_Azimuth_Mode_Description	229
327	IGNSSINFO_SNR_Description	229
328	IGNSSINFO_Fix_Type_Description	229
329	IGNSSINFO_EPH_Type_Description	230
330	IGNSSINFO_EPH_Status_Description	230
331	AT%IGNSSEV	232
332	IGNSSEV_Event_Description	232
333	IGNSSEV_Mode_Description	232
334	IGNSSEV_SESSIONSTAT_Description	233
335	IGNSSEV_ALLOWSTAT_Description	233
336	AT%IGNSSMEM	234
337	IGNSSMEM_Op_Description	234
338	IGNSSMEM_Bitmask_Description	234
339	AT%IGNSSCEP	235
340	IGNSSCEP_Op_Description	235
341	IGNSSCEP_Days_Description	235
342	AT%LWM2MCMD	237
343	+LWM2MCMD_cmd_Description	238
344	+LWM2MCMD_cmd_Description	239
345	+LWM2MCMD_cmd_Description	240
346	+LWM2MCMD_Binding_Description	241
347	+LWM2MCMD_ServiceStat_Description	241
348	+LWM2MCMD_Val_Description	242
349	+LWM2MCMD_Fota_State_Description	243
350	AT%LWM2MOPEV	244
351	%LWM2MOPEV_Mode_Description	244
352	%LWM2MOPEV_Event_Description	245
353	+LWM2MOPEV_Val_Description	246
354	AT%LWM2MEV	247
355	%LWM2MEV_Event_Description	247
356	%LWM2MEV_Error_Type_Description	248
357	AT%LWM2MOBJEV	248
358	%LWM2MOBJEV_Confirmation_Description	248
359	%LWM2MOBJEV_Fragment_Description	249
360	LWM2MOBJEV_Val_Description	249
361	AT%LWM2MOBJRSP	250
362	%LWM2MOBJRSP_ret_code_Description	250
363	LWM2MOBJRSP_Val_Description	251
364	AT%LWM2MOBJDEF	252
365	%LWM2MOBJDEF_cmd_Description	252
366	%LWM2MOBJDEF_Operation_Description	252
367	%LWM2MOBJDEF_instance_Description	253
368	%LWM2MOBJDEF_data_type_Description	253
369	AT%MQTTCFG	254
370	MQTTCMD_Obj_Description	255
371	AT%MQTTCMD	257
372	%MQTTCMD_Cmd_Description	258

373	AT%MQTTEV	260
374	%MQTTCMD_Ev_Type_Description	261
375	AT%AWSIOTCFG	263
376	%AWSIOTCFG_Cmd_Description	263
377	AT%AWSIOTCMD	265
378	%AWSIOTCMD_Cmd_Description	265
379	AT%AWSIOTEV	267
380	%AWSIOTEV_Ev_Type_Description	268
381	AT%COAPCFG	272
382	COAPCFG_Obj_Description	273
383	AT%COAPCMD	275
384	COAPCMD_cmd_Description	277
385	AT%COAPEV	279
386	COAPEV_ev_type_Description	280

**Contact**

Würth Elektronik eiSos GmbH & Co. KG
Division Wireless Connectivity & Sensors

Max-Eyth-Straße 1
74638 Waldenburg
Germany

Tel.: +49 651 99355-0
Fax.: +49 651 99355-69
www.we-online.com/wireless-connectivity

WÜRTH ELEKTRONIK MORE THAN YOU EXPECT