

Step 1. Create a panel cutout in the panel according to datasheet





Step 2. Assemble by screwing from front of the panel Suggest screw size: Male Screw M3



IP67 Panel Protection

The gasket should be sandwiched tightly between the connector and panel





Note:

IP67 Test follows IEC-60529

IP**6**7 -> Totally protected against dust

IP6<u>7</u>-> Protected against liquid effects of temporary immersion between 15 ~ 100 cm (30 minutes)

Würth Elektronik eiSos GmbH & Co. KG EMC & Inductive Solutions

Max-Eyth-Str. 1 74638 Waldenburg Germany com. +49 79 42 945 - 0

www.we-online.de eiSos@we-online.de



CREATED CHECKED
CTC OTS

DESCRIPTION

IP67 N TYPE Panel Jack 4-Hole Installation Guide

REVISION STATUS DATE BUSINESS UNIT 2022-08-24 eiCan