




**Step 1.** Prepare connector components



**Step 2.** Put body on the PCB and center contact need to place on the middle of the trace.




**Step 3.** Bring the contact body close to the PCB and mounting holes aligned with the PCB through holes.



Mounting holes aligned with the PCB through holes

**Step 4.** Using 0.5 N\*m torque force to screw the bolt.

⚠ Do not apply excessive force, it might damage connector and PCB.



Würth Elektronik eiSos GmbH & Co. KG  
 EMC & Inductive Solutions  
 Max-Eyth-Str. 1  
 74638 Waldenburg  
 Germany  
 Tel. +49 (0) 79 42 945 - 0  
 www.we-online.com  
 eiSos@we-online.com

CREATED AK	CHECKED OTs		
DESCRIPTION <b>Assembly instructions</b> <b>603 128 621 125 52</b>			
REVISION 001.002	STATUS Valid	DATE 2023-09-12	BUSINESS UNIT eiCan

This electronic component has been designed and developed for usage in general electronic equipment only. This product is not authorized for use in equipment where a higher safety standard and reliability standard is especially required or where a failure of the product is reasonably expected to cause severe personal injury or death, unless the parties have executed an agreement specifically governing such use. Moreover Würth Elektronik eiSos GmbH & Co KG products are neither designed nor intended for use in areas such as military, aerospace, aviation, nuclear control, submarine, transportation (automotive control, train control, ship control), transportation signal, disaster prevention, medical, public information network etc.. Würth Elektronik eiSos GmbH & Co KG must be informed about the intent of such usage before the design-in stage. In addition, sufficient reliability evaluation checks for safety must be performed on every electronic component which is used in electrical circuits that require high safety and reliability functions or performance.